




PDL ELECTRONICS LTD

**ELITE SERIES TECHNICAL MANUAL
PART NO. 4201-180 REV J**

Head Office:
81 Austin Street
P.O. Box 741
Napier
New Zealand
Tel.: +64-6-843-5855
Fax.: +64-6-843-5185

4201-003 Rev C
Page 1 of 8



IMPORTANT NOTES

SAFETY WARNINGS:

- It is the installer's responsibility to ensure the configuration and installation of the Elite Series meets the requirements of any site specific, local and national electrical regulations.
- The Elite Series operates from HIGH VOLTAGE, HIGH ENERGY ELECTRICAL SUPPLIES. Stored charge is present after switch off.
- Due to the high leakage currents inherent to AC drives, earth connection of both the motor and the Elite Series is essential before connection to the supply. The Elite Series must be permanently connected to the supply.
- For safety reasons, normal operation of the Elite Series requires front covers/doors to be in place and secured closed.
- Do not attempt to isolate the motor while the Elite Series is running.
- Some parameter settings may cause the Elite Series to start automatically after power failure.
- Motor overspeed operation may be limited by mechanical constraints.

RELIABILITY WARNINGS:

- Always screen control wiring.
- Ensure that the Elite Series is not mounted in an adverse environment.

SERVICING WARNINGS:

- Service only by qualified personnel.
- Always isolate and allow to discharge before servicing.
- Never replace ceramic fuses with glass types.
- Always wear safety glasses when operating with the cover removed.
- The Elite Series contains static sensitive printed circuit boards. Use static safe procedures when handling these boards.
- Never work on live equipment alone.
- Observe all recommended practices.

NOTES:

- This manual and the screen list contained within this document relate to Elite Series software version **3.7**. Refer to Screen Z2 for the software version of your Elite Series.
- It is the responsibility of the end user/purchaser to ensure that operators understand how to use this equipment safely. Please read this manual thoroughly.
- The latest revision of this manual is available from our web-site **www.pdl.co.nz**.

DEDICATION TO QUALITY

AC Motor Control Products can dramatically improve your process control, productivity and energy efficiency, but only if they are working correctly.

Which is why we at PDL Electronics go to great lengths in our design and manufacturing, to ensure that our products operate correctly first time, every time.

An extensive research and development investment ensures that this product is one of the most technically advanced in the world, with built-in strength and robustness to suit your application and environment.

Our AS/NZS ISO 9001 certification gives you the confidence of our international, independently certified Quality Assurance program. All staff are actively involved in continuous improvement programs with a customer focus.

The components that go into our products are selected from the best in the world - and must pass our rigorous and demanding test program.

Finally, every new drive design is run through a rigorous test program, including full load operation at above rated temperature, under the most demanding load conditions.

Our dedication to quality makes the PDL Electronics product, regardless of price, less expensive than other controllers in the long run.

COMPREHENSIVE SUPPORT PROGRAM

The PDL Electronics customer support program demonstrates our confidence in our Quality Assurance system. We have total faith in our products and their reliability, and so provide a comprehensive warranty.

Fully trained engineers and technicians, with a wealth of experience and easy access to information, can assist in solving any of your drive application projects.

Our service staff are available for commissioning, after sales service, and repairs, 24 hours a day, seven days a week.

We select capable and highly qualified representatives to act as our distributors and service agents. Only after passing PDL Electronics' intensive training program are they accredited for repair or on-selling of our products.

To further support our products and customers, we run a series of comprehensive training programs focusing on self maintenance and application advice. These are available on-site and at our Head Office.

REVISION HISTORY

Date:	Revision:	Description:
April 1997	D	Process Control and Fibre Optic Mode added.
Nov. 1997	E	Elite Software Version 2.0
May 1998	F	Ultradrive specifications added
March 1999	G	Add large Ultradrive specifications
Dec. 2000	H	Update to software revision 3.5. UL listings added. 500V ratings & Open Loop Vector added.
Oct. 2001	I	New 500V ratings and parallel drive fault codes added
April 2002	J	UL Cables sizes added

CONTENTS

1	INTRODUCTION TO THE ELITE SERIES AC MOTOR CONTROLLER	9
1.1	THE CONCEPT	9
1.2	THE ELITE SERIES RANGE	9
1.3	THE BASIC PRINCIPLE OF FLUX VECTOR CONTROL	9
1.4	CONFIGURATION OF CONTROLLER TYPE	9
1.5	CONTROL CONFIGURATION OPTIONS	9
2	ELITE SERIES SPECIFICATIONS	10
2.1	ELITE SERIES SPECIFICATIONS	10
3	DESCRIPTIONS	13
3.1	DESCRIPTION OF THE ELITE SERIES HARDWARE	13
3.1.1	Overview	13
3.1.2	Power Conversion	15
3.1.3	Control Board	15
3.1.4	The Display Unit and Controls	18
3.1.5	Control Inputs and Outputs	18
3.2	DESCRIPTION OF THE ELITE SERIES CONTROL SYSTEM	20
3.2.1	Structure of the Inputs and Outputs	20
3.2.2	Structure of the Motor Control System	21
4.1	THE MOTOR	25
4.1.1	Sizing the Motor and Elite Series	25
4	APPLICATION RECOMMENDATIONS	25
4.1.2	Operation Above Motor Rated Speed	25
4.1.3	Operation of More Than One Motor	25
4.1.4	Thermal Protection of the Motor	25
4.1.5	Large Frame-size Motor Considerations	26
4.2	THE ENCODER	26
4.2.1	Choice of Encoder	26
4.2.2	Connection of the Encoder	26
4.3	SWITCHING	26
4.3.1	Power Switching	26
4.3.2	Motor Switching	26
4.4	TORQUE AND SPEED CONTROL MODES	26
4.4.1	Torque Control Mode	26
4.4.2	Speed Control Mode	27
4.4.3	Switching Between Torque and Speed Control Modes	27
4.5	DYNAMIC BRAKING	27
5	UNPACKING, INSTALLATION AND CONNECTION	28
5.1	UNPACKING	28
5.2	INSTALLATION	28
5.3	MANUFACTURER'S RECOMMENDATIONS	28
5.4	POWER WIRING CONNECTIONS	28
5.5	CONTROL WIRING CONNECTIONS	29
5.6	SHAFT ENCODER CONNECTIONS	29
5.7	FIBRE OPTIC CONNECTION	29
5.8	DYNAMIC BRAKE DETAILS	29

5.9	ANCILLARY EQUIPMENT	29
5.10	COMMISSIONING DETAILS	29
6	SERVICE AND MAINTENANCE	33
6.1	FAULT FINDING	33
6.1.1	Electrical Failure	33
6.1.2	Protective Fault Operation	33
6.1.3	Encoder Failure	33
6.1.4	Incorrect Set-up or Adjustment	33
6.1.5	Poor Vector Control Tuning	33
6.1.6	Failure of External Control Device	33
6.1.7	Failure of the Display Unit	33
6.2	THE FAULT SCREEN	34
6.2.1	Control of the Fault Screen	34
6.2.2	Fault Messages	34
6.3	USE OF LED INDICATORS	37
6.4	FUSE FAILURE	38
7.1	DISPLAY UNIT CONTROLLABILITY	39
7.2	MENU STRUCTURES AND SCREENS	39
7.2.1	Screen Lists	39
7.2.2	Scrolling, Unfolding and Folding	39
7	THE ELITE SERIES DISPLAY UNIT	39
7.2.3	Parameter Conventions	39
7.2.4	Adjusting a Screen Value	39
7.2.5	Off to Modify	40
7.3	OPERATING MODES	40
7.3.1	Summary of Operating Modes	40
	40	
7.3.2	Swapping Between OPERATION and COMMISSIONING Modes	40
7.3.3	MENU SET-UP Mode	41
8.1	PDL VYSTA® FOR WINDOWS CONFIGURATION SOFTWARE	42
8.2	CUSTOM SCREEN CONFIGURATION	42
8	CUSTOMISATION OF CONTROL	42
8.3	PDL DRIVELINK FOR WINDOWS SOFTWARE PACKAGE	42
8.4	MODBUS COMMUNICATIONS CONNECTIONS BETWEEN PC AND DRIVE	42
8.4.1	The Elite Series to PC Connection	42
8.4.2	Configuring the Connection	42
8.4.3	Down-loading from a PC to the Elite Series	42
9	THE DEFAULT SCREEN LIST	43
10	APPLICATION EXAMPLE - SIMPLE FAN SPEED CONTROL	85
	COMMISSIONING CONFIGURATION RECORD — SCREENS	86
	COMMISSIONING CONFIGURATION CONTROL — TERMINALS	88
	ELITE SERIES SPARES LIST	89
	ULTRADRIVE ELITE SPARES 400VAC (FRAMES 5-7)	91
	ULTRADRIVE ELITE SPARES 500V (FRAMES 5-7)	92

FIGURES

Figure 2.1:	Elite Series 400V Nominal and Re-rated Specifications	11
Figure 2.2:	Elite Series 500V Nominal and Re-rated Specifications	12
Figure 3.1:	Microdrive Elite Series Dimensions	13
Figure 3.2:	Ultradrive Elite Frame 4 Dimensions	14
Figure 3.3:	Ultradrive Elite Frames 5 to 7 Dimensions	15
Figure 3.4:	Elite Series Electrical Overview	16
Figure 3.5a:	Power Electronics - Microdrive Elite Frames 1 & 2	17
Figure 3.5b:	Power Electronics - Microdrive Elite Frame 3	17
Figure 3.5c:	Power Electronics - Ultradrive Elite Frame 4	17
Figure 3.5d:	Power Electronics - Ultradrive Elite Frames 5 to 7	17
Figure 3.6:	The Display Unit and Keys	18
Figure 3.7a:	Control Terminals T1-T21	19
Figure 3.7b:	Control Terminals T22-T42	20
Figure 3.8:	Structure of the Elite Series Input/Output Processing System	22
Figure 3.9:	Structure of the Elite Series Motor Control System	23
Figure 3.10:	Process Control	24
Figure 4.1:	Elite Series Thermal Overload Characteristics	25
Figure 4.2:	Typical Motor Thermal Derating	25
Figure 4.3:	Dynamic Brake Resistor Ratings (Typical)	27
Figure 5.1:	Elite Series Power Terminal tightening Torque	29
Figure 5.2:	Elite Series Power Connection	29
Figure 5.3:	Shaft Encoder Connection Details	30
Figure 5.4:	Microdrive Elite Series Cable Configuration	30
Figure 5.5:	Ultradrive Elite Frame 4 Cable Configuration	31
Figure 5.6:	Ultradrive Elite Frame 5 Cable Configuration	31
Figure 5.7:	Ultradrive Elite Frame 6 Cable Configuration	32
Figure 5.8:	Ultradrive Elite Frame 7 Cable Configuration	32
Figure 7.1:	The Display Unit	39
Figure 7.2:	Screen Unfolding and Folding	39
Figure 7.3:	Setting Commission Mode after a Password has been set	40
Figure 7.4:	Setting a Password for the First Time	40
Figure 7.5:	Entering and Exiting Menu Set-up Mode	41
Figure 7.6:	Typical Screen Display in Menu Set-up Mode	41
Figure 9.1a:	Screen List A-H	43
Figure 9.1b:	Screen List I-N	44
Figure 9.1c:	Screen List O-P	45
Figure 9.1d:	Screen List R-Z	46
Figure 9.2:	Comparator Source Selection	49
Figure 9.3:	Local Start/Stop-Reset Control	53
Figure 9.4:	Speed Reference Source Selection	54
Figure 9.5:	Torque Reference Source Selection	54
Figure 9.6:	Analogue Input Format Selection	55
Figure 9.7:	Analogue Input Scaling and Torque/Speed Limits	55
Figure 9.8:	Analogue Input Reference Zero Band	56
Figure 9.9:	Input Mode Selection	57
Figure 9.10:	Active High/Active Low Selection	58
Figure 9.11:	Multi-function Input Functions (Selectable Functions)	59
Figure 9.12:	Fibre Optic Control Mode Selection	59
Figure 9.13:	Skip Speeds	61
Figure 9.14:	Special Functions using Multi-Reference Setpoints	62
Figure 9.15:	Multi-Reference 2 Wire Functions	62
Figure 9.16:	Function of Multi - Reference 3 Wire	63
Figure 9.17:	Analogue & Fibre Outputs Source Selection	65
Figure 9.18:	Analogue Output Format Selection	66
Figure 9.19:	Analogue Output Scaling	66
Figure 9.20:	Relay Table Selection	67
Figure 9.21:	Process Control Setpoint Source	68
Figure 9.22:	Process Control Feedback Source	69
Figure 9.23:	Dual Acceleration/Deceleration Rates	70
Figure 9.24:	Stopping Modes	73
Figure 9.25:	Start and Off Delay Times	73
Figure 9.26:	Initialisation Levels	80

SYMBOLS USED



Caution, risk of electric shock *ISO 3864, No. B.3.6*



Caution (refer to accompanying documents) *ISO 3864, No. B.3.1*



Three-phase alternating current *IEC 617-2, No. 02-02-06*



Direct Current *IEC 417, No. 5031*



Protective Earth (PE) Terminal *IEC 417 No. 5019*



Earth (ground) Terminal *IEC 417 No. 5017*



Induction motor, three phase, squirrel cage *IEC 617-2, No. 06-08-01*

1 INTRODUCTION TO THE ELITE SERIES AC MOTOR CONTROLLER

1.1 THE CONCEPT

The AC induction motor is the preferred choice of motive power for many industrial applications. With the development of electronic variable voltage variable frequency (VVVF) controllers, it became possible to control the speed of the induction motor. PDL Electronics has been at the forefront of development of VVVF controllers for the past 25 years.

However standard VVVF controllers have certain performance limitations, specifically in applications where high torque is required at standstill and very low speeds, and in applications where extremely fast dynamic response is required. To address these limitations, PDL Electronics has developed the Elite Series of controllers. Advanced flux vector control techniques enables extended performance to be obtained from the AC induction motor, including full torque at standstill, and a speed response rivalling that of servomotors.

The Elite Series further evolves the hardware and software technology of previous ranges. The same Elite Series induction motor controller can be used without motor feedback for general industry applications, or with a shaft encoder (pulse tacho) driven by the motor to give the full performance associated with flux vector orientation control.

1.2 THE ELITE SERIES RANGE

The Elite Series has been developed from PDL's previous AC motor controller series, the Microdrive and Microvector. It inherits the Microdrive's simplicity and well proven electrical design. The Elite Series improves on the already highly flexible digital controls which have become the hallmark of the Microdrive and Microvector series.

The Elite Series range currently consists of 37 models spanning the range from 0.75 kW to 355kW (1hp to 500hp), with extensions to the range presently under development. All models are constructed to meet IP54, for protection against the ingress of dust and splashing water. Alternatively, IP20 rated models are also available for the Microdrive Elite Series.

Elite Series models up to frame 4 have attained UL listing in the categories of Power Conversion Equipment and Power Conversion Equipment Certified for Canada.

1.3 THE BASIC PRINCIPLE OF FLUX VECTOR CONTROL

Field orientated flux vector control (or simply vector control) is a technique for controlling the torque developed by an AC induction motor. By independently controlling the magnitude of the air gap flux and the rotor current, and maintaining their orthogonality, it becomes possible to directly control the torque output of the motor. This is achieved by controlling the torque-producing and flux-producing components of the motor stator current. This is similar to controlling the armature and field currents in a separately excited DC motor. To achieve this level of control, the shaft speed and position must be sensed using a shaft encoder on the motor.

The Elite Series employs this technique in its Closed Loop Vector control mode. However if a shaft encoder is not used on the motor, Open Loop Mode control operation is available. This uses sophisticated monitoring and modelling techniques

to estimate the rotor position. Speed and torque accuracy are sacrificed, and very low speed operation **may not be possible**.

1.4 CONFIGURATION OF CONTROLLER TYPE

When the Elite Series is set up for Closed Loop Vector control, it is set up as a torque controller. If further configured to "torque control" mode, it provides accurate output torque from the motor, in response to an external torque reference signal. This torque is available down to zero speed. This mode is most suited for use in torque control applications, e.g., power winder and rewinder systems. It can also be used in position control applications, with an external speed-position controller. A quadrature shaft encoder will be required on the motor, to provide rotor position feedback.

Closed Loop Vector control "speed control" mode is recommended for servomotor type applications, or anywhere that a speed controller with fast dynamic response or accurate speed holding is required. This mode is suitable for elevators or crane hoists, and other applications where full torque capability at zero speed are required. In this mode, the Elite Series can also be used in conjunction with an external position controller to do position control applications. A quadrature shaft encoder will be required on the motor, to provide rotor position and speed feedback.

Open Loop Mode control operating mode is for general purpose speed control applications, e.g., pumps, fans, conveyors, mixers etc. This mode gives equivalent or better performance to that of drives using previous VVVF technologies. In this mode, a quadrature shaft encoder on the motor is not necessary.

The V/Hz control operating mode is also suitable for general purpose speed control applications e.g., pumps, fans, conveyors, mixers etc. This mode gives equivalent or better performance to that of drives using previous VVVF technologies. When multiple motors are to be driven from the output of the Elite Series, the V/Hz control operating mode must be utilised.

The Elite Series will also function as an accurate sensor of torque, power and speed. The accuracy of this sensing is improved by using in Closed Loop Vector control operating mode. The outputs are available in analogue or digital format, or can be applied to internal comparators and limits.

1.5 CONTROL CONFIGURATION OPTIONS

The functions and formats of the six digital and two analogue inputs, and three digital and two analogue outputs, can be configured in a number of different ways.

Full details of the available screens and control functions are given in Section 9 of this manual.

2 ELITE SERIES SPECIFICATIONS

2.1 ELITE SERIES SPECIFICATIONS

INPUT

Input frequency range	48 to 62Hz
Input current	< output current
Input displacement factor	> 0.99
Input current THD	< 40%
Power loss ride through	> 2 seconds at nominal voltage
Input voltage	(model dependant) refer Figures 2.1 and 2.2 for details.

OUTPUT

Output voltage to motor	
Microdrive Elite Series	0 to V_{IN} -3V @ 100% load
Ultradrive Elite Series	0 to V_{IN} -15V @ 100% load
Current overload capability	150% for 30 secs (when hot) at 50°C at nominal rating 150% for 60 secs (when hot) at 40°C at nominal rating
Frequency range	
Closed Loop Mode	0 to \pm 100Hz
Open Loop Mode	0 to \pm 100Hz
V/Hz Mode	0 to \pm 400Hz
Efficiency (full load, 50Hz)	>97%
Suit motor rated kW	typically 50 to 150% of Elite Series nominal rating
Suit motor rated voltages	5 to 500Vac
Suit motor rated frequencies	10 to 400Hz
Modulation method	Space vector modulation
Modulation frequency	Up to 16kHz Whisper Wave or Narrow Band (model dependant)
Cable Length	Maximum cable length is typically 150m, but it is dependant on cable type and switching frequency. For more information please refer to PDL Document 4216-035, (The effect of long cable runs on inverter outputs).

ENVIRONMENTAL

Protection standard	Refer to Figures 2.1 and 2.2.
IP54/NEMA 12	Protected against dust and splashing water. Maximum pollution degree 2.
IP20/NEMA 1	Protected against accidental electrical contact. Maximum pollution degree 1.
Operating temperature	0°C to 50°C
Temperature re-rating of output current @ 40°C	
For quadratic torque applications, the Elite Series may be up-rated when operated with a maximum ambient temperature of 40°C. Refer to Figures 2.1 and 2.2.	
Storage temperature	-25°C to +80°C
Relative humidity	<90%, noncondensing

Altitude	1000m
Altitude derating (>1000m)	-1% per 100m; 3000m max
Display unit protection	IP54, dust and splashing water protected

MOTOR AND DYNAMIC BRAKE PROTECTION

Motor thermal model trip	PTC thermistor trip
Overload warning	Shear pin trip (configurable)
Dynamic brake resistor thermal model trip	
Torque limit and time-out (configurable)	
Speed limit and time-out (configurable)	

ELITE SERIES PROTECTION

Supply loss	Input phase loss
Software thermal model	Heatsink overheat
IGBT overload	Internal air overheat
Output current limit	Output current trip
DC bus voltage limiting	400V 500V
Software	720Vdc 820Vdc
Hardware	750Vdc 850Vdc
Phase Fault	Ground fault
Low DC bus voltage	Regeneration limit
Hardware failure	

CONTROL

Control method	Closed Loop Mode, Open Loop Mode, V/Hz Mode
Analogue inputs	2 inputs, configurable as 0–10Vdc, \pm 10Vdc, 4–20mA or 0–20mA
Digital inputs	6 inputs, configurable as active high/low, inch, speed or torque select, direction invert functions; front panel configurable to provide stop, start, reset
Analogue outputs	2 outputs, configurable as 0-10Vdc, \pm 10Vdc, 4-20mA or 0-20mA, with multiple function selections for each
Relay outputs	1 changeover, 2 normally open, rated 250Vac or 30Vdc 2A non-inductive, with multiple function selections for each
Display unit controls	2 lines x 16 characters liquid crystal display, start, stop-reset push-buttons. Increase, decrease, select push-buttons. Display unit can be removed and relocated up to 3m distance.

Specifications are subject to change without notice

Elite Series 400V Ratings

Rated Voltage (V_{IN}) 380Vac to 440Vac (-10% to +10%)
Supply type 3 phase earthed neutral

ENCLOSURE RATING	FRAME	MODEL	380V-440V (Note 1)			RECOMMENDED CABLE SIZING PER PHASE		FUSES PER PHASE
			I[A] @ 50°C (Note 2)	MOTOR kW @ 400V 50°C (Note 3)	I[A] @40°C F>25Hz (Note 4)	AWG/kcmil	mm ²	A (Notes 5)
Nema 12 & Nema 1 models available IEC IP54 & IP20 models available	1	ME-2.5	2.5	0.75	3.1	14 to 12	2.5 to 4	6
		ME-6.5	6.5	3	8.1	12 to 10	2.5 to 4	16
		ME-10.5	10.5	4	13.1	12 to 10	2.5 to 4	25
		ME-12	12	5.5	15	10 to 8	4 to 6	32
	2	ME-18	18	7.5	22.5	10 to 8	4 to 6	40
		ME-22.5	22.5	11	28	10 to 8	4 to 6	50
	3	ME-31	31	15	39	8 to 6	6 to 10	80
		ME-38	38	18.5	47	6 to 4	10 to 16	100
		ME-46	46	22	57	4 to 3	16 to 25	100
Nema 12 IEC IP54 Electronics Enclosure	4	UE-60	60	30	75	3 to 1	25 to 35	150
		UE-75	75	37	94	1 to 1/0	35 to 50	200
		UE-90	90	45	112	1/0 to 3/0	50 to 70	200
		UE-115	115	55	144	2/0 to 4/0	70 to 95	300
		UE-140	140	75	175	4/0 to 250	95 to 120	300
Nema 1 IEC IP20 Termination Nema 12 IEC IP54 Electronics Enclosure	5	UE-170	170	90	187	3/0 to 300	95 to 150	350
		UE-210	210	110	230	250 to 400	120 to 240	350
		UE-250	250	132	275	350 to 500	185 to 2400	350
	6	UE-305	305	160	335	2 by 500	2 by 240	2 by 350
		UE-340	340	160	374	2 by 500	2 by 240	2 by 350
		UE-420	420	225	462	2 by 500	2 by 240	2 by 350
		UE-480	480	250	528	2 by 500	2 by 240	2 by 350
	7	UE-575	575	315	632	3 by 500	3 by 240	3 by 350
		UE-660	660	355	726	3 by 500	3 by 240	3 by 350
Parallel Drives		UE-830	830	450	910	4 by 500	4 by 240	4 by 350
		UE-1000	1000	560	1100	4 by 500	4 by 240	4 by 350
		UE-1140	1140	630	1250	6 by 500	6 by 240	6 by 350

Note 1: Frames sizes 1-4 are also available to suit a 230Vac (-20+10%) supply.
 Note 2: Current rating is constant across the voltage range.
 Note 3: Power rating applies to typical 4-pole machines only. Check your motor specification before selecting.
 Note 4: Decrease linearly to nominal at 0Hz.
 Note 5: Fuse must be selected to protect circuits with a maximum 200kA symmetrical short circuit supply.

Figure 2.1: Elite Series 400V Nominal and Re-rated Specifications

Elite Series 500V Ratings

Rated Voltage (V_N)
Supply type
440Vac to 500Vac (-10% to +10%)
3 phase earthed neutral



ENCLOSURE RATING	FRAME	MODEL	440-500V (Note 1)						RECOMMENDED CABLE SIZING PER PHASE		FUSES PER PHASE
			@ 50°C			@40°C			AWG/kcmil (Notes 5-6)	mm ²	A (Notes 7-10)
			I[A] (Note 2)	MOTOR kW 500V (Note 3)	MOTOR HP 460V (Note 3)	I[A] F>25Hz (Note 4)	MOTOR kW 500V (Note 3)	MOTOR HP 460V (Note 3)			
Nema 12 IEC IP54 Electronics Enclosure	1	ME-2D	2.5	1.1	1.0	3.1	1.5	1.5	14 to 12	2.5 to 4	6
		ME-6D	6	2.2	3.0	7.6	4	5	12 to 10	2.5 to 4	16
		ME-9D	9	4	5	12	7.5	7.5	12 to 10	2.5 to 4	25
		ME-11D	11	5.5	7.5	14	9	10	10 to 8	4 to 6	32
	2	ME-16D	16	7.5	10	21	11	15	10 to 8	4 to 6	40
		ME-21D	21	11	15	27	15	20	10 to 8	4 to 6	50
	3	ME-30D	30	18.5	20	37.5	22	25	8 to 6	6 to 10	80
		ME-35D	35	22	25	45	30	30	6 to 4	10 to 16	100
		ME-41D	41	22	30	52	33	40	3 to 1	16 to 25	100
Nema 12 IEC IP54 Electronics Enclosure	4	UE-60D	60	37	40	75	45	50	6 to 3	16 to 36	150
		UE-75D	75	45	50	94	55	60	4 to 1	20 to 50	200
		UE-90D	90	55	60	112	75	75	3 to 1/0	25 to 50	200
		UE-115D	115	75	75	144	90	100	1 to 3/0	50 to 95	300
		UE-140D	140	90	100	175	110	125	2/0 to 4/0	70 to 120	300
Nema 1 IEC IP20 Termination Nema 12 IEC IP54 Electronics Enclosure	5	UE-170D	170	110	125	205	132	150	3/0 to 300	95 to 150	350
		UE-205D	205	132	150	250	160	200	250 to 400	120 to 240	350
		UE-250D	250	160	200	305	200	250	350 to 500	185 to 2400	300
	6	UE-305D	305	200	250	370	250	300	2 by 500	2 by 240	2 by 350
		UE-370D	370	250	300	440	315	350	2 by 500	2 by 240	2 by 350
		UE-440D	440	315	350	540	355	450	2 by 500	2 by 240	2 by 350
	7	UE-540D	540	355	450	620	400	500	2 by 500	2 by 240	2 by 350
		UE-620D	620	400	500	700	500	600	3 by 500	3 by 240	3 by 350
	Parallel Drives	UE-700D	700	500	600	850	630	680	3 by 500	3 by 240	3 by 350
		UE-760D	760	560	600	930	630	680	4 by 500	4 by 240	4 by 350
		UE-930D	930	630	680	1070	710	845	4 by 500	4 by 240	4 by 350
		UE-1070D	1070	710	845	1200	800	952	6 by 500	6 by 240	6 by 350
	UE-1200D	1200	800	952	1470	1000	1207	6 by 500	6 by 240	6 by 350	
Note 1:	Frames 1-4 are UL/cUL approved to 480Vac. Frames 5-7 & Parallel drives (inside delta) are UL/cUL approved to 500V. Frames 1-4 are also available to suit a 230Vac (-20+10%) supply.					Note 6:		Frame 1 maximum cable size for UL/cUL compliance is 5.3 mm ² (10WG).			
Note 2:	Current rating is constant across the voltage range.					Note 7:		Frames 1-2 input fuses must be of type gG (distribution) or gR/UR (semiconductor).			
Note 3:	Power rating applies to typical 4-pole machines only. Check your motor specification before selecting.					Note 8:		Frames 3-4 input fuses must be type gR/UR (semiconductor). Input fuses with UL recognition type gR/UR (semiconductor) are supplied pre-fitted for Frames 5-7 & Parallel drives.			
Note 4:	Decrease linearly to nominal at 0Hz.					Note 9:		If UL/cUL is to be complied with UL/cUL recognised fuses must be fitted.			
Note 5:	To comply with UL/cUL, use copper conductors only.					Note 10:		Fuses must be selected to protect circuits with a maximum 200kA symmetrical short circuit supply.			

Figure 2.2: Elite Series 500V Nominal and Re-rated Specifications

3 DESCRIPTIONS

3.1 DESCRIPTION OF THE ELITE SERIES HARDWARE

3.1.1 Overview

The Elite Series range is a family of advanced AC induction motor controllers, presented in seven frame styles. All models are available with IP54 ingress protection rating, suitable for installation in an environment where dust and splashing water may be present. Alternatively, IP20 rated models are also available for the Microdrive Elite Series.

Ensure the correct model was specified for the intended environment. For detailed dimensional drawings, refer to Figures 3.1 to Figure 3.3.

An electrical overview is shown in Figure 3.4.

Full details of mounting are provided in the Elite Series Getting Started Manual, Part No. 4201-179.





Figure 3.1: Microdrive Elite Series Dimensions



MODELS	Net Weight kg (lbs)	Packaged Weight kg (lbs)
UE-60, UE-75	73.5 (162.04)	90 (198.42)
UE-90	77.5 (170.86)	94 (207.24)
UE-115, UE-140	80.5 (177.47)	97 (213.85)

Figure 3.2: Ultradrive Elite Frame 4 Dimensions




Figure 3.3: Ultradrive Elite Frames 5 to 7 Dimensions

3.1.2 Power Conversion

Key electrical circuit elements of the Elite Series range are shown in Figure 3.5.

AC power is fed to the Elite Series input via external input fuses. Here it is rectified to DC, filtered by chokes and capacitors and reconverted ("inverted") to AC current at the appropriate frequency, phase and voltage to supply the motor.

DC bus terminals are provided for connection of dynamic braking modules or direct supply from a DC source (external soft charge needed for DC supply).

3.1.3 Control Board

The control processor (control board) is supplied from the DC bus via a DC to DC converter. In this way the control system uses the DC bus to provide brief energy storage to achieve significant immunity to small mains supply interruptions or variations. Provision is made for energising of the control board from an external power supply.

A Display Unit (3 LEDs, 16 x 2 character alphanumeric display, 3 keys, and START and STOP-RESET push-buttons) provides the primary user interface to the Elite Series. Detail follows in Section 3.1.4. The Elite Series can be configured from this Display Unit. Alternatively custom configuration can be achieved by use of the external PDL Vysta® for Windows software package, on a PC running Microsoft Windows.

The push-buttons can be configured to be inactive, or to provide stand-alone START/STOP-RESET control.

Analogue and digital inputs and outputs are provided as detailed in Section 3.1.5. More details can be found in the Elite Series Getting Started Manual, Part No. 4201-179.




Figure 3.4: Elite Series Electrical Overview




Figure 3.5a: Power Electronics - Microdrive Elite Frames 1 & 2




Figure 3.5b: Power Electronics - Microdrive Elite Frame 3




Figure 3.5c: Power Electronics - Ultradrive Elite Frame 4




Figure 3.5d: Power Electronics - Ultradrive Elite Frames 5 to 7




Figure 3.6: The Display Unit and Keys

3.1.4 The Display Unit and Controls

The Display Unit of the Elite Series may be removed from the front of the unit, and refitted in any orientation, or mounted remotely from the unit (up to three metres away). The display is in an IP54 enclosure, thus is protected against ingress of dust and moisture.

The following descriptions refer to Figure 3.6.

THE LED INDICATORS

- ON Indicates mains power is supplied to the Elite Series Display.
- RUN Indicates the Elite Series is running (driving a motor).
- OK Steady: Indicates that the Elite Series is operating normally.
- OK Flashing: Indicates that the Elite Series has tripped on fault protection.

THE LCD DISPLAY

The Elite Series has a sixteen character by two line (16x2) LCD display.

The lines each have different functions:

- The STATUS LINE is always present and shows the Elite Series status, the output current or torque and the motor speed.
- The CONTROL LINE of the display is used to view and/or adjust the many parameters of the Elite Series.

THE CONTROL KEYS

The "+" and "-" keys are used to scroll between screen groups. The "*" key can be used to unfold a screen group, then the "*" and "+" or "-" keys used to adjust the parameter or mode on display on the control line. Refer to Section 7 of this manual for full details of screen organisation and control.

THE START AND STOP-RESET PUSH-BUTTONS

These push-buttons may be configured to enable starting and stopping of the motor from the display unit if required, and also to reset the Elite Series in the event of a fault trip.

Alternatively, the START push-button can be configured to be in parallel with an external START switch, and the STOP-RESET push-button in series with an external STOP-RESET switch.

Details on configuring these push-buttons are given in Section 9 of this manual.

SCREEN ORGANISATION

Screens can be arranged in **folded** format. Each screen group has a main screen with the group identifying letter and description. Folded under this main Screen can be a number of subscreens, each of which has a single parameter or mode for viewing or adjustment. These subscreens cannot be viewed until unfolded using the "*" key. The entire set of screens is known as a Screen List.

Once unfolded, some subscreens in a Screen List have a numerical parameter which may be adjusted. Others may have a list of options, with each option separately viewable and selectable.

Each screen or subscreen has a viewing attribute. This attribute defines if the screen is "read only", "read-write" or "hidden".

Note that the main screen or subscreen will be visible only if its attribute is configured to be "read" or "read-write". If a screen is configured as "hidden" it will only be visible when the Elite Series is in "commissioning" mode.

Details on controlling these screens and adjusting parameters and modes are given in Section 7 of this manual.

Full details of the Screen List are given in Section 9 of this manual.

CUSTOMISATION OF CONFIGURATION

The Elite Series Control Board processor has a number of logic and processing blocks integrated into the firmware. These can be configured using **PDL VYSTA® for Windows** to enhance the existing default configuration, or for configuring a completely new control system. These blocks include logic gates, counters, timers, analogue signal processors, PID controllers, inputs and outputs.

To suit any custom configuration, a custom Screen List can also be designed. This Screen List may be a modified version, or a foreign language version, of the default Screen List provided.

More details on customisation of control are given in Section 8 of this manual.

SECURITY PROTECTION

For reasons of security, the Elite Series must be in **commissioning mode** (Screen Z) before certain adjustments can be made. Some adjustments also cannot be made unless the Elite Series is in a OFF state (this is for safety reasons).

If **commissioning mode** is enabled, any user can adjust all settings and configurations. To enable this mode, scroll to Screen Z, and enter the correct password. Further details are given in Section 9 of this manual.

3.1.5 Control Inputs and Outputs

Figure 3.7 provides the complete electrical specification of all Elite Series control inputs and outputs. Each input and output is individually described below. Further information (including specific examples of connection) is presented in the detailed descriptions of the relevant control screens.

For further connection information to these terminals, refer to Elite Series Getting Started Manual, Part No. 4201-179.

Terminals T1 to T7 - Configurable Relay Outputs

These are low power relay contacts offering operation at signal or 250Vac levels (referenced to the protective earth - PE). Selection of their function is made through Screen Group O. Avoid settings which cause the relays to switch excessively as this will reduce their life expectancy. The software places a 250ms minimum pulse width to prevent relay chatter.

Terminals T8, T9 - Dynamic Brake Control

If a dynamic brake is to be installed in conjunction with the Elite Series, it can be controlled from these terminals. For drives up to and including ME-22.5, these terminals will be internally connected to the inbuilt dynamic brake transistor. Dynamic brake resistor thermal protection can be configured from Screen Group D.

Terminal T10 to T12 - Display Unit

The connections to the Display Unit are made via these terminals. The Display Unit may be removed from its position within the drive and be mounted remotely. The maximum allowable length of wiring is 3 metres.

Terminals T13 to T18 - Multi-function Inputs

The function of these inputs can be programmed from the keyboard, from Screen Group I. Alternatively they can be customised via the PDL Vysta® for Windows software running on a personal computer.

Their operating format may be set for active high or active low. These inputs are factory preset for active high operation (that is, they are internally connected to bias low). Sampling rate: 4ms

Terminal T19 - External trip/Motor PTC

This is a digital input committed to causing a protective trip should the resistance between this terminal and the selected common exceed 2.1kOhms. This is characterised for a set of standard motor PTC thermistors. The operating mode of the input can be changed between active high and active low. Opening this circuit will always trip the Elite Series, removing power from the motor. Open this circuit in the event of a "loss of control" situation. Sampling rate: 4ms

Terminals T20, T21 - Input Switch 0V & +24Vdc Connections

These terminals provide a return point for the seven digital inputs connected to terminals T13 to T19. If active high is selected, the common points of the switches connect to Terminal T21. If active low is selected, the common points of the switches connect to Terminal T20.




Figure 3.7a: Control Terminals T1-T21

Terminal T22 - Analogue Output 0V Connection

This 0V is a suitable return point for the two analogue outputs connected to Terminals T23, T24. This ground is internally linked to the other control grounds with the exception of T40.

Terminals T23, T24 - Configurable Analogue Outputs

These two analogue outputs may have their formats and sources configured. Formats can be 0 to 10Vdc, -10 to +10Vdc; 5mA max or 0 to 20mA or 4 to 20mA. Configuration is done from Screen Group O. Accuracy: $\pm 2\%$; Resolution: 8 bits.

Terminal T25 - Analogue Input 0V Connection

This 0V connection is a suitable return point for the two analogue outputs connected to Terminals T26, T27. This ground is internally linked to the other control grounds with the exception of T40.

Terminals T26, T27 - Analogue Inputs

These inputs are configurable as to their function, also their formats and scaling may be set. Formats can be 0 to 10Vdc, -10 to +10Vdc, 0 to 20mA or 4 to 20mA. Configuration is done from Screen Group I. Accuracy: $\pm 2\%$; Resolution: 10 bits.

Terminals T28, T29 - Potentiometer Supply

A 10mA constant current source provides up to 10Vdc for a 1k Ohm potentiometer.

Terminals T30 - +5Vdc

This terminal is provided for the encoder power supply. Maximum load is 100mA.

Terminals T31 to T34 - Incremental Quadrature Encoder Inputs

The Elite Series is designed to accept input from a standard quadrature encoder designed to operate from +5Vdc to 24Vdc and having single ended open collector outputs, push-pull open collector outputs, or differential logic driver outputs. This encoder is only required if operating in Closed Loop Vector control mode. The encoder type and pulses per revolution may be configured from Screen Group N.

Terminal T35 - Encoder 0V

This terminal is provided for the encoder power supply 0V return. This ground is internally linked to the other control grounds with the exception of T40.

Terminals T36, T37 - User 24Vdc In/out, 0V

These are provided for powering of user controls, encoder power supply or for back feeding a backup power supply to energise the control board in the event of mains failure. This output is fuse protected.

Maximum output current capability: 500mA
 Minimum input current capacity of backup supply: 1A.
 Backup supply voltage: 24Vdc ±10%

Terminals T38 to T42 - RS232 / RS485 Connections

These terminals are provided for serial communications connections, for control, monitoring or configuration from a PC or other remote host. These terminals are optically isolated from the Elite Series potential.

IMPORTANT NOTES REGARDING RELIABILITY OF CONTROL CIRCUITS

Screening

Screening - it is essential that all control inputs and analogue outputs are screened. There are no exceptions if you expect reliability!

Cable Separation

Do not run control signals together with power input or output cables to the motor - space at least 300mm away, and cross at right angles.

Relay Signals

Output relay signals do need to be screened. If power switching, do not include output relay signals in the same screened cable with control signals. Do not overload relays.

Switch Inputs

Switch (multifunction) Input circuits are designed for 24Vdc operation. Do not apply any other voltage.

Earthing of Control 0V

To comply with the requirement of a Class 1 earthing system, the Elite Series control 0V must be linked to earth at some point. Connection of multiple earth points may cause earth loops and should be avoided. An earth link is provided, and must be removed if not required. Removal will allow the 0V point to float up to ±50Vdc (30Vac) from chassis earth.

More comprehensive connection information is given in the Elite Series Getting Started Manual (PDL Part No. 4201-179).




Figure 3.7b: Control Terminals T22-T42

3.2 DESCRIPTION OF THE ELITE SERIES CONTROL SYSTEM

3.2.1 Structure of the Inputs and Outputs

The following descriptions refer to Figure 3.8.

ANALOGUE INPUTS

Two analogue inputs are provided. The format and scaling of these inputs are configurable from the front panel.

The format of each is configurable by Screens I6a, I6d, without links, to be 0 to 10Vdc, -10 to +10Vdc, 0 to 20mA or 4 to 20mA.

Analogue Processing -Screen I6g may be used to introduce a zero baud to the analogue signal. This is used to ease setting of absolute zero values. Scaling determines the percentage (of motor speed or torque) demanded by the minimum and maximum settings. This is done by Screens I6b, I6c, I6e, I6f.

OUTPUTS

Potentiometer Supply - A 11mA constant current source provides 10V to a 1kOhm potentiometer.

Relay Outputs - Each of three relay outputs may be controlled from a large number of sources using Screens O2a, O2c, O2e. Each may be individually inverted. RLY1 is of changeover configuration, RLY2 and RLY3 have normally open contacts.

Analogue Outputs - Each of the two analogue outputs can have its source, format and scaling configured from the

display unit. Each analogue output can have its format configured, with a choice of 0 to 10Vdc (unipolar), -10 to +10Vdc (bipolar), 0 to 20mA or 4 to 20mA using Screens O1a to O1h.

COMPARATOR

Comparator - Two software comparators allow relay outputs to respond to analogue levels. The comparators may be individually selected to any analogue output source. Individual ON and OFF levels may be set. A window function may also be selected. Configuration is by Screens C1 to C6.

SWITCH INPUTS - MULTI-FUNCTION INPUTS

Switch Inputs - Six switch inputs are provided. These inputs set digital levels and are collectively known as Multi-function Inputs (MFI).

The multi-function inputs are factory set from the Display Unit to bias low for active high switching, which is considered to be a "fail-safe" mode. Alternatively the inputs may be set for active low switching using Screen I7b.

The six multi-function inputs perform control functions according to the input mode selected on Screen I7a. When certain modes are selected the function of some (or all) of the inputs may be individually programmed to act as one of a wide range of possible controls, by use of Screens I7c to I7h.

The switch inputs are processed together with keyboard controls (and set point references - multi-references) to provide a number of internal digital controls as well as the control of two analogue reference signals (motorised potentiometer and multi-reference).

3.2.2 Structure of the Motor Control System

Referring to Figure 3.9, **unless the Elite Series is operating in V/Hz mode**, the structure of the Elite Series control system may be considered as a torque controller, (the flux vector control system), the input of which selects either a speed referencing or torque referencing processor. This torque controller may be operated with a shaft encoder mounted on the motor for the best response and low speed operation. Alternatively it may be used without an encoder (Open Loop Mode control mode) for less critical applications.

THE FLUX VECTOR (TORQUE) CONTROLLER

Unlike conventional AC motor speed controllers, the Elite Series is primarily a torque control system. The flux vector control method requires complete knowledge of motor parameters, together with feedback of the rotor shaft speed. A high resolution encoder fixed to the motor shaft directly feeds back accurate indication of motor speed. This is scaled according to the pulse per revolution rating of the encoder (typically 2000 ppr) and the motor rated speed. The encoder additionally feeds back speed to the speed control loop, and overspeed protection override.

To ensure accurate operation, all the motor and shaft encoder parameters must be entered using the N screen group. Also vector loop tuning parameters (the X screens) must also be entered. The X screens can most easily be set up by using the autotuning facilities available (Screen X2).

Open Loop mode operation is also available, where a motor shaft encoder is not used. A reduction in performance may be expected when running in this mode. Torque control is not available when operating in Open loop Mode.

The source of the torque demand reference is selected according to the desired (speed or torque) operating mode. The torque reference is subject to overspeed limits set on Screens L2 and L3, and minimum and maximum torque limits set on Screens L4 and L5.

Additionally a special torque limit (L8 MAX REGEN) is provided which controls the maximum level of regenerated power.

TORQUE REFERENCE PROCESSING

The torque set point may be selected from eight possible torque references. Additionally a second alternative reference selection may be made. The chosen torque set point may optionally be inverted. Minimum and maximum torque limits are provided. An optional torque filter completes the processing. The torque set point is then routed to the flux vector controller source selector.

SPEED REFERENCE PROCESSING


The speed set point may be selected from eight possible sources. Additionally a second alternative reference selection may be made. The chosen speed reference may optionally be inverted. At this point the speed set point may be overridden by fixed speed demands such as inch references.

Minimum and maximum speed limits are provided followed by Skip speeds (set by Screens L10 to L12) to allow the user to avoid mechanical resonances. The speed set point is then processed by the acceleration, deceleration and speed filter controls according to various rate (R) screen settings.

As the flux vector controller is a torque control system, the speed control signal cannot be applied directly to the vector controller. Instead it must be applied to a speed feedback loop, the output of which is a torque demand. Thus, the speed set point is finally applied to a PID speed controller. The set point is compared to the actual speed, fed back from the shaft speed encoder. The resulting torque command signal is routed to the flux vector controller source selector.

PROCESS CONTROL

The inclusion of a full three term PID regulator allows the Elite Series to perform process control (e.g., constant pressure pumping etc.). External auto/manual selection is also available to assist during start-up conditions. Refer to Figure 3.10







Figure 3.9: Structure of the Elite Series Motor Control System



4808-070 Rev F

Figure 3.10: Process Control

4 APPLICATION RECOMMENDATIONS

4.1 THE MOTOR

4.1.1 Sizing the Motor and Elite Series

The Elite Series is suitable for controlling all standard three phase induction motors. In sizing the Elite Series, the torque requirements of the load must first be assessed. Under flux vector control conventional induction motors are able to provide at least 200% of rated torque (often 250%). Choose a motor capable of supplying the required torque and a Elite Series capable of supplying the motor's current requirements.

In applications requiring high peak torques, the Elite Series is required to supply current approximately in proportion to the torque. The Elite Series should be chosen according to its short term overload limit of **150%** (30 seconds).

Note: Figure 4.1 is presented as a guide only, refer to Figure 2.1 for the 400V ratings and Figure 2.2 for the exact ratings of the 500V models.




Figure 4.1: Elite Series Thermal Overload Characteristics

In applications operating continuous loads or providing significant torque at low speeds, the motor must be chosen on a basis of continuous dissipation. It may be necessary to oversize, or force cool the motor for applications operating with significant torque at low speeds (Figure 4.2). In such applications the Elite Series should be chosen according to its continuous rating.

For pump and fan applications having a quadratic torque requirement where a high overload margin is not usually required, the Elite Series may be re-rated according to Figure

2.1, if the Elite Series is to be operated in an environment of an ambient temperature not exceeding 40°C.




Figure 4.2: Typical Motor Thermal Derating

4.1.2 Operation Above Motor Rated Speed

The Elite Series can be operated above motor rated speed in V/Hz and closed loop mode only, however the torque that is able to be generated declines (1/f) as there is insufficient voltage to provide correct stator flux. The torque response also reduces significantly in this mode of operation for the same reasons.

Check that the motor is suitable for operation above rated speed. Consult the motor manufacturer.

A popular solution to achieve a wider speed range is to reconfigure the motor for lower voltage operation (e.g., connect a 400Vac star motor as a 230Vac delta, or specially wind the motor). Full performance is achieved at increased speeds (until the supply voltage is reached), at the penalty of increased motor current.

4.1.3 Operation of More Than One Motor

When running the Elite Series in Open or Closed Loop mode, operation of more than one motor from the Elite Series is generally impractical. In certain applications utilising identical motors with identical loads (e.g., load sharing or mechanically locked) connection of more than one motor may be possible.

When running the Elite Series in V/Hz Mode, it is possible to run more than one motor in parallel off one Elite Series. If running parallel motors, the rating of the Elite Series should exceed the sum of the individual motor currents. Each motor will require individual thermal protection. Performance will be reduced.

4.1.4 Thermal Protection of the Motor

The Elite Series maintains a thermal model of the motor as its primary means of detecting overload and providing protection. Nevertheless the use of a temperature protecting PTC embedded in the motor windings provides ultimate protection and is recommended. The thermal model will not

be effective if the Elite Series is running more than one motor.

4.1.5 Large Frame-size Motor Considerations

Large frame-size motors (typically greater than 315 frame) have additional installation requirements when used with AC motor controllers. These motors may exhibit rotor voltage build-up due to parasitic capacitance. Unless protective measures are taken, this voltage may discharge through the anti-friction bearings possibly leading to degradation of the bearing via electrical discharge machining (EDM).

The preferred solution is to fit insulated bearings (or an insulated bearing housing) with a rotor earthing brush. Careful selection of the rotor earthing brush is required, as this brush must provide a low impedance earth for high frequency pulses. Rotor shaft earthing brushes are now commercially available to suit this low voltage, low current application. These brush systems are designed for long life with minimal maintenance. Contact PDL Electronic or its agent for further information on suitable earthing brushes. An alternative solution is available from PDL Electronics in the form of PDL's EDM Filter. The EDM filters out the common mode voltage applied to the motor. Contact PDL Electronics or its agent for further information on the EDM Filter.

4.2 THE ENCODER

4.2.1 Choice of Encoder

If the Elite Series is to be used in Closed Loop Vector control mode, a shaft encoder will need to be connected to the motor. A specification for a suitable encoder for a 50 or 60Hz motor is:

Encoder type:

Incremental, quadrature (bi-phase), differential or single-ended output. Push-pull output preferred to maximise range.

Recommended ppr:

1000 to 2000 ppr per motor pole pair, for directly driven encoder

Minimum ppr:

500 ppr per motor pole pair (4 pole motor = 1000 ppr)

Supply requirement:

5Vdc, 100mA maximum

The shaft encoder should be fitted directly to the motor (using a flexible coupling) or indirectly via a toothed (zero slip) belt drive or similar. There must be zero slip or backlash, and high shaft loads or loose couplings must be avoided.

The encoder **MUST** be connected using shielded twisted cable. The shield should be earthed at the Elite Series end only, to avoid the possibility of earth loops. The maximum cable length is inversely proportional to the required maximum pulse rate. A push-pull output encoder gives a better range than a single ended open collector type, and is recommended for cable runs exceeding 30 metres. If using an open collector type of encoder, when wired with typical shielded cable with capacitance of 200pF/metre, the product of cable length (metres) x max. frequency (kHz) should not exceed 1500.

A differential output encoder has a high common-mode noise rejection capability, thus is **recommended** for electrically noisy environments. The encoder inputs to the Elite Series

will also accept input pulses from an encoder operating off a supply up to 24Vdc.

4.2.2 Connection of the Encoder

The encoder orientation shown in the drawings in this manual (i.e., the connection of the A and B outputs) assumes the encoder is to be connected directly to the non-drive end (non-shaft end) of the motor and that motor wiring orientation is normal (motor terminals U1, V1 and W1 are connected to Elite Series terminals U, V, W, respectively). In this case, an increasing count (Screen Z9) should correspond to rotation in the positive direction (motor shaft rotates clockwise when the motor is viewed from the drive end), in response to a positive speed reference.

If the encoder direction is inverted (e.g., by mounting at the drive end or using an inverting belt coupling), A and B, or for a differential encoder, A and A signals should be swapped. Refer Figure 5.4.

4.3 SWITCHING

4.3.1 Power Switching

Generally it is better practice to leave electronic equipment (including the Elite Series) permanently connected to the mains supply. Switching the mains on and off to control the Elite Series is bad practice and should be avoided (use the control terminals). Mains switching must not occur more often than once every five minutes to avoid overheating the charging circuits.

4.3.2 Motor Switching

Because the Elite Series acts as a variable frequency (including DC) current source :-

WARNING: Motor isolation **MUST NOT BE OPENED** while the Elite Series is running.

Although the Elite Series will not be damaged, standard industrial switchgear (AC1 or AC3) is not designed to operate at or near DC conditions, and there is great danger of damage or fire due to arcing under these conditions.

4.4 TORQUE AND SPEED CONTROL MODES

4.4.1 Torque Control Mode

Unlike conventional AC motor speed controllers, the Elite Series is primarily a torque controlling device. When used in Closed Loop Vector torque mode, a reference torque demand signal sets the output torque level which the Elite Series will try to achieve from the motor. This level may be positive or negative and is quite independent of the motor speed (within speed limits). Web control systems which require constant tension applied to the web, regardless of speed, are a typical torque control application.

While in torque mode, speed limits are used to limit overspeed such as may occur from temporary loss of load (e.g., a web break in the above example). The speed reference signal is disregarded while in torque control mode.

To run in torque control mode, it is necessary to employ Closed Loop Vector control mode and use a shaft encoder on the motor.

4.4.2 Speed Control Mode

In Open Loop or Closed Loop vector mode PID settings are used to adjust the response of the speed control loop. Apart from this, speed control is implemented and settings made in a similar way to conventional AC drives.

A reference speed control signal sets the output speed which the Elite Series will try to achieve at the motor. The direction may be positive or negative, and is independent of load torque (within torque limits).

While in speed control mode, torque limits are used to limit over-torque such as may occur due to process changes or fault conditions.

For best performance in speed control mode, employ Closed Loop Vector control mode and use a shaft encoder on the motor. This gives improved speed regulation, faster dynamic response, and full torque capability at zero speed.

If such high performance is not required, Open Loop Mode or V/Hz control mode may be employed. In these modes a shaft encoder on the motor is not necessary.

4.4.3 Switching Between Torque and Speed Control Modes

When switched, transition from torque control mode to speed control mode and the inverse, is achieved without discontinuity (i.e., smoothly). **Torque Control mode may only be selected** when the Elite Series is used in Closed Loop Vector control mode.

4.5 DYNAMIC BRAKING

Regeneration is achieved through the motor being driven by the load (e.g., lowering crane hoists or rapid deceleration of high inertia loads). While being driven, the motor acts as a generator and energy is transferred back into the DC bus capacitors of the Elite Series. In its standard form the Elite Series can only dissipate this energy as losses and so can only provide limited braking of 5-10%.

Where higher levels of braking are needed, an additional dynamic brake module must be fitted. Dynamic brakes are controlled power switches which are used to dump energy from the DC bus into resistive loads. Generally such brakes and resistors must be sized to suit the requirements of the application according to considerations of both peak and continuous power dissipation requirements. Refer to the supplier for more information regarding specific dynamic brake modules, or to the dynamic brake manual if already supplied.

The Elite Series frame 1 to 2 models have a dynamic brake transistor built into the unit. Simply connect the appropriately sized resistor between the positive DC bus terminal "+" and the dynamic brake resistor terminal "B".

ELITE SERIES	DB RESISTOR MINIMUM (Ohms)	DB RESISTOR POWER RATING (MIN-kW)
ME-2.5	500	1.1
ME-2D	500	1.4
ME-6.5	180	3
ME-6D	180	3.8
ME-10.5	130	4
ME-9D	130	5.3
ME-12	100	5.3
ME-11D	100	6.7
ME-18	50	10.6
ME-16D	50	13.5
ME-22.5	50	10.6
ME-21D	50	13.5

Figure 4.3: Dynamic Brake Resistor Ratings (Typical)

For application advice on resistor sizing and cabling requirements please request assistance from PDL Electronics or its agent.

Dynamic Brake Resistor Wiring

Due to the high voltage switching and the currents involved, special wiring practices must be observed when connecting the dynamic brake resistor.

For the dynamic brake resistor connection a multicore cable with screen is recommended. Alternatively, two separate cables securely tied together at 200mm intervals without gaps between the cables may be used. This minimises the cable inductance. Keep the cable length to a minimum to reduce overall cable inductance.

The resistor bank MUST be of non-inductive construction.

Do observe normal wiring practices of separating control and power cables.

The dynamic brake resistor cable must have sufficient dielectric strength to withstand 1000 Vdc (conductor to conductor rating for multicore cables).

On the Elite Series, set Screen D1 (DB Time Constant) to the time it would take to reach 64% of the resistor's final temperature if continuously energised.

Set Screen D2 (DB Duty) to the average percentage of time that the resistor may be operated for.

5 UNPACKING, INSTALLATION AND CONNECTION

5.1 UNPACKING

Full details on the unpacking procedure are given in the Elite Series Getting Started Manual (Part No. 4201-179). Ensure that all of the listed items are supplied, and that there is no visible damage. The packaging material must be disposed of thoughtfully.

5.2 INSTALLATION

Full details on the installation of the Elite Series are given in the Elite Series Getting Started Manual (Part No. 4201-179).

The Elite Series IP54 models are protected against an environment contaminated to pollution degree 2 (damp or dusty air). The IP20 models should be situated in an environment not exceeding pollution degree 1. The Elite Series can handle an ambient air temperature not exceeding 50°C. However the cleaner and cooler the environment, the longer the lifetime that can be expected from the unit. If used in an ambient temperature not exceeding 40°C, the Elite Series may have its output current re-rated according to Figure 2.1 (125% for Elite frame sizes 1 to 4, 110% for Elite frame sizes 5 to 7) for motor speeds exceeding 25Hz. This is useful for pump and fan applications with quadratic torque requirements.

The Microdrive Elite Series range is designed for wall mounting, either vertical upright, vertical inverted, with back or side to the wall.

The Ultradrive Elite Series frame 4 is designed for wall mounting (vertical upright). Do not invert.

The Ultradrive Elite Series frames 5 to 7 are designed for floor mounting only (vertical upright). Secure using the wall supports for earthquake protection.

The IP20 Elite Series must be protected against electrically conductive (wet or dry) dust (e.g.. carbon, fibre, salt, etc.) and free of spraying water. As with all electronic equipment, the cleaner, cooler and more vibration free environment, the longer and more trouble free will be the life of the Elite Series AC Motor Controller.

If the environment cannot be guaranteed to the pollution degree 1 or less, then the IP20 Elite Series must be mounted inside an IP54 or equivalent enclosure. The enclosure must be such that the interior air temperature does not exceed 50°C while the Elite Series is operating at normal levels.

Frame	380-440V Models (note 1)	440-500V Models (note 2)
1	ME-2.5 to ME-12	ME-2D to ME-11D
2	ME-18 to ME-22.5	ME-16D to ME-21D
3	ME-31 to ME-46	ME-30D to ME-41D
4	UE-60 to UE-140	UE-60D to UE-140D
5	UE-170 to UE-250	UE-170D to UE-250D
6	UE-305 to UE-480	UE-305D to UE-540D
7	UE-575 to UE-660	UE-620D to UE-700D

Note1: Frames 1-4 are also available to suit a 230Vac (-20+10%) supply

Note 2: Frames 1-4 are UL/cUL approved to 480Vac

5.3 MANUFACTURER'S RECOMMENDATIONS

Failure to adhere to the manufacturer's recommendations for installation, environmental conditions and electrical specifications may result in damage to the Elite Series (and/or external equipment) and may void the warranty.

5.4 POWER WIRING CONNECTIONS

Full electrical connection details are given in the Elite Series Getting Started Manual (Part No. 4201-179).

Figure 5.2 provides a summary of required power connections. Note the following requirements:

- The Elite Series is designed for operation from a three phase earthed neutral supply. Input fuses are required. Details of the recommended fuse size are given in Figure 5.3. In all cases, observe all site, local and national wiring and safety regulations.
- Power factor capacitors are not required on the Elite Series input, and must not be connected to the Elite Series output.
- An off load isolation switch or contactor may be fitted to the Elite Series output. **Never** attempt to operate this switch under load. **Never** open a contactor on the output while the Elite Series is running as the Elite Series operates as a current source. Opening the output while running could cause extensive damage or fire in the switchgear.
- The Microdrive Elite Series and Ultradrive Elite frame 4 are fitted with electromagnetic interference (EMI) filtering as standard. External supply side EMI filters are required for the Ultradrive Elite frames 5 to 7. To maximise the effectiveness of these filters, screened cable (minimum - neutral screen, steel conduit; preferred - copper tape and/or mesh) must be used on the Elite Series output. Bond the screen solidly to the Elite Series and motor chassis. Failure to use screened output cables may lead to disruption of other electronic equipment. The output cables should be run separately from the input cables, to reduce the chance of EMI cross-coupling between cables. Refer to Figures 5.5 to 5.7 for screen connection details.
- The Elite Series protects the motor with an electronic overload, so an external overload relay is not necessary. Where multiple motors are attached, separate overload protection must be applied to each motor. The Elite Series or the motor must be isolated before operating on the motor terminals.
- The Elite Series output switching voltage waveform can give rise to high (capacitive) earth leakage currents. Permanent earth connection of the motor and the Elite Series is essential before connection to the supply. Screened cable must be used between the Elite Series output and the motor to reduce the chances of radio frequency interference problems. A suitable cable is three phase neutral screened (minimum), with the screen wired as the earth return. Steel conduit may also be suitable.
- For applications where regeneration is likely to occur, a dynamic brake resistor may be required. The resistor must be positioned where the expected heat

generated by it will not ignite or damage its surroundings.

- 8 The location and order of the power terminals varies from model to model. Refer to the terminals labels before connection. Figure 5.1 provides recommended tightening torques for the power terminals.
- 9 The 400V Elite series, frame sizes 5 to 7, are fitted with AC cooling fans. These fans are phase sequences sensitive. Please ensure the input phases have the correct phase rotation sequence.
- 10 The 500V Elite series, frame sizes 5 to 7, are fitted with UL approved DC cooling fans. These fans are powered from a DC power supply. The AC supply to the fan power supply transformer must be matched to the incoming supply voltage. Ensure that the phase to phase voltage of the incoming supply goes into the correct position on the Fan Supply terminal block. These drives are factory wired for 500V operation.

Mismatching the fan power supply and line voltage can lead to inefficient cooling, or fan damage.

To achieve full IP54 and UL Type 12 ingress protection rating, it is important to pass all external wiring through the gland plate supplied. Glands must be correctly fitted to the cables and the gland plate screws tightened to the recommended torque refer to the Elite Series Getting Started Manual (PDL Part No. 4201-179). Also once connections are made, ensure that the terminal cover is fitted correctly and all screws and locks tightened to the recommended torque.

Model	Torque N.m (lbs.ins)
ME frames 1 to 2	1.7 - 2.3 (15-20)
ME frame 3	10.2 - 12.4(90-110)
UE frame 4	M8 22 - 29 (195-257) M10 43 - 56(381-496)
UE frames 5 to 7	43 - 56(381-496)

Figure 5.1: Elite Series Power Terminal tightening Torque




Figure 5.2: Elite Series Power Connection

5.5 CONTROL WIRING CONNECTIONS

Control wiring should be done using screened cable. The screen is earthed at one end only (at the Elite Series end). For safety reasons, the Elite Series control 0V should be linked to earth at some point. Avoid connection of multiple 0V points to earth as this will cause earth loops.

Note that the control inputs and output are highly configurable, so the desired configuration should be planned and designed before attempting connections.

Communications connections can be made to the RS232 or RS485 ports.

Control wiring connections and recommendations are detailed in the Elite Series Getting Started Manual (Part No. 4201-179).

5.6 SHAFT ENCODER CONNECTIONS

If using the Elite Series in Closed Loop Mode a shaft encoder is required on the motor. Shaft encoder recommendations are detailed in Section 4.2 of this manual. Figure 5.4 details encoder connections. Refer to the Elite Series Getting Started Manual (PDL Part No. 4201-179) for details on achieving correct orientation of encoder and motor wiring.

5.7 FIBRE OPTIC CONNECTION

The fibre optic cable used can be any low cost plastic fibre with 1mm core diameter. The maximum recommended cable length is 50m at 50°C ambient. Note that if the fibre optic cable is located near power cables, the local ambient temperature may exceed 50°C. Signal attenuation increases with temperature thereby decreasing the maximum cable length for reliable communication.

Connection is made by cutting a suitable length using a knife (recommended) or side cutters, inserting through a rubber control cable grommet into the fibre optic port and screwing tight the connector. There is no need to strip back the sleeving of the fibre optic cable.

5.8 DYNAMIC BRAKE DETAILS

The possible need for dynamic braking is discussed in Section 4.5 of this manual. If a dynamic brake is required, the brake resistor must be mounted in a position where the expected heat generated by it will not ignite or damage its surroundings.

5.9 ANCILLARY EQUIPMENT

The Ultradrive Elite frames 5 to 7 has mounting points for small items of ancillary equipment. Do not drill additional holes in the Elite metalwork as swarf (metal filings etc) may short internal components leading to irreparable damage and danger to personnel.

5.10 COMMISSIONING DETAILS

Full information on the commissioning of the Elite Series are given in the Elite Series Getting Started Manual (Part No. 4201-179).




Figure 5.3: Shaft Encoder Connection Details




Figure 5.4: Microdrive Elite Series Cable Configuration




Figure 5.5: Ultradrive Elite Frame 4 Cable Configuration




Figure 5.6: Ultradrive Elite Frame 5 Cable Configuration




Figure 5.7: Ultradrive Elite Frame 6 Cable Configuration




Figure 5.8: Ultradrive Elite Frame 7 Cable Configuration

6 SERVICE AND MAINTENANCE

WARNING: Observe the safety precautions detailed at the beginning of this manual.

6.1 FAULT FINDING

Faults in the Elite Series will fall into one of five major categories:

- Failure of an external control device, e.g., switch or analogue input device.
- Protective fault operation with resulting display message.
- Incorrect settings, set up or adjustment resulting in unsatisfactory performance.
- Encoder failure.
- Electrical failure within the drive.

6.1.1 Electrical Failure

Electrical failure is rare but can occur in the power electronic circuits or in the control circuits. A problem with the power electronics will usually evidence itself as an input fuse failure, and subsequent loss of power to the Elite Series, or as a "Desaturation fault" or "Current Trip fault" which is persistent or can not be reset. Note that the desaturation fault indication also can be caused by wiring faults or load related problems. Often severe electrical faults will cause physical damage which must be checked for and corrected before any attempt is made to restart the Elite Series.

Electrical failure is generally not repairable by the user. Repair is achieved by returning the faulty unit to PDL Electronics or their authorised Service Agent. Before disconnection, try to record commissioning parameters either on paper or by uploading to a PC running PDL Drivecomm for Windows. If, due to the nature of the fault, you cannot power up the unit to do this recording, it may be possible to liven the Control Board by back-feeding with 24Vdc. Refer to the Elite Series Getting Started Manual (4201-179) for instructions.

6.1.2 Protective Fault Operation

The Elite Series is designed to trip when a fault or user programmed trip function is detected. The fault message will be displayed on the LCD display. Refer to Section 6.2 for detailed descriptions.

6.1.3 Encoder Failure

The Elite Series cannot continue to operate in **Closed Loop mode** if the encoder signals are missing or excessively corrupted by noise. Should the signals be lost, the unit will indicate 0% speed. If the Elite Series is operating in speed control and the encoder signal is lost then the output frequency and shaft speed will drop to only a few percent and the unit will typically indicate torque or current limit.

If you cannot run the Elite Series above a certain speed in spite of a high speed reference signal, and torque limit is indicated at this speed, this may indicate that the encoder signals are becoming unreadable by the Control Board. The usual cause of this is excess encoder cable capacitance. This can be overcome by using a screened cable of lower capacitance per metre, using a shorter cable run, or by selecting a complementary output or differential output type shaft encoder. These types of encoder can drive a higher capacitance than a single-ended open collector type.

To check the encoder connection and function use V/Hz control mode (by setting Screen X1) and monitor the encoder Screen Z9.

If the motor speed or torque is erratic; check that the encoder is mounted correctly to the rotor and is not slipping.

6.1.4 Incorrect Set-up or Adjustment

Many problems will stem from an inappropriate configuration or maltuned control parameters.

Ensure the correct input mode and reference source is chosen and that the programmable input selections are appropriate. Note that some input modes are designed to operate in conjunction with other parameters and may be affected by the reference source selection.

In some instances the Elite Series may be unable to follow the prescribed control signals. This will be indicated by the various limit status indications (as seen on the Status Screen). The torque, speed, and regeneration limits (L screens) are user selectable within bounds and must be set to suit the application.

All the screens apart from those which define the motor ratings and vector control parameters (N and X screens) can be returned to the factory default settings using the Initialise User Parameters function in Screen Y2. The level of initialisation can be chosen. Refer to Section 9 of this manual for details. Use this feature if the set-up is unknown.

6.1.5 Poor Vector Control Tuning

If the parameters in the X and N screens are not correctly adjusted the Elite Series may operate erratically. Excessive current draw, vibration and motor noise, and the failure to accelerate indicate possible maladjustment. Generally if **autotuning** has been employed, this problem should not occur. Autotuning can be invoked from Screen X2. Full details on tuning options are given in the Elite Series Getting Started Manual (4201-179).

If when running in Closed Loop Vector control mode, the Elite Series output voltage is very sensitive to load torque and/or the torque reading is in error and does not correspond to the expected current (rated current at rated torque) then parameters X3a and X3c may be incorrect. If the Elite Series operates correctly in torque control mode but is unstable in speed control mode then the speed control parameters X4f, X4g, X4h and X5i may be maltuned.

All the X and N screens can be returned to the factory default settings using the Initialise Motor Parameters function (Screen Y2). Use this feature if the setup is unknown. Reinitialisation will cause a "ZERO PARAM" fault indication which can be reset only after the N nameplate parameters are reprogrammed.

6.1.6 Failure of External Control Device

A problem with the signal processing circuitry may cause erratic and possibly rough operation or cause the Elite Series to fail to respond to control signals. External wiring faults or incorrect setup can also stop the Elite Series responding to control signals in the desired manner. Therefore special provision has been made to simplify the checking of the incoming signals and input circuitry. Refer to Screens Z3 to Z12 for diagnostic information.

6.1.7 Failure of the Display Unit

Should the Elite Series fail to communicate with the Display Unit, the message **NO COMMS** will be displayed. This indicates that the 24Vdc supply to the Display Unit is functioning but invalid (or no) communications has been received by the Display Unit. Check the connection to the Display Unit from the Elite Series unit.

6.2 THE FAULT SCREEN

(See also Status Messages, Screen AA)

6.2.1 Control of the Fault Screen

Fault messages are automatically displayed on the Fault Screen (Screen F).

There is a **fault log** folded as subscreens of the fault screen. This fault log records the previous five faults, with the first screen being the most recent fault. This fault log may be inspected at any time.

When a fault is cleared and the Elite Series is reset, the fault message will be moved to the first of the screens folded behind the fault screen. All existing messages on the fault log will be moved down one screen, with the oldest message being discarded. The fault message on the main fault screen will be replaced by **NO FAULT**.

6.2.2 Fault Messages

Fault conditions, their interpretation and suggested remedies are listed below.

Fault	NO FAULT
Detail	No fault detected
Possible cause	Normal operation
Action	None required
Fault	01 LOW Vdc
Detail	Mains voltage has dropped too low (=LOW V TRIP - Screen S5).
Sense level	Model dependant
Possible cause	Mains interruption, dip.
Action	Check supply conditions. Disable Low Volts Trip (refer detailed description of Screen S7).
Fault	02 HIGH Vdc
Detail	DC bus voltage has risen to a dangerous level
Sense level	750Vdc (400V) 850Vdc (500V)
Possible cause	Very high mains surge. Excessive regeneration from regenerative load or excessive deceleration rate (refer detailed description of Screen R2). Earth fault on motor.
Action	Reduce deceleration rate. Check motor circuit for earth fault. Apply Speed Filter via Screen R7.
Fault	03 HI Vdc T/O
Detail	DC bus voltage has risen to a dangerous level
Sense level	720Vdc for greater than 5 seconds (400V) 820Vdc for greater than 5 seconds (500V)
Possible cause	Mains too high for too long. Earth fault on motor.
Action	Check mains supply voltage. Check motor circuit for earth fault.
Fault	04 SUPPLY FLT
Detail	Input supply phase voltage imbalance
Sense level	40Vac ripple voltage in Elite Series DC bus. Phase imbalance is most sensitive under heavy load conditions. Under light load conditions, the Elite Series will run satisfactorily with only two phases connected.
Possible cause	Loss of phase, fuse, motor phase loss, motor winding fault.
Action	Check supply conditions, check wiring to motor, check motor.

Fault	05 S/W DL FLT
Detail	Incorrect software down loaded.
Possible cause	Data transmission error; incompatible software and hardware revisions.
Action	Down load correct software.
Fault	06 EEPROM FLT
Detail	Nonvolatile memory (EEPROM) is faulty
Possible cause	IC failure
Action	Seek service.
Fault	07 I LIM FLT
Detail	Output current has reached a dangerous level.
Sense level	220% of Elite Series rated current.
Possible cause	Short circuit; wiring fault; circuit fault; motor fault.
Action	Check entire output circuit and motor for wiring or winding faults. Check output circuit contactors or isolators for correct operation.
Fault	08 U+ DESAT 09 V+ DESAT 10 W+ DESAT 11 U- DESAT 12 V- DESAT 13 W- DESAT 14 NEG DESAT
Detail	Automatic protection of the internal power switching semiconductor device has operated.
Possible cause	Short circuit; extreme overcurrent; wiring fault; circuit fault; motor fault; IGBT desaturation; IGBT failure.
Action	Check entire output circuit and motor for wiring or winding faults. If fault persists when output leads are disconnected, replace or service the Elite Series.
Fault	15 ELITE O/L
Detail	The temperature calculated by the Elite Series inverter thermal model has reached a dangerous level.
Sense level	150% of rated Elite Series rated current for 30 seconds at 50° C. Maximum continuous operation possible without trip is 105% of Elite Series rating.
Possible cause	Continuous overload of Elite Series.
Action	Check load requirements.
Fault	16 MOTOR O/L
Detail	The temperature calculated by the thermal model of the motor has reached a dangerous level.
Sense level	110%
Possible cause	Excessive load on motor (current draw too high); motor load exceeds cooling capacity at the operating speed; motor phase loss; motor winding fault; motor thermal model parameters incorrectly set. Refer also to the detailed descriptions of Screens N1 and N6.
Action	Check load and thermal model settings in Screens N1 and N6.

Fault	17 BRAKE O/L	Possible cause	Poor ventilation; obstructed ventilation path, Elite Series heatsink and internal cooling fan failure; local ambient temperature exceeds 50°C.
Detail	The temperature calculated by the thermal model of the dynamic brake resistor has reached a dangerous level.	Action	Check heatsink and internal cooling fans are operating; Check ventilation and thermal conditions. Improve cooling. Seek service.
Sense level	Set by dynamic brake thermal model in Screens D1 and D2.	Fault	25 COMMS TRIP
Possible cause	Excessive regeneration for the resistor specified in Screens D1 and D2. Incorrect values entered.	Detail	Host computer generated trip.
Action	Check values (refer detailed descriptions of Screens D1 and D2). Reduce regeneration via Screen L8. Select a bigger braking resistor. Reduce deceleration rate (Screen R2).	Sense level	–
Note:	Active whether a dynamic brake is connected or not.	Possible cause	Trip generated by the host computer via serial communications.
Fault	18 DATA FLT	Action	No action required.
Detail	Nonvolatile memory (EEPROM) reading error. This fault can only be cleared using Screen Y2 to initialise user and motor settings. Be sure motor is isolated before resetting fault and entering correct data.	Fault	26 COMMS T/O
Sense level	Check sum in memory	Detail	Time since last valid serial communication has exceeded timeout period on Screen H2.
Possible cause	Spurious fault; faulty memory.	Sense level	Set by communications timeout value on Screen H2.
Action	If fault recurs, replace Elite Series.	Possible cause	Serial communications wiring faults; host computer fault; incorrect settings on Screens H1 to H4.
Fault	19 ZERO PARAM	Action	Check complete serial communications system; Check screen settings, Seek Service.
Detail	Zero parameters (N screens) have been detected.	Fault	27 FIBRE T/O
Possible cause	Elite Series has been reinitialised; ex-factory state; error in set up.	Detail	Time since last valid fibre optic input has exceeded timeout period on Screen I8d.
Action	Enter all N values correctly.	Sense level	Set by Fibre T/O value on Screen I8d.
Fault	20 PARAM FLT	Possible cause	Speed or torque reference (Screens I2 to I5) selected from fibre optic port with no fibre optic cable connected; fibre optic cable connected to fibre optic output port instead of input port; fibre optic cable fault.
Detail	Inconsistent set of parameters (N screens, L9 screen) selected.	Action	Check fibre optic cable; Check screen settings; Seek service.
Possible cause	Error in set up; wrong values chosen.	Fault	28 OVERSPEED
Action	Enter consistent set of N values.	Detail	Maximum output speed has been exceeded.
Fault	21 GROUND FLT	Sense level	300% of motor rated frequency; absolute maximum 450Hz.
Detail	Excessive current flow to ground.	Possible cause	Loss of control of the motor while being driven by load; excessive load.
Sense level	Internally set.	Action	Check actual operating conditions to determine cause. Adjust load or set up to eliminate problem.
Possible cause	Motor or cable insulation fault.	Fault	29 TQ LIM T/O
Action	Check motor and cables (isolate from Elite Series first). Refer to Screen L13.	Detail	At torque limit for longer than specified.
Fault	22 EXT/PTC	Sense level	Set by Screen L7.
Detail	External trip device has operated. External motor winding temperature sensor (PTC, thermostat etc.) circuit (Terminal T19) has operated.	Possible cause	Load condition or inappropriate setting of Screen L7; encoder failure.
Sense level	Circuit resistance exceeds 4kOhms.		Additional causes for this fault occurring during Open Loop mode starting are: Insufficient start torque (Screen X4c) Too high an acceleration rate (Screen R1, & R3), and Insufficient start delay (Screen S5).
Possible cause	Operation of external trip device; Motor has become too hot (motor load exceeds cooling capacity at the operating speed); Fault in sensor wiring.	Action	Another possible cause is the motor is overloaded while in Open Loop normal mode.
Action	Check motor temperature and sensor wiring. Check external trip switch (if fitted).		Check load condition or alter Screen L7. For Open Loop mode starting fault adjust any of the three screens mentioned above as follows: Increase start torque (Screen X4c), Decrease acceleration rate (Screen R1), Increase the torque limit (Screen L4 & L5). Increase Rs(Screen X3b)
Fault	23 H/S TEMP	Fault	30 SP LIM T/O
Detail	Elite Series heatsink too hot.	Detail	At speed limit for longer than specified.
Sense level	90°C.	Sense level	Set by Screen L6.
Possible cause	Poor ventilation; obstructed ventilation path, Elite Series cooling fan failure; local ambient temperature exceeds 50°C.		
Action	Check fan is operating; Check ventilation and thermal conditions. Improve cooling. Clean fins with compressed air. Seek service.		
Fault	24 INT TEMP		
Detail	Elite Series internal temperature too hot.		
Sense level	80°C.		

Possible cause	Load condition or inappropriate setting of Screen L6.	Fault Detail	41 STOP T/O The system has not stopped within the time-out set by Screen S11
Action	Check load condition or alter Screen L6.	Possible Cause	Parameters set incorrectly: Stop Timeout (Screen S11), Decel rates (Screen R2, R4, R6), Speed filter (R7). Mal-tuned speed pid in vector systems.
Fault Detail	31 CAL FLT Internal reference voltage levels are incorrect.	Action	Check all parameters. Check Dynamic brake.
Possible cause	Elite Series fault. Seek service.	Fault Detail	43 MAS U+ DES 44 MAS U- DES 45 MAS V+ DES 46 MAS V- DES 47 MAS W+ DES 48 MAS W- DES 49 SLV U+ DES 50 SLV U- DES 51 SLV V+ DES 52 SLV V- DES 53 SLV W+ DES 54 SLV W- DES
Fault Detail	32 S/W T/O Internal timing requirements exceeded.	Possible Cause	Output short circuit, extreme output over current, wiring fault, IGBT Desaturation, IGBT failure.
Possible cause	PDL Vysta® for Windows configuration too complex.	Action	Check entire output circuit and motor for wiring or winding faults. If fault persists when output leads are disconnected, replace or service the Ultradrive Elite.
Action	Simplify configuration.	Fault Detail	55 MAS I FLT The MASTER Ultradrive Elite output current has reached a dangerous level.
Fault Detail	33 LVDC FLT Failure of the low voltage dc power supplies.	Possible Cause	Short circuit, wiring fault, circuit fault, motor fault.
Possible cause	Heatsink cooling fan failure; control PCB failure.	Action	Check entire output circuit and motor for wiring or winding faults. Check output circuit contactors and or isolators for correct operation.
Action	Seek service.	Fault Detail	56 SLV I FLT The SLAVE Ultradrive Elite output current has reached a dangerous level.
Fault Detail	34 VYSTA TRIP Custom configuration developed using PDL Vysta® for Windows has deliberately tripped the Elite Series.	Possible Cause	Short circuit, wiring fault, circuit fault, motor fault.
Possible cause	Refer to custom configuration schematic.	Action	Check entire output circuit and motor for wiring or winding faults. Check output circuit contactors and or isolators for correct operation.
Action	Refer to custom configuration schematic.	Fault Detail	57 DESAT/OCT The SLAVE drive indicates a common desat or over current fault.
Fault Detail	35 NO DISPLAY The Elite Series has detected that the display unit is disconnected or faulty. The Elite Series will trip on this fault only if the display unit is enabled via Screen I1 (I1 LOCAL S/STP= 1,2,3).	Possible Cause	Short circuit, wiring fault, circuit fault, motor fault.
Possible cause	Display removed by personnel; display mounted more than 3m distance from the Elite Series unit; faulty display unit.	Action	Check entire output circuit and motor for wiring or winding faults. Check output circuit contactors and or isolators for correct operation.
Action	Connect display unit and disable keyboard mode using Screen I1 (I1 LOCAL S/STP=0); reduce distance, replace display unit.	Fault Detail	58 CURR IMB The MASTER and SLAVE Ultradrive Elite output current is out of balance.
Fault Detail	36 EPLD TRIP An unrecognised fault has been detected by the control board EPLD.	Sense Level	10% of actual individual Drive output current.
Possible cause	Power supply fault.	Possible Cause	Mismatch of IGBTs, output impedances or input rectifier.
Action	Reset fault; if fault persists, seek service or replace the Elite Series.		
Fault Detail	37 WATCHDOG An unknown fault has reset the Control Board microcontroller.		
Possible cause	Power supply fault., PDL Vysta® for Windows configuration too complex.		
Action	Reset fault; if fault persists, seek service or replace the Elite Series; simplify PDL Vysta® for Windows configuration.		
Fault Detail	38 NO VYSTA PRG User Program not set		
Action	Reload Program via Drivelink software		
Fault Detail	39 FIBRE TRIP The Elite Series has tripped due to a fault being reported via the Fibre Optic Network		
Cause	See other Elite Series connected to the network		
Action	Reset fault on the other Elites		
Fault Detail	40 ILIMIT T/O The hardware current limit has been active for longer than 30 seconds.		
Possible Cause	A partial short circuit in the cabling or motor.		
Action	Check cables and motor for possible short circuit.		

Action	Check entire output circuit including IGBTs output bus work, DC bus fuses and input rectifier.
Fault Detail	59 SLV HS FLT The SLAVE Drive has detected either MASTER or SLAVE drive heatsink is TOO HOT.
Sense Level	80°C.
Possible Cause	Poor ventilation; obstructed ventilation path, Elite Series cooling fan failure; local ambient temperature exceeds 50°C.
Action	Check fan is operating; check ventilation and thermal conditions. Improve cooling. Clean fins with compressed air. Seek service.
Fault Detail	60 SLV DC HI The SLAVE Ultradrive Elite dc bus voltage has risen to a dangerous level.
Sense Level	820Vdc
Possible Cause	DC bus inter-link cable fault.
Action	Check dc bus inter-link.
Fault Detail	61 SLV EPLD The SLAVE Ultradrive Elite internal processing units have faulted.
Possible Cause	Faulty or unprogramed SLAVE drive control board.
Action	Reset all Drive parameters using the INILITILISE ALL VAR at screen Y2; replace SLAVE drive control board.
Fault Detail	62 CONNECT FLT The MASTER and/or SLAVE Ultradrive Elite looming connections are incorrect.
Possible Cause	The fibre optic connections are plugged in incorrectly or not working.
Action	Check all the wiring connections.
Fault Detail	63 SLV WDT An unknown fault has reset the SLAVE drive control board.
Possible Cause	Power supply fault., Software fault.
Action	Reset fault; seek service or replace the SLAVE drive control board.
Fault Detail	64 SLV EEPROM The SLAVE drive control board's nonvolatile memory (EEPROM) is faulty.
Possible Cause	IC failure.
Action	Seek service.
Fault Detail	65 SLV PSU The SLAVE Ultradrive Elite Control board power supply failure.
Possible Cause	Fault IC.
Action	Seek service.
Fault Detail	66 SLV DATA The SLAVE Ultradrive Elite control board's nonvolatile memory (EEPROM) reading error. This fault can only be cleared using Screen Y2 to initialise settings. Isolated motor before resetting fault.
Sense level	Check sum in memory.
Possible Cause	Spurious fault.; faulty memory.
Action	If fault recurs, replace SLAVE paralleling card.
Fault Detail	67 SLV CAL The SLAVE Ultradrive Elite drive select modules are incorrect.
Possible Cause	Incorrect combination of drive select modules are plugged into the SLAVE drive select card.

Action	Check both drive select modules are identical on the SLAVE drive control board.
Fault Detail	68 SLV SW VER SLAVE Ultradrive Elite has incorrect software loaded.
Possible Cause	The SLAVE drive control board data transmission error; incompatible software and hardware revisions.
Action	Download correct software to SLAVE drive control board.
Fault Detail	69 SLV PCBTEM The SLAVE Ultradrive Elite internal temperature is too hot.
Sense level	70°C
Possible Cause	Poor ventilation; obstructed ventilation path; fan failure; local ambient temperature exceeds 50°C.
Action	Check fan is operating; Check ventilation and thermal conditions; Seek service.
Fault Detail	70 DC FUSE FLT Fuse monitoring device has operated. External fuse monitoring circuit on SLAVE Ultradrive Elite Parallel Board T30 has operated.
Sense level	
Possible Cause	One of the monitored fuses has failed and the monitoring switch has opened.
Action	Check for continuity on fuse monitoring circuit, look for open circuit in wiring.
Fault Detail	71 DWM1 TRIP Drive web interface watchdog timer trip
Sense level	Time out set by Driveweb server during configuration
Possible Cause	Ethernet interface link to drive has been lost. Driveweb interface has not been polled within the watchdog time specified.
Action	Check Ethernet interface wiring.
Fault Detail	72 DWMI BLOCKS Driveweb interface is fitted and drive has detected Vysta program blocks are loaded.
Possible Cause	No Vysta blocks are allowed in a drive fitted with a Driveweb interface.
Action	Remove Vysta program from drive (download standard screen list) or remove Driveweb interface.

6.3 USE OF LED INDICATORS

The LED indicators on the Display Unit provide visual indication of the unit's status as follows:

LED ON

Functional indication	Mains power is supplied and stored charge is present.
Actual indication	+24V functioning on the Display Unit.
Implication	Primary and secondary switchmodes functioning.

LED RUN

Functional indication	Elite Series is running.
Actual indication	Output devices enabled.
Implication	Elite Series is functional.

LED OK (Steady)

Functional indication	Elite Series is operating normally.
Actual indication	Elite Series ready to operate.
Implication	No fault is present.

LED OK (Flashing)

Functional indication	Fault trip.
Actual indication	Output disabled.

Implication A fault (Screen F) has tripped the Elite Series.

6.4 FUSE FAILURE

The Elite Series incorporates electronic protection. The few fuses included are for SAFETY back up.

Supply fuses Fitted by customer at point of supply

Possible reason for failure

Wrong fuses; Supply surge; Age or cyclic stress failure; Fault in supply cable to Elite Series; Elite Series failure.

Action Check supply cable; check Elite Series unit. Isolate Elite Series and replace fuses. If OK reconnect Elite Series and re-test. If failure persists replace Elite Series or request service.

+24Vdc User supply fuse (F1)

Fitted beneath the expansion board cover beneath the normal Display Unit position.

Possible reason for failure

Overload of the +24Vdc supply or low voltage supplies derived from +24Vdc. Faulty external equipment connected to the User +24Vdc supply. 230Vac accidentally connected to the +24Vdc input supply.

Action Check external equipment connected to the +24Vdc supply. Replace fuse. If failure persists request service.

Microdrive Elite Series Supply fuses

These fuses must be fitted at the point of input termination to the Elite Series. Refer to Table 5.2 for recommended fuses. These fuses are fitted to limit fault energy let-through to protect cables and upstream switchgear.

Possible reason for failure

Wrong fuses; supply surge; age or cyclic stress failure; fault in supply cable to Elite Series; Elite Series failure.

Action Check input cables and Elite Series for any signs of a fault. Isolate Elite Series and replace with correct fuses. Test. If OK, reconnect Elite Series and re-test. If failure persists replace Elite Series, or request service.

Ultradrive Elite frames 5 to 7

DC bus fuses

These fuses are fitted to limit fault energy and prevent damage to the Power PCB.

Possible reason for failure

Supply surge; age or cyclic stress failure; wrong fuses; fault in output cable to motor; Ultradrive Elite Series failure.

Action Isolate Ultradrive Elite Series. Check output cables; check Ultradrive Elite Series; Unless confident fault found and cured, contact service agent. Replace fuses. Reconnect Ultradrive Elite Series and test. If failure persists replace Ultradrive Elite Series, or request service.

Ultradrive Elite frames 5 to 7

F1/F2 2A 440Vac SMPS DC Bus Fuses

Fitted on Ultradrive Elite frames 5 to 7 DC Fuse PCB to protect the Power PCB and DC bus cable loom to the Power PCB.

Possible reason for failure

Fault in switch mode power supply or loom to Power PCB.

Action Replace fuses. If failure persists, replace Ultradrive Elite Series Power PCB assembly, or request service.

WARNING: These fuses must not be replaced with glass fuses (glass fuses will rupture and cause catastrophic damage). Use only the specified 440Vac 2A ceramic fuse.

Ultradrive Elite frames 5 to 7

10A 440Vac heatsink fan supply fuses

Fitted on the Ultradrive Elite frames 5 to 7 SCR PCB to protect against transient suppression overload; and to protect against heatsink fan failure.

Possible reason for failure

Supply surge; faulty heatsink cooling fan.

Action Replace fuse, check fan operation. If failure persists, replace heatsink cooling fan(s), or request service. Use only the specified 440Vac ceramic fuses.

WARNING: These fuses must not be replaced with glass fuses (glass fuses will rupture and cause catastrophic damage). Use only the specified 440Vac 2A ceramic fuse.

7 THE ELITE SERIES DISPLAY UNIT

7.1 DISPLAY UNIT CONTROLLABILITY

The Display Unit, as described in Section 3.1.4, is shown in Figure 7.1. The degree of control and monitoring available from this display will be as set up at the time of commissioning.

The status (top) line of the display will display the drive status, overload status, output current or torque and speed magnitude and direction, and operation mode (speed or torque control).

Each screen will have a pre-configured attribute, controlling whether it is hidden, read only, or read-write. The attribute will apply only when the Elite Series is in Operation Mode (refer Section 7.3 following). When in Commissioning Mode, all screens will be read-write. Before control adjustment is available from the Display Unit when in Operation Mode, the respective screen must have its attribute set to read-write.




Figure 7.1: The Display Unit

The Display Unit is considered to be the LOCAL controller. Therefore for local control, the START and STOP-RESET are usually enabled via Screen I1 (I1 LOCAL S/STP=3) and the speed reference is usually set to come from the Display Unit Screen A3 (I2 REF S=LOCAL).

The digital inputs are usually disabled by setting to local mode (I7a I/P MODE=00 DISABLED). This is the factory default mode.

7.2 MENU STRUCTURES AND SCREENS

7.2.1 Screen Lists

The Elite Series screen list is comprised of multiple screens. Each individual screen, its function and options are discussed in detail in Section 9 of this manual.

A Screen List may also be a foreign language translation of the default screen list as discussed above. When operating in a specific configuration, the required Screen List may be selected (when in Commissioning Mode) from Screen Y1.

7.2.2 Scrolling, Unfolding and Folding

Each screen list is organised in a hierarchical structure, as shown in Figure 7.2.

Scrolling between main screens is by use of "+" or "-" keys. When the main screen of interest is reached, press then release "*" key. This will unfold any subscreens under the main screen, and pressing the "+" key will scroll to the first

subscreen. Only subscreens that do not have attributes set to "hidden" will be visible.

Scroll down the subscreens by using "+" key. Scroll up using "-" key. When the top subscreen is reached, press "-" key to fold up the subscreens and return to the main screen.




Figure 7.2: Screen Unfolding and Folding

7.2.3 Parameter Conventions

USE OF %

Where possible, all adjustments are normalized to the motor parameters - i.e., they are given as a percentage of a motor rating.

The motor ratings themselves are entered in engineering units (volts, amps, etc.).

USE OF "+" AND "-"

"+" Is used to describe speed or torque in the forward direction of the motor.

"-" Is used to describe speed or torque in the reverse direction of the motor.

According to IEC34-7, the motor rotates forward (clockwise) when:

- viewed from the drive (shaft) end
- and terminals U1, V1, and W1 or U2, V2 and W2 are connected to Elite Series phases U, V, W respectively
- and the Elite Series is operating with "+" speed.

7.2.4 Adjusting a Screen Value

Before a screen value can be changed, the screen on view must have its attribute set to "read-write".

To adjust a numeric parameter, press "*" and "+" to make it more positive. Press "*" and "-" to make it more negative. The new value is stored to nonvolatile memory (EEPROM) on release of "*" key.

To adjust a two-state parameter (e.g., HI/LO, Y/N) use "*" and "+" or "-" to toggle the state of the parameter.

To select from a list, use "*" and "+" or "-" keys to scroll through the choices. Release of "*" key will store the displayed choice to EEPROM.

7.2.5 Off to Modify

For maximum flexibility, most screens can be adjusted while the Elite Series is running.

For reasons of safety, however, certain settings may not be adjusted while running. Attempts to do so will cause the display of the message OFF TO MODIFY.

7.3 OPERATING MODES

7.3.1 Summary of Operating Modes

Operation Mode

This is the normal operating mode of the drive. Each screen will have a pre-configured attribute, controlling whether it is hidden, read only, or read-write. Thus operator access to screens can be controlled.

Commissioning Mode

In this mode, each screen is visible and commissioning parameters may be adjusted, irrespective of the screen's attribute. Some parameters are not adjustable while the drive is started or running.

Access to Commissioning Mode may be controlled by a password.

Menu Set-Up Mode

This mode is accessible when in commissioning mode, and enables the attributes of each screen to be set. The attribute controls access to the screen when in Operation Mode, as follows:

- Hidden:** The screen cannot be viewed or changed.
- Read Only:** The screen can be viewed, but not changed.
- Read-Write:** The screen can be viewed and the parameter changed when in Operation Mode.

7.3.2 Swapping Between OPERATION and COMMISSIONING Modes

Setting to COMMISSIONING mode before a Password has been set:

Scroll to Main Screen Z.
Z COMMISSION=N

Press "*" and "+" or "-". The status line should change to:
Z COMMISSION=Y

All screens will now be visible, and all parameters adjustable.

Selecting COMMISSIONING mode after a Password has been set:

Figure 7.3 illustrates the procedure for swapping between OPERATION and COMMISSIONING modes using a password.

Scroll to Main Screen Z. The display's control (bottom) line will read:

Z COMMISSION=N

Press "*" and "+" or "-". The screen will automatically display:
PASSWORD= ZZZZZ

Now press "*" and "+" or "- until the correct password is reached. Then release the keys.

All screens will now be visible, and all parameters adjustable.




Figure 7.3: Setting Commission Mode after a Password has been set

Selecting OPERATION Mode:

To change from COMMISSIONING Mode to OPERATION Mode, scroll to Screen Group Z.

The display's control line will read:
Z COMMISSION=Y

Use "*" and "+" or "-" to toggle to :
Z COMMISSION = N

Setting a Password for the First Time

Refer to Figure 7.4.

Once set to COMMISSIONING mode as described above, a password may be set up. Unfold Screen Group Z and scroll to Screen Z1. The display will read:

Z1 PASSWRD= OFF.

Press "*" and "+" or "-" to set the required password.




Figure 7.4: Setting a Password for the First Time

What happens if a password is unknown or forgotten?

Once a password has been entered, a special hashing number is displayed on Screen Z when trying to enter COMMISSIONING mode.

The display will read:
Z PASSWORD= ZZZZZ

Take a note of this number and contact a PDL Electronics Applications Engineer, who with suitable authority will be able to pass this code through an algorithm to reconstruct the original password.

7.3.3 MENU SET-UP Mode

Entering MENU SET-UP mode

The drive must be stopped before entering MENU SET-UP Mode.

While in COMMISSIONING mode and displaying the commissioning screen (Screen Z), press “*” for five seconds. The status (top) line of the display will be replaced with the message: MENU SET-UP MODE

Figure 7.5 illustrates the procedure for entering to and exiting MENU SET-UP mode.




Figure 7.5: Entering and Exiting Menu Set-up Mode

Figure 7.6 shows a typical screen display when in MENU SET-UP mode.

M	E	N	U		S	E	T	-	U	P		M	O	D	E
N	1		M	T	R		C	U	R	=		?			

Where ? = R (read only) or W (read-write) or H (hidden or invisible)

Figure 7.6: Typical Screen Display in Menu Set-up Mode

All screens will be unhidden, but the parameter value on each control line will be replaced by R or W or H (for read only/read-write/Hidden). The attribute can be altered by “*” and “+” or “-”.

Exiting MENU SET-UP Mode

This is achieved by pressing “*” for more than five seconds.

Exit also occurs after more than five minutes of inactivity, or on start-up after power-down.

Initialising user parameters in Screen Y2 will return the menu setup to the default configuration.

8 CUSTOMISATION OF CONTROL

8.1 PDL VYSTA® FOR WINDOWS CONFIGURATION SOFTWARE

Customisation of Control

The Elite Series Control Board processor has a number of logic and processing blocks integrated into the firmware. These can be configured to enhance one of the existing default configuration, or for configuring a completely new control system. These blocks include logic gates, counters, timers, analogue signal processors, PID controllers, inputs and outputs.

PDL Vysta® for Windows Editor

Configuration of these processing blocks is done by PDL Vysta® for Windows. PDL Vysta® for Windows is an editing software package which can be installed on a personal computer running Microsoft Windows. Each processing block is represented by an icon.

The icons can be placed on the screen and interconnected as required. Each icon has an associated dialogue box for naming and defining parameters. Each type of icon can be used as many times as required, within the limits of user memory within the Elite Series. The resultant schematic diagram can have comments and text attached, and a title block attached. The schematic can be printed.

Compilation and Decompilation of PDL Vysta® for Windows Schematics

A configuration schematic designed using the PDL Vysta® for Windows editor is compiled into a text-based Netlist. This list stores sufficient information to identify the blocks, their associated names, inputs, outputs, variables, interconnection information, and associated screens. When a file is saved inside the PDL Vysta® for Windows editor, it is saved in Netlist format.

When a saved file is opened, the Netlist is decompiled and icons will be regenerated for display on the screen.

The PDL Vysta® for Windows is available for Microsoft Windows 95/98 and Windows NT. PDL Part No. VYSTA

8.2 CUSTOM SCREEN CONFIGURATION

Screen Editor

The PDL Vysta® for Windows configuration software has a screen editing utility included. This enables a new Screen List to be created and down loaded to the Elite Series.

Creating or Modifying a Screen List

When creating a new Screen List, a dialogue box is presented to name and number the list. Then a Screen Window is presented enabling the hierarchical structure of the Screen List to be designed. Screen groups and subscreens can be inserted, deleted, or edited.

Editing a Screen

When a screen is selected for editing, a dialogue box appears. The screen title, attributes and text may be inserted. When down loaded to the Elite Series, this text will appear in the control line (second line) of the display.

The text can include variables, which can be set up as read only, or modifiable from the front panel of the Elite Series. These variables can be defined as the variable names

assigned when configuring processing blocks, or system names.

8.3 PDL DRIVELINK FOR WINDOWS SOFTWARE PACKAGE

The DRIVELINK software package allows Vysta for Windows configuration to be downloaded to the Elite Series drives. It also allows the system code within the Elite to be updated with later revision software as it is developed.

This package is available for Microsoft Windows 95, and Windows NT. PDL Part No. 0407.

8.4 MODBUS COMMUNICATIONS CONNECTIONS BETWEEN PC AND DRIVE

8.4.1 The Elite Series to PC Connection

The Modbus serial communications format is used for data transfer between the Elite Series and a personal computer. The Elite Series is equipped with RS485 and RS232 ports, either of which (but not both) can be used.

For long range communication (more than five metres), or where connection to more than one drive is required, RS485 is the recommended connection. An RS485/RS232 protocol converter will be required, located near to the PC.

For one-to-one communication over a short range and **downloading system code**, the RS232 connection should be satisfactory. It is more noise sensitive than RS485, and can only be connected to a single drive. However direct connection is possible, without the need for a protocol converter.

8.4.2 Configuring the Connection

Each Elite Series unit connected to the serial communications link will require a Modbus Address. Program this address on Screen H3a. This address must be unique to each drive on the same link.

The baud rate must be set on Screen H3b of the Elite Series. This should be set to the maximum (9600 baud). However if regular communications failures are noted, the baud rate may require reducing.

Configure the PDL Drivelink baud rate to match that of the connected drive(s). Configure the serial port to COM 1 if the 9-pin serial connector is available on the PC. If this port is used (e.g., by the mouse), configure the serial port to COM 2 (usually a 25-pin connector on the PC).

8.4.3 Down-loading from a PC to the Elite Series

Once the serial connection is established and configured, a custom control configuration and custom Screen List can be down loaded from the PC to the Elite Series. On transfer, the Netlist files stored in the Elite are converted to Modbus code and transmitted via the configured RS232 port. The Netlist file can then be stored for future reference.

9 THE DEFAULT SCREEN LIST

The Elite Series provides as a default a very flexible set of formats and functions for control inputs and outputs.

The Elite Series can be operated in Open Loop mode as a speed controller, or in Closed Loop mode as a torque or speed controller.

The Screen List available in the default configuration is shown in Figure 9.1.




Figure 9.1a: Screen List A-H




Figure 9.1b: Screen List I-N




Figure 9.1c: Screen List O-P




Figure 9.1d: Screen List R-Z


STATUS LINE

AA	STATUS LINE
Screen AA	OFF 0.0% 0.0% STP t+000% S+000%
Description	STATUS, OVERLOAD, TORQUE/ CURRENT, SPEED, INDICATION
Units	% OF RATED MOTOR TORQUE/AMPS, % OF RATED MOTOR SPEED
Notes	ALWAYS DISPLAYED
FUNCTION	This is the top line of the display and is permanently present. The status line shows Elite Series status, overload condition, output torque or current and output speed. Indication of operational mode is also provided.
SCREEN	OFF 0.0% 0.0% STP () t +000% S +000% 1 2 3 4 5 6
Table Reference	1 2 3 4 5 6
REF.	FUNCTION
1	Elite Series Status Indication Refer to list opposite
2	Overload Status Indicated by a lower case letter while overload is present i - current exceeds Elite Series rating. The Elite Series will shut down to protect itself if the overload persists. m - current exceeds motor capability. The thermal model of the motor indicates the motor will become too hot if this condition persists. The Elite Series will eventually trip if the overload is not eliminated. o - Elite Series and motor overload exists.
3	Torque Mode Indicator T- Elite Series is in C/L vector torque mode t- Elite Series is in C/L vector speed mode l Elite Series is in V/Hz speed mode or O/L mode
4	Motor Torque or Current Indication In C/L vector mode this shows the actual motor torque as a percentage of rated motor torque. In V/Hz or O/L mode the motor current is displayed in amps.
5	Speed Mode Indicator S - Elite Series is in speed mode s - Elite Series is in torque mode
6	Motor Speed Indication Shows actual motor speed as a percentage of rated motor speed

Status Messages

Indication	STP
Message	STOPPED
Notes	Motor stopped.
Indication	SPG
Message	STOPPING
Notes	Motor is stopping.
Indication	RDY
Message	READY
Notes	Elite Series is ready to run. A start command has been received but the bus voltage is too low to run or L14 run at minimum speed is set to NO and setpoint is below minimum speed (L2).
Indication	RUN
Message	RUNNING
Notes	Motor is running.
Indication	INC
Message	INCHING
Notes	Elite Series is responding to an inch command.
Indication	ILT
Message	CURRENT LIMITING
Notes	Elite Series has altered the motor speed to maintain the motor current at or below the current limit setting.
Indication	VLT
Message	VOLTAGE LIMITING
Notes	Elite Series is limiting the deceleration rate to avoid excessive regeneration (Vdc > 720V).
Indication	Fnn
Message	FAULT TRIP
Notes	Elite Series has tripped on a fault. Where "nn" indicates the fault number (refer to Screen F for detail).
Indication	OFF
Message	OUTPUT OFF
Notes	Elite Series has switched off all output power.
Indication	SLT
Message	SPEED LIMITING
Notes	Speed is being limited to value set by Screens L1 or L2.
Indication	TLT
Message	TORQUE LIMITING
Notes	Torque is being limited to value set by Screens L3 or L4 or L8.
Indication	ATU
Message	AUTOTUNING
Notes	Autotune in progress.
Indication	SPN
Message	SPIN STARTING
Notes	Elite Series is searching for the speed of the motor.
Indication	HGT
Message	HEATING
Notes	DC Heat is being applied to the motor.
Indication	LFX
Message	LOW FLUX STATUS
Notes	Open loop vector controller has detected that the motor is close to stalling and has taken compensatory action.

A1 SCREEN GROUP A: STATUS DISPLAYS



A1 A1 LOCAL CONTROL MODE

Screen **LOCAL MODE=SP**
 Description LOCAL KEYBOARD MODE SELECT
 Range SPEED/TORQUE
 Default Value SPEED
 OFF to Modify NO
 Attribute Read Only
 FUNCTION Sets the operating mode of the Elite Series if not otherwise selected (i.e., as a Multi-function input. Refer Screen I7a).
 SETTING UP Select the desired operating (speed or torque) mode.
 Note: The selected mode is indicated on the Status Screen by means of a uppercase "S" (speed mode) or uppercase "T" (torque mode).

A2 A2 LOCAL TORQUE REFERENCE

Screen **LOCAL TQ=+0.0%**
 Description LOCAL TORQUE REFERENCE
 Range -250% to +250%
 Units % OF MOTOR RATED TORQUE
 Default Value 0%
 OFF to Modify NO
 Attribute Read-Write
 FUNCTION Local keyboard control of reference torque.
 SETTING UP The reference torque source (Screen I3 or I5) must be set to LOCAL before this screen has an effect. Although it can be adjusted to ±250% of motor rated torque, the reference torque is constrained between the minimum and maximum torque (set by Screens L4 and L5).

A3 A3 LOCAL SPEED REFERENCE

Screen **LOCAL SP=+100.0%**
 Description LOCAL SPEED REFERENCE
 Range -250% to +250%
 Units % OF MOTOR RATED SYNCHRONOUS SPEED
 Default Value 100%
 OFF to Modify NO
 Attribute Read-Write
 FUNCTION Local keyboard control of reference speed.
 SETTING UP The reference speed source (Screen I2 or I4) must be set to LOCAL before this screen has an effect. Although it can be adjusted to ±250% of motor rated synchronous speed, the reference speed is constrained between the minimum and maximum speeds (set by Screens L2 and L3).

A4 A4 REFERENCE TORQUE, REFERENCE SPEED

Screen **TQ=+100.0% SP=+100%**
 Description TORQUE REFERENCE, SPEED REFERENCE
 Range -250% TO +250%;
 -250 TO +250%
 Units % OF MOTOR RATED TORQUE;
 % OF MOTOR RATED SYNCHRONOUS SPEED
 Attribute Read Only
 FUNCTION Shows reference torque and speed. This screen is displayed after power up or external reset.

A5 A5 MOTOR POWER, MOTOR RPM

Screen **+7.5kW +1480RPM**
 Description MOTOR POWER, MOTOR RPM
 Range -999kW TO +999kW;
 -12000RPM TO +12000RPM
 Units kW - KILOWATTS;
 RPM - REVOLUTIONS PER MINUTE
 Attribute Read Only
 FUNCTION Shows estimated motor power and motor speed in revolutions per minute (RPM). In Open Loop Mode and V/Hz control modes, the speed will be estimated.
 SETTING UP The motor rated kW (Screen N4) and rated RPM (Screen N5) must be entered for correct calibration of this screen.

A6	MOTOR CURRENT, STATOR FREQUENCY
Screen	+16A +50.0Hz
Description	MOTOR CURRENT, FREQUENCY OF AC APPLIED TO STATOR
Units	Amps; HERTZ
Attribute	Read Only
A6a	PHASE OUTPUT CURRENTS
Screen	1.2A 1.2A 1.2A
Description	PHASE OUTPUT CURRENTS
Range	0 to 1999A
Units	Amps
Attribute	Read Only
FUNCTION	This screen displays the individual phase currents of the Elite Series.
A7	MOTOR, INVERTER TEMPERATURES
Screen	Tm=100% Ti=100%
Description	ESTIMATED MOTOR TEMPERATURE; ESTIMATED INVERTER TEMPERATURE
Range	0 TO 150%; 65 TO 150%
Units	% OF RATED MOTOR TEMPERATURE; % RATED INVERTER TEMPERATURE
Attribute	Read Only
FUNCTION	Shows motor temperature as estimated by the motor thermal model, and Elite (inverter) temperature as estimated by the inverter thermal model.
Note:	The inverter thermal model is non-linear, starting at 66%, determined by the 30 second overload rating at 150% of rated inverter current in a 50°C ambient. Refer Section 4.1.1.
A7a	ACTUAL HEATSINK & INTERNAL TEMPS
Screen	Th=23° Ti=26°
Description	HEATSINK TEMPERATURE; INTERNAL TEMPERATURE
Units	°C
Attribute	Read only
FUNCTION	This screen displays the actual measured heatsink and internal temperatures of the Elite.

A8	BUS AND OUTPUT VOLTAGES
Screen	565Vdc 400Vac
Description	DC BUS VOLTAGE ; OUTPUT VOLTAGE
Units	Vdc;Vac
Attribute	Read only
FUNCTION	Shows the internal DC voltage of the Elite Series, and the AC voltage applied to the motor.
Note:	The control system of the Elite Series will attempt to apply whatever voltage is necessary to achieve the calculated current requirement - therefore output voltages displayed with the motor disconnected or isolated may not relate to the voltage applied once the motor is connected.

NO.	SOURCE	UNITS
00	NULL	minimum signal output
01	FULL SCALE	maximum signal output
02	OUTPUT CURR	% of motor rated current
03	OUTPUT VOLTS	% of motor rated voltage
04	BUS VOLTAGE	% of motor rated voltage x 1.414
05	MOTOR POWER	% of motor rated power
06	MOTOR SPEED	% of motor rated speed
07	MOTOR TORQUE	% of motor rated torque
08	REF SPEED	% of motor rated speed
09	REF TORQUE	% of motor rated torque
10	MOTOR TEMP	% of motor rated temperature
11	INVERTER TEMP	% of inverter rated temperature
12	ANALOG IN 1	%
13	ANALOG IN 2	%
14	ANALOG IN 1+2	%
15	FIBRE IN	%
16	PROCESS REF	%
17	PROCESS FEEDBACK	%
18	PROCESS CONTROL	%

Figure 9.2: Comparator Source Selection

SCREEN GROUP C: LEVEL COMPARATOR

C1

Group Attribute Hidden


C2

C3

C4

C5

C6



Screen **C1 COMP1 SEL =02**
C4 COMP2 SEL =02

Description COMPARATOR SOURCE SELECTION
 Range 00-18, REFER FIGURE 9.2
 Default Value 02 (OUTPUT CURRENT)
 OFF to Modify NO

Screen **C2 1 ON =+100%**
C5 2 ON =+100%

Description COMPARATOR ON SETPOINT
 Units % OF FUNCTION SELECTED
 Range C3, C6 TO +250%
 Default Value 100
 OFF to Modify NO

D1

Screen **C3 1 OFF =+90%**
C6 2 OFF =+90%

Description COMPARATOR OFF SETPOINT
 Range -250% TO C2, C5
 Units % OF FUNCTION SELECTED
 Default Value 90
 OFF to Modify NO


FUNCTION Provides two highly programmable relay output comparator functions. Each comparator may select one of a number of analogue levels. Screens C1 & C4, select from the table Figure 9.2. The level at which the relay should turn ON and turn OFF is programmable (Screens C2, C5 and C3,C6 respectively).

SETTING UP If not required, leave set to default values. Where required, select the appropriate function for the Comparator (Screens C1,C4) and set the desired ON and OFF levels (C2,C5 and C3,C6).
 The output of Comparator is only available to the relay outputs. The desired relay must be configured to connect to the comparator (see Screens O2).
 The output of Comparator 1 and Comparator 2 may be connected to the relay outputs to form a window comparator. Comparator 1 sets the lower switching level and Comparator 2 sets the upper switching level.

Note: If ON/OFF levels are adjusted very closely together any noise in the signal may cause the relays to chatter, significantly reducing their life. Avoid this condition by ensuring a reasonable margin between the ON and OFF levels.

SCREEN GROUP D: DYNAMIC BRAKE CONTROLS

Group Attribute Hidden



Screen **D1 DB TIME= 10s**

Description TIME CONSTANT OF DYNAMIC BRAKE RESISTOR
 Range 0 TO 250 SEC
 Units SEC
 Default Value 10
 OFF to Modify NO

Screen **D2 DB DUTY= OFF**

Description % DUTY RATING OF DYNAMIC BRAKE RESISTOR
 Range OFF, 0 TO 100%,
 Units % OF TIME ON
 Default Value OFF
 OFF to Modify NO

FUNCTION The Elite Series includes thermal model protection for a dynamic brake. To protect the brake resistor the Elite Series will stop (indicating BRAKE O/L) when the calculated use of the resistor exceeds its rating.

The time constant of the brake resistor is the time it would take to reach 64% of its final temperature if continuously energised.

The percentage duty rating represents the average percentage of time the resistor may be operated for (when averaged over periods long in comparison to the time constant).


SETTING UP Leave these screens set at 10s and OFF respectively unless a Elite Series dynamic brake option is fitted (the model is active whether a dynamic brake is fitted or not).

If a dynamic brake option is fitted, these screens **MUST BE CORRECTLY SET** according to the manufacturer's resistor specifications. The dynamic brake thermal model can only protect the resistor if it is correctly set - never consider using larger than specified figures.

Refer to Section 4.5 for dynamic brake resistor selection.

SCREEN GROUP F: FAULT HISTORY SCREENS

Group Attribute Read-Write




Screen	F NO FAULTS
Description	FAULT DISPLAY SCREEN
FUNCTION	Automatic display of fault information. The Elite Series automatically shows this screen in the event of a fault tripping of the drive (unless a key has been pressed in the last 2 seconds). A list of possible faults and suggested causes are given in Section 6 of this manual. In the event of a fault, the Elite Series may be reset by pressing the STOP-RESET button on the display unit, or using an externally configured RESET input.
Screens	F1 NO FAULTS F2 NO FAULTS F3 NO FAULTS F4 NO FAULTS F5 NO FAULTS
Description	FAULT HISTORY LOG
FUNCTION	Display of fault history log. Nested under Screen F is a list of the five most recent faults, in order of their occurrence, with the most recent fault first. This is the fault history log. It is used to retain information for maintenance personnel. After the clearing of the current fault and resetting the Elite Series, the fault just cleared will move to the first position on the fault log. All other logged faults will move down one position. The oldest logged fault message will be lost. The fault history log is retained when the power is removed from the Elite Series.
Screen	F6 CLEAR HIST=N
Description	CLEAR FAULT HISTORY LOG
Range	YES OR NO
Default Value	NO
OFF to Modify	NO
Attribute	Read-Write
FUNCTION	Clears the fault history log.
SETTING UP	Select Yes to clear the fault history log. The screen will automatically be set back to the default No once the fault history log is cleared.

SCREEN GROUP H: SERIAL COMMUNICATION CONTROLS

F

Group Attribute Hidden



Screen	H1 PROTOCOL= M
Description	SELECT SERIAL PROTOCOL TO USE
Range	MODBUS/DEVICENET
Default Value	MODBUS
OFF to Modify	NO
NOTE	DeviceNet operation requires an additional product (EDNI) to be used with the Elite Series.
Screen	H2 COMMS T/O=OFF
Description	SERIAL COMMUNICATIONS TIMEOUT PERIOD
Range	1/5/25/OFF
Units	SEC
Default Value	OFF
OFF to Modify	NO
FUNCTION	The communications timeout period provides the option of tripping the Elite Series (indicating COMMS T/O) if the time since the last valid serial communications data transfer has exceeded the communications timeout period. Serial communications with the Elite Series is available via the RS232 serial communications terminals, RS485 serial communications terminals or serial communication interface. This allows the Elite Series to be controlled by a host computer such as a PLC or computer from a remote location, and enables the down loading of customised application configurations generated by the PDL Vysta® for Windows PC software package. All the controls, parameters and modes available on the Elite Series can be monitored or adjusted by using the serial communications option. For example, the host controller can start and stop the motor, control its speed, monitor the estimated motor temperature, and the status of the drive. In addition, the host controller can monitor a process by accessing unused digital and analogue inputs on the Elite Series.
SETTING UP	When there is no host controller connected, the communications address and baudrate parameters have no effect. However, the communications timeout feature remains active, and, as such, should be set to "OFF". If the Elite Series serial communications feature is required, select the required address, baudrate, parity and timeout period.

H1

H2

H3a SUBGROUP H3: MODBUS COMMUNICATION PARAMETERS

H3b	Screen	H3a COMM ADR=10
	Description	MODBUS SERIAL COMMUNICATIONS ADDRESS
	Range	1-240
	Units	-
H3c	Default Value	10
	OFF to Modify	NO

H4a	Screen	H3b BAUD=9600
	Description	MODBUS SERIAL COMMUNICATIONS BAUDRATE
	Range	1200/2400/4800/9600/OFF
	Units	-

H4b	Default Value	9600
	OFF to Modify	NO
	FUNCTION	Sets the Modbus serial communication Baudrate.

H4c	SETTING UP	The Baudrate selection must match that of the Modbus master who is communicating with the Elite.
------------	------------	--

H4d	Screen	H3c PARITY=EVEN
	Description	MODBUS PARITY SELECTION
	Range	EVEN/ODD/NONE
	Units	-

H4e	Default Value	EVEN
	OFF to Modify	NO
	FUNCTION	Sets the Modbus serial communication parity.

H4f	SETTING UP	The parity selection must match that of the Modbus master which is communicating with the Elite.
------------	------------	--

SUBGROUP H4: DEVICENET COMMUNICATIONS PARAMETERS

These option will be valid if an Elite DeviceNet Interface (EDNI) module has been installed.

Screen	H4a Mac ID=63
Description	Mac Identification number
Range	0 to 63
Default Value	63
OFF to Modify	NO
FUNCTION	Defines the Mac ID for the Elite Series unit.
SETTING UP	Each unit must have a unique Mac ID.

Notes Changes to MAC ID have no effect until EDNI is reset via DeviceNet or the power is cycled.

Screen	H4b BAUD=125kbps
Description	DeviceNet Communication Baud rate
Range	125/250/500
Units	kbps
Default Value	125kbps
OFF to Modify	NO
Notes	Changes to MAC ID have no effect until Baud rate EDNi is reset via DeviceNet or the power is cycled.

Screen	H4c Ass In=70
Description	Assembly Input Instance
Range	50 Basic Overload/Contactor Input (1 byte) 51 Extended Overload/Contactor Input (1 byte) 52 Basic Motor Starter Input (1 byte) 53 Extended Motor Starter 1 Input (1 byte) 54 Extended Motor Starter 2 Input (1 byte) 60 Basic Softstarter Input (1 byte) 61 Extended softstarter Input (1 byte) 70 Basic Speed Control Input (4 bytes) 71 Extended Speed Control Input (4 bytes) 101 PDL Control Input (8 bytes)
Default Value	70
OFF to Modify	NO
SETTING UP	Select the Input Instance that gives the required functionality. Refer to the EDNi Technical Manual (PDL part no. 4201-212) for further detail.

Screen	H4d Ass Out=20
Description	Assembly Output Instance
Range	1 Basic Contactor Output (1 byte) 2 Basic Overload Output (1 byte) 3 Basic Motor Starter Output (1 byte) 4 Extended Contactor Output (1 byte) 5 Extended Motor Starter Output (1 byte) 20 Basic Speed Control Output (4 bytes) 21 Extended Speed Control Output (4 bytes) 100 PDL Control Output (8 bytes)
Default Value	20
OFF to Modify	NO
SETTING UP	Select the Input Instance that gives the required functionality. Refer to the EDNi Technical Manual (PDL part no. 4201-212) for further detail.

Screen	H4e CTRL SRC=00
Description	DEVICENET CONTROL SOURCE
Range	00 DNET DECIDES 01 DNET REF 02 LOCAL REF
Default Value	00
OFF to Modify	NO
FUNCTION	Controls where the Run & Reset commands for the Elite Series came from. Local control selects the normal Elite Series controls (keyboard and multifunction inputs). DNET Ctrl selects the commands to come from the source selected by the "Control from Net" bit in the input instance.


Screen	H4f REF SRC=00
Description	DEVICENET REFERENCE SOURCE
Range	00 DNET DECIDES 01 DNET CTRL 02 LOCAL CONTROL
Default Value	00
OFF to Modify	NO
FUNCTION	Controls where the speed reference for the Elite Series comes from. Local Control selects the normal Elite Series reference. DNET CTRL selects the drives reference to come from DeviceNet and DNET DECIDES allows the Elite Series speed reference to come from the source selected by the "Reference from Net" bit in the input instance.

Screen	H4g Interface Status
Description	DeviceNet Interface Status
Range	Off Line Interface board not responding or network not powered up.
	No Net Power 24Volts missing on DeviceNet network
	Self-Testing Powering up.
	Standby Network power OK but no communications established.
	Operational Network is OK and communication is established.
	R Fault Recoverable network fault has occurred.
	NR Fault Non-recoverable network fault has occurred.

SCREEN GROUP I: INPUTS

Group Attribute Hidden

H4g
I1



4808-077 Rev B

I1 LOCAL START/STOP-RESET CONTROL

Screen	I1 LOCAL S/STP=3
Description	LOCAL START/STOP AND RESET CONTROL
Range	0-3 See Table below
Default Value	3 START/STOP-RST
OFF to Modify	NO
Attribute	READ ONLY
FUNCTION	Enables the display unit's START, STOP and RESET functions.

SETTING UP

	Code	Notes
0	NONE	Display START and STOP/RESET inactive. Allows operation without display.
1	RESET ONLY	Display START and STOP inactive. STOP/RESET key resets faults only.
2	STOP-RESET	Display START inactive. STOP and RESET functions active.
3	START/STOP-RST	Display START, STOP and RESET functions active.

Figure 9.3: Local Start/Stop-Reset Control

12

12, 14 SPEED REFERENCE SOURCES

Screen **12 REF S=LOCAL**
 Description SPEED REFERENCE SOURCE
 Range REFER FIGURE 9.4
 Default Value LOCAL
 OFF to Modify YES

13

Screen **14 AREF S=AIN1**
 Description ALTERNATIVE SPEED REFERENCE SOURCE
 Range REFER FIGURE 9.4
 Default Value AIN1 (ANALOGUE INPUT 1)
 OFF to Modify YES

14

15

FUNCTION Defines which input source is used as the speed reference (12) or alternative speed reference source (14):

CODE	SPEED REFERENCE SOURCE
NULL	NO SOURCE SELECTED
AIN1	ANALOGUE INPUT 1
AIN2	ANALOGUE INPUT 2
AIN1+2	ADDITION OF SCALED ANALOGUE INPUTS 1 + 2
FIBRE	FIBRE OPTIC INPUT
LOCAL	LOCAL SPEED CONTROL (SCREEN A3)
MREF	MULTI-REFERENCE (SCREENS I7a, M1 TO M7)
MTRPOT	MOTORISED POTENTIOMETER (SCREEN I7a)
PROCESS	PROCESS CONTROL OUTPUT

Figure 9.4: Speed Reference Source Selection

Note: The alternative speed reference is a switchable second source option. This function is enabled by selecting alternative reference as a multi-function input, by appropriate selection of Screens I7a and I7c to I7h.

SETTING UP Select the desired (and alternative, if required) speed reference source to suit your requirements.

Note: If the alternative speed reference is to be used, the Digital Input controlling this also selects the alternative torque reference source, so Screen I5 must also be set appropriately.

13, 15 TORQUE REFERENCE SOURCES

Screen **13 REF T=NULL**
 Description TORQUE REFERENCE SOURCE
 Range REFER FIGURE 9.5
 Default Value NULL (NO SOURCE SELECTED)
 OFF to Modify YES

Screen **15 AREF T=NULL**
 Description ALTERNATIVE TORQUE REFERENCE SOURCE
 Range REFER FIGURE 9.5
 Default Value NULL (NO SOURCE SELECTED)
 OFF to Modify YES

FUNCTION Defines which input source is used as the torque reference (13) or alternative torque reference source (15):

CODE	TORQUE REFERENCE SOURCE
NULL	NO SOURCE SELECTED
AIN1	ANALOGUE INPUT 1
AIN2	ANALOGUE INPUT 2
AIN1+2	ADDITION OF SCALED ANALOGUE INPUTS 1 + 2
FIBRE	FIBRE OPTIC INPUT
LOCAL	LOCAL SPEED CONTROL (SCREEN A2)
MREF	MULTI-REFERENCE (SCREENS I7a, M1 TO M7)
MTRPOT	MOTORISED POTENTIOMETER (SCREEN I7a)
PROCESS	PROCESS CONTROL OUTPUT

Figure 9.5: Torque Reference Source Selection

Note: The alternative torque reference is a switchable second source option. This function is enabled by selecting alternative reference as a multi-function input, by appropriate selection of Screens I7a and I7c to I7h.

SETTING UP Select the desired (and alternative, if required) torque reference source to suit your requirements.

Note: If the alternative torque reference is to be used, the Digital Input controlling this also selects the alternative speed reference source, so Screen I4 must also be set appropriately.

SUBGROUP I6: ANALOG INPUTS**I6a - I6f ANALOGUE INPUT FORMATTING AND SCALING CONTROLS**

Screen	I6a AI1=0-10V
Description	ANALOGUE INPUT 1 FORMAT
Range	REFER FIGURE 9.6
Default Value	0-10V
OFF to Modify	YES
Screen	I6b AI1 LO= 0%
Description	ANALOGUE INPUT 1 LOW SETPOINT
Range	-400% TO +400%
Units	%
Default Value	0%
OFF to Modify	NO
Screen	I6c AI1 HI= +100%
Description	ANALOGUE INPUT 1 HIGH SETPOINT
Range	-400% TO +400%
Units	%
Default Value	+100%
OFF to Modify	NO
Screen	I6d AI2=0-10V
Description	ANALOGUE INPUT 2 FORMAT
Range	REFER TABLE BELOW
Default Value	0-10V
OFF to Modify	YES
Screen	I6e AI2 LO=0%
Description	ANALOGUE INPUT 2 LOW SETPOINT
Range	-400% TO +400%
Units	%
Default Value	0%
OFF to Modify	NO
Screen	I6f AI2 HI=+100%
Description	ANALOGUE INPUT 2 HIGH SETPOINT
Range	-400% TO +400%
Units	%
Default Value	+100%
OFF to Modify	NO

CODE	ANALOGUE INPUT FORMAT
0-10V	0 to 10Vdc input
+/-10V	-10 to +10Vdc input
4-20mA	4 to 20 mA input
0-20mA	0 to 20 mA input

Figure 9.6: Analogue Input Format Selection

SCALING	AI1 LO / AI2 LO Sets the reference level when the minimum analogue level is applied to the respective input.
	AI1 HI / AI2 HI Sets the reference level when the maximum analogue level is applied to the respective input. The Elite Series input is interpolated linearly between the selected LO and HI settings.
	LO settings may be greater than HI settings, thus providing inverse control (i.e., increasing the reference input decreases the reference speed, torque or process setpoint).

SETTING UP If it has been determined that one or both analogue inputs are needed as torque or speed reference sources, they must first be selected (Screens I2 to I5).

Determine the required format of these analogue inputs, and set up on Screens I6a, I6d.

Determine the range over which analogue control is desired. Adjust the LO setting (Screens I6b, I6e) to the speed/torque desired at minimum analogue input. Adjust the HI setting (Screens I6c, I6f) to the speed/torque desired at maximum analogue input (+10V/20mA).




Figure 9.7: Analogue Input Scaling and Torque/Speed Limits

I6g ANALOGUE ZERO BAND

Screen **I6g ZERO BAND=N**

Description ZERO BAND OF $\pm 2\%$ FOR ANALOGUE INPUT SOURCES

Range YES/NO

Default Value NO

OFF to Modify NO

FUNCTION To provide a definite zero region for analogue controls, especially for speed control.

This is important in applications where absolute zero speed (or torque) is required in conjunction with analogue control. It overcomes small errors in the reference voltage about the zero reference point.

SETTING UP Not required if analogue reference inputs are not used.

If analogue input references are to be used to command exactly zero speed (or torque) or the motor shaft is to be locked (i.e., mechanical brake) at zero speed, the zero band must be set to YES.

If absolute zero speed (or torque) is not critical, the shaft is not mechanically locked at zero speed or the analogue reference

forms part of a feedback loop, set the zero band to NO.

Note: Zero band is provided since the digital tachometer feedback employed in the Elite Series in Closed Loop Mode control mode is absolute - i.e., it cannot lose counts. Therefore any error in zero speed reference setting, however small, will be integrated over time causing the shaft to rotate.

The zero band function does not apply to the digital speed references (e.g., Local keyboard, fibre optic, or multi-reference select) since such zero settings are absolute.




Figure 9.8: Analogue Input Reference Zero Band

SUBGROUP 17: DIGITAL INPUT

17a - 17h DIGITAL INPUT CONTROLS

17a MULTI-FUNCTION INPUT MODE SELECTION

Screen	I/P MODE=0
Description	MULTI-FUNCTION INPUT MODE SELECTION
Range	0 TO 5, REFER FIGURE 9.9
Default Value	0 - DISABLED
OFF to Modify	YES

DESCRIPTIONS OF MULTI-FUNCTION INPUT MODES

0 Disabled - Disables all multifunction digital inputs. If the Display Unit Start/Stop-Reset is enabled from Screen I1, then the motor may be started and stopped using the Display Unit. Useful for commissioning by keyboard control without interference from external inputs. **The PTC/Ext Trip input is still active in this mode.**

1 Remote (3 Wire) Control - Enables Start/Stop-Reset control from external inputs.

MFI 1 ASTOP-RESET
 MFI 2 START
 MFI 3 STOP-RESET
 MFI 4 INVERT SPEED
 MFI 5 INVERT TORQUE
 MFI 6 SPEED/TORQUE

If the Display Unit Start/Stop-Reset are enabled from Screen I1, then the motor may also be started and stopped using the Display Unit.

2 All Programmable - Each of the six inputs (MFI 1 to MFI 6) can individually be programmed to one of many functions, using Screens I7c to I7h respectively.

3 Multi-reference, 2 Wire - Two of the six inputs (MFI 5, MFI 6) may be used to select from the multi-reference settings (Y, Z; refer to Screens M4 to M7), allowing a selection of four preset references.

The remaining four inputs (MFI 1 to MFI 4) may be individually programmed using Screens I7c to I7f respectively.

4 Multi-reference, 3 Wire - Three of the six inputs (MFI 4 to MFI 6) may be used to select from the multi-reference settings (X, Y, Z; refer to Screens M1 to M7), allowing a selection of zero plus seven preset references.

The remaining three inputs (MFI 1 to MFI 3) may be individually programmed using Screens I7c to I7e respectively.

5 Motorised Potentiometer - Offers reference control by UP (increase reference) or DOWN (decrease reference) push buttons.

UP (increase reference) (MFI 5) is defined as normally open and may be parallel connected to provide distributed control points. DOWN (decrease reference) (MFI 6) is defined as normally closed and may be series connected to provide distributed control points.

MFI 4 selects which reference is to be adjusted (Speed = Open & Torque = Closed).

The speed reference source (Screen I2 or I4) and/or the torque reference source (Screen I3 or I5) must be set to the motorised potentiometer ("MTRPOT") selection.

MFI 1 to MFI 3 may be individually programmed using Screens I7a to I7e respectively.

Adjustment is possible from minimum to maximum as follows (refer to Screens M4 to M7):

MREF4 - Minimum Speed
 MREF5 - Maximum Speed
 MREF6 - Minimum Torque
 MREF7 - Maximum Torque

By setting the minimum speed or torque to be greater than the maximum setting, reverse control may be implemented.

The adjustment rate is scaled to allow full scale adjustment in ten seconds. On power up, the motorised potentiometer speed reference is set to MREF4 and the motorised potentiometer torque reference is set to MREF6 unless the minimum and maximum values span zero in which case the reference is set to zero.

MULTI-FUNCTION SETTING UP WARNING

I7a

Altering the multi-function input mode of the Elite Series completely reconfigures the logic of operation of the input control terminals. Be very sure that you understand the operating mode that you require, and that any inputs already connected will not cause the unit to automatically start once your mode is selected.

Hints:

Mode 0 is a special "safe" multi-function mode in which all inputs are disabled except for the PTC/Ext Trip Input. In this mode the Elite Series will not respond to external terminal inputs, but it will show the state and operation of the analogue and multifunction inputs on the control status display screens (Screens Z3 to Z12). Before finally selecting your desired operating multifunction mode, use this mode to safely inspect the status and operation of all of your inputs. If the previous setup of the Elite Series is not known - remove the link from the External Trip input (Terminal T19). This will trip the Elite Series and prevent possible instantaneous starting of the motor upon applying power.

The status of the six inputs can be observed on Screen Z7.

Notes:

The multifunction Speed/Torque reference modes can be selected using Screens I2-I5.

INPUT MODES		CONTROL INPUT TERMINAL FUNCTIONS					
NO.	NAME	INPUT 1 T13	INPUT 2 T14	INPUT 3 T15	INPUT 4 T16	INPUT 5 T17	INPUT 6 T18
0	DISABLED	DISABLED	DISABLED	DISABLED	DISABLED	DISABLED	DISABLED
1	3 WIRE	ASTOP-R-ST	START	STP-RST	INV SP	INV TQ	SP/TQ
2	ALL PROG	MFI 1	MFI 2	MFI 3	MFI 4	MFI 5	MFI 6
3	MULTIREF 2 WIRE	MFI 1	MFI 2	MFI 3	MFI 4	Y	Z
4	MULTIREF 3 WIRE	MFI 1	MFI 2	MFI 3	X	Y	Z
5	MOTORIS- ED POT	MFI 1	MFI 2	MFI 3	SP/TQ	UP	DOWN

Figure 9.9: Input Mode Selection

I7b MULTI-FUNCTION INPUT INVERSION

Screen **I7b POLARITY=HI**
 Description MULTI-FUNCTION INPUT LOGICAL INVERSION

I7c Range HI (active high) or LO (active low)
 Default Value HI (active high)
 OFF to Modify YES

I7d FUNCTION The Elite Series has the ability to have its input circuits operated in two modes:
 ACTIVE HIGH (I7b POLARITY= HI)

Pull input high to activate

I7e ACTIVE LOW (I7b POLARITY= LO)
 Pull input low to activate

I7f This screen changes the biasing of the digital input circuits, to bias low when active high is selected, or bias high when active low is selected. It also changes the polarity of the input logic running in the processor.

I7g Note 1: Changing the input polarity allows the user to select the voltage level required to close the input circuits — either 24Vdc (when configured as active high) or 0Vdc (when configured in active low).

I7h Note 2: The setting of this screen is not modified when the Elite Series is initialised from Screen Y2. The default (factory set) mode for this screen is:

ACTIVE HIGH(I7b POLARITY= HI)

Pull input high to activate.

Note 3: The setting of this screen can not be modified unless Screen I7a is set to DISABLED. This is to prevent possible starting upon changing the digital input polarity.

WARNING It is strongly recommended that the Elite Series on any one site should be configured for either ACTIVE HIGH or ACTIVE LOW to minimise the risk of non-fail-safe operation if the Elite Series are exchanged. The mode would probably be set up to correspond to that used by other models of drive used on site.

I7c - I7h MULTI-FUNCTION INPUT SELECTIONS

Screen **I7c MFI 1 SEL=00**

Description MULTI-FUNCTION 1 INPUT SELECTIONS; TERMINAL T13

Range 00 TO 19, REFER FIGURE 9.11

Default Value 00 (UNUSED)

OFF to Modify YES

Screen **I7d MFI 2 SEL=00**

Description MULTI-FUNCTION 2 INPUT SELECTIONS; TERMINAL T14

Range 00 TO 19, REFER FIGURE 9.11

Default Value 00 (UNUSED)

OFF to Modify YES

Screen **I7e MFI 3 SEL=00**

Description MULTI-FUNCTION 3 INPUT SELECTIONS; TERMINAL T15

Range 00 TO 19, REFER FIGURE 9.11

Default Value 00 (UNUSED)

OFF to Modify YES

Screen **I7f MFI 4 SEL=00**

Description MULTI-FUNCTION 4 INPUT SELECTIONS; TERMINAL T16

Range 00 TO 19, REFER FIGURE 9.11

Default Value 00 (UNUSED)

OFF to Modify YES

Screen **I7g MFI 5 SEL=00**

Description MULTI-FUNCTION 5 INPUT SELECTIONS; TERMINAL T17

Range 00 TO 19, REFER FIGURE 9.11

Default Value 00 (UNUSED)

OFF to Modify YES

Screen **I7h MFI 6 SEL=00**

Description MULTI-FUNCTION 6 INPUT SELECTIONS; TERMINAL T18

Range 00 TO 19, REFER FIGURE 9.11

Default Value 00 (UNUSED)

OFF to Modify YES

FUNCTION Certain input modes are able to be selected from Screen I7a which offer programmable input functions. There are a maximum of six inputs and each may be programmed individually using Screens I7c to I7h. The selection of functions available is shown in table opposite.

SETTING UP Determine which input mode is required (Screen I7a). Program each input, MFI 1 to 6, Screens I7c to I7h, as required.

Be very careful that you have selected the correct functions.

Always check operation under safe conditions before entering the system into service.




Figure 9.10: Active High/Active Low Selection

No.	Input	Inactive State	Action Function/Notes
00	Unused	N/A	Input has no effect
01	Start	Open	Commands start, latching
02	Stop	Closed	Commands stop (Screen S2), latching
03	Alternative Stop-Reset	Closed	Commands alternative stop (Screen S4) while active; latches stop (Screen S2); reset on opening edge
04	Stop-Reset	Closed	Commands stop (Screen S2); latching; reset on opening edge
05	Start/Stop	Open	Commands start when closed; stop when open
06	Stop/Start-Reset	Open	As O5, but provides reset on closing edge
07	Reset	Open	Reset upon closing edge
08	Inch 1	Open	Inches (jumps to speed mode) at setting of MREF1 (Screen M1); Inch is dominant only if "STOP" is closed; Closing Inch 1 and Inch 2 give Inch 3 (MREF3)
09	Inch 2	Open	Inches (jumps to speed mode) at setting of MREF2 (Screen M2); Inch is dominant; Closing Inch 1 and Inch 2 gives Inch 3 (MREF3)
10	Invert Speed	Open	Inverts sign of speed reference
11	Invert Torque	Open	Inverts sign of torque reference
12	Invert Torque-Speed	Open	Inverts sign of both torque and speed references
13	Invert Inch	Open	Inverts sign of inch reference
14	Alternative Acceleration	Open	Toggles selected acceleration and deceleration rates in conjunction with Screen R5 (Accel/Decel break speed)
15	Alternative Reference	Open	Selects alternative reference (Screens I4, I5)
16	Speed/Torque Mode	Open	Switches to torque control mode
17	Remote/Local	Open	Disables writes by Serial Comms and Comms timeout fault
18	Start/Stop-Reset	Open	As O5, but provides rest on opening edge
19	Astop	Closed	As O2, but without reset

Figure 9.11: Multi-function Input Functions (Selectable Functions)

SUBGROUP I8: FIBRE OPTIC INPUT

I8a - I8d FIBRE OPTIC INPUT SCALING CONTROLS

Screen **I8a F LO=-100.0%**
 Description FIBRE INPUT LOW SETPOINT
 Range -400% TO +400%
 Units % OF MOTOR RATED SYNCHRONOUS SPEED OR TORQUE
 Default Value -100%
 OFF to Modify NO
 Attribute HIDDEN

Screen **I8b F HI=+100.0%**
 Description FIBRE INPUT HIGH SETPOINT
 Range -400% TO +400%
 Units % OF MOTOR RATED SYNCHRONOUS SPEED OR TORQUE
 Default Value +100%
 OFF to Modify NO
 Attribute HIDDEN

FUNCTION Defines the scaling of the Fibre Optic input.

Screen **I8c FIBRE MODE=0**
 Description FIBRE OPTIC CONTROL MODE SELECTION
 Range 0-5, REFER TABLE BELOW
 Default Value 0 (No Control)
 OFF to Modify YES
 Attribute HIDDEN
 FUNCTION A master/slave fibre optic network enabling synchronised starting/stopping and fault response of the Elite Series connected via a fibre optic loop. Refer General Application Note 4216-045 for more detail.

SETTING UP Only one Elite Series in the loop should be set to master.

NO	FIBRE MODE	FUNCTION
0	NO CONTROL	No response to the fibre optic control
1	MASTER	Overall control of the network
2	SLAVE	Full slave control
3	SLAVE TRIP	Slave control with Trip/Reset related control only
4	SLAVE RUN	Slave control with run control only
5	SLAVE RUN/STP	Slave control with run control and stop on trip

Figure 9.12: Fibre Optic Control Mode Selection

NOTE: The setting on this screen does not affect the transmission or reception of reference information which is controlled by screens I8a, I8b, and O3a.

Screen **I8d FIB T/O=OFF**
 Description FIBRE OPTIC INPUT TIMEOUT PERIOD
 Range 1s/5s/25s/OFF
 Units Sec
 Default Value OFF
 OFF to Modify YES
 FUNCTION Provides the option of tripping the Elite Series (indicates "F27 FIBRE T/O") if the time since the last valid fibre optic input signal has exceeded the timeout period.

I8a

I8b

I8c


I8d

L2

SCREEN GROUP L: LIMITS

Group Attribute READ

L3



L4

L5

L6

Screen **L2 MIN S=-110%**
 Description MINIMUM SPEED
 Range -250% TO MAXIMUM SPEED SETTING
 Units % OF MOTOR RATED SYNCHRONOUS SPEED

L7

Default Value -110% Frames 1 to 4
 0% Frames 5 to 7
 OFF to Modify NO

L8

Screen **L3 MAX S=+110%**
 Description MAXIMUM SPEED
 Range MINIMUM SPEED SETTING TO +250%
 Units % OF MOTOR RATED SYNCHRONOUS SPEED

Default Value +110%
 OFF to Modify NO

FUNCTION Sets the speed limits within which the Elite Series can be commanded to operate the motor. Commands to operate beyond these limits will be limited to these limits.

Note that a negative reference speed implies motor operation in reverse.

SETTING UP Adjust minimum and maximum speed limits according to your application requirements.

L4, L5 TORQUE LIMITS

Screen **L4 MIN T=-150%**
 Description MINIMUM TORQUE
 Range -250% TO MAXIMUM TORQUE SETTING
 Units % OF RATED MOTOR TORQUE
 Default Value -150%
 OFF to Modify NO

Screen **L5 MAX T=+150%**
 Description MAXIMUM TORQUE
 Range MINIMUM TORQUE SETTING TO +250%
 Units % OF RATED MOTOR TORQUE
 Default Value +150%
 OFF to Modify NO

FUNCTION Sets the torque limits within which the Elite Series can be commanded to operate the motor. Commands to operate beyond these limits (e.g., from torque reference input, or as a result of speed control demands) will be limited to these limits.

SETTING UP Adjust minimum and maximum torque limits according to your application limits.

Note: The motor will draw current in approximate proportion to the torque demanded. Therefore be sure that the Elite Series

connected is able to supply the current necessary to supply the torque required. Do not select minimum or maximum torque which will require the Elite Series to produce more than 150% of its rated output current.

When running in Closed Loop Mode control mode, torque limiting will be indicated if the shaft encoder signals are lost.

L6, L7 TIMEOUT CONTROLS

Screen **L6 SP T/O =INF**
 Description SPEED LIMIT TIMEOUT
 Range 0 TO 25 SEC AND INFINITE
 Units SECONDS
 Default Value INFINITE
 OFF to Modify NO

Screen **L7 TQ T/O =INF**
 Description TORQUE LIMIT TIMEOUT
 Range 0 TO 25 SEC AND INFINITE
 Units SECONDS
 Default Value INFINITE
 OFF to Modify NO

FUNCTION To provide the option of automatically tripping the Elite Series if the speed or torque limits are encountered for a period of time between 0 and 25 seconds.

SETTING UP The Elite Series will automatically limit speed or torque (Screens L2 - L5) if required. In some processes this is normal and may occur continuously, in which case these screens should be set to never timeout - i.e., Set to infinite.

In other processes, such activity indicates loss of process control which may be tolerated for a brief period of time, or may call for immediate tripping of the process. In such cases these screens may be set to the appropriate time.

Torque limit timeout control also protects against shaft encoder signal loss when running in Closed Loop Mode mode.

Zero settings equate in action to instantaneous speed or torque shear-pin functions.

Note: The Torque limit timeout is also used for Current limit timeout.

L8 REGENERATION LIMIT

Screen **L8 REGEN= 150%**
 Description REGENERATION LIMIT
 Range 0 TO 250%
 Units % OF MOTOR POWER
 Default Value 150
 OFF to Modify NO

FUNCTION When the sign of the load torque and motor speed are different the motor acts as generator (e.g., when decelerating high inertia loads).

This function automatically limits the torque applied (by controlling motor speed) to control the amount of regenerated power. The object of this is to keep the regenerated power within the system's capabilities

(whether relying on natural losses or using a dynamic brake).

In utilising this function the optimum braking performances can be achieved without danger of loss of control due to regeneration beyond the system's ability to dispose of it.

SETTING UP If the application does not involve regeneration, this screen need not be adjusted. When relying on natural losses to dissipate regenerated power adjust this level to the estimated loss level (typically 5 to 10 percent) and confirm correct (i.e., trip free) operation by experiment.

When utilising a dynamic brake, set this screen to the appropriate (short or long term) power limit level according to the application requirement and brake dissipation capability.

L9 CURRENT LIMIT CONTROLS

Screen L9 I LIMIT = 16A
Description CURRENT LIMIT
Range 0.25/1.50 times Elite Series nominal rating
Default 1.2 times Elite Series nominal rating
OFF to Modify NO
FUNCTION To maintain load current within controllable bounds (status = ILT). Torque limit timeout (L7) provides a setable maximum time of active current limit, beyond which the Elite Series will automatically trip (Fault status = TQ LIM T/O)

If the torque limit timeout period is set at zero, the current limit function effectively acts as a "SHEARPIN", providing rapid over-torque protection.

In Open Loop mode, the current limit is restricted to 125% of the drive current rating even if the value entered is higher. This is to preserve the integrity of the current waveshape, which is important for Open Loop mode control.

SETTING UP Current limit: Where not strictly part of the required setup for the particular application leave this set at 1.2 x Elite Series nominal rated current (refer Figure 2.1). If there is a particular requirement for this function (e.g., for torque limiting or to ensure the motor cannot approach the overload setting and thus will not trip out) set the current limit to the desired value.

Hints: For normal operation, avoid choosing values much below the motor's rated current as various effects (starting torque settings, rapid acceleration or deceleration) can lead to confusing results.

In a well set up application current limit should never be required. Current limit acts to override incorrect Elite Series setup or load problems. If current limit action is observed during normal operation of the Elite Series or process, check that the setup is correct - particularly check acceleration, deceleration, motor parameters and boost settings.

L10, L11, L12 SKIP SPEEDS

Screen L10 SKIP 1 =+0.0%
Description SKIP SPEED 1
Range -250% to +250%
Default 0%
OFF to Modify No

Screen L11 SKIP 2 =+0.0%
Description SKIP SPEED 2
Range -250% to +250%
Default 0%
OFF to Modify No

Screen L12 SKIP BW=0.0%
Description SKIP BANDWIDTH
Range 0% TO 20%
Default 0%
OFF to Modify NO

FUNCTION To provide two zones of reference speeds that cannot be set. The object is to provide "keep out" area of operation which may be selected so that natural mechanical system resonances can be avoided. Skip speeds 1 and 2 define the middle of each skip zone. The skip bandwidth defines the width of the zones.

SETTING UP Complete other commissioning first. Determine points, and breadths of any (two) mechanical resonances in your system. Enter skip speeds and desired bandwidth. To turn off skip speeds set SK BW to 0.0%. Check operation and readjust as necessary.





Figure 9.13: Skip Speeds

L13

L13 GROUND CURRENT LIMIT

Screen **L13 GND ILT=12A**
 Description **GROUND CURRENT LIMIT**
 Range OFF/0.1 to 9999A
 Units Amps/Phase
 Default 30% of Inverter rated current per phase
 FUNCTION To set the limit of ground current that is acceptable.

L14

L14 RUN AT MINIMUM SPEED

Screen **L14 MIN SP RUN=Y**
 Description **RUN MINIMUM SPEED**
 Range YES/NO
 Default YES
 FUNCTION If set to NO then the Elite Series will change to the READY state if the reference speed is reduced to below the minimum speed while running.

M1

M2

M3

M4


M5

M6

M7

SCREEN GROUP M: MULTI-REFERENCE SETPOINTS

Group Attribute HIDDEN



- Screens **M1 MREF1=+0.00%**
M2 MREF2=+0.00%
M3 MREF3=+0.00%
M4 MREF4=+0.00%
M5 MREF5=+0.00%
M6 MREF6=+0.00%
M7 MREF7=+0.00%

Description **MULTI-REFERENCE SETPOINTS**
 Range **-250% TO +250%**
 Units **% OF RATED MOTOR SPEED OR TORQUE**
 Default Value **0.00%**
 OFF to Modify **NO**
 FUNCTION These are reference setpoints into which user values can be loaded.

SCREEN	TITLE	SPECIAL FUNCTIONS
M1	MREF1	INCH1
M2	MREF2	INCH2
M3	MREF3	INCH3
M4	MREF4	MOTORPOT MIN SPEED
M5	MREF5	MOTORPOT MAX SPEED
M6	MREF6	MOTORPOT MIN TORQUE
M7	MREF7	MOTORPOT MAX TORQUE

Figure 9.14: Special Functions using Multi-Reference Setpoints

Note: Figure 9.14 shows special functions that can be assigned to the multi-reference setpoints using either the motorised Pot input mode or all programmable input mode with multi-function input selection in Screens I7c to I7h.

SCREEN	TITLE	MULTI-REFERENCE FUNCTIONS		
		MF14 (T16) X	MF15 (T17) Y	MF16 (T18) Z
M4	MREF4	X	O	O
M5	MREF5	X	O	X
M6	MREF6	X	X	O
M7	MREF7	X	X	X

Figure 9.15: Multi-Reference 2 Wire Functions

Note: Figure 9.15 shows special functions assigned to Multi-reference setpoints M4-M7 when using Input Mode O3 (MRef 2W). Multireference setpoints M1-M3 are available as in Figure 9.14.

SCREEN	TITLE	MULTI-REFERENCE FUNCTIONS		
		MF14 (T16) X	MF15 (T17) Y	MF16 (T18) Z
	ZERO	O	O	O
M1	MREF1	O	O	X
M2	MREF2	O	X	O
M3	MREF3	O	X	X
M4	MREF4	X	O	O
M5	MREF5	X	O	X
M6	MREF6	X	X	O
M7	MREF7	X	X	X

O= Open X = Closed


Figure 9.16: Function of Multi - Reference 3 Wire

Note: Figure 9.16 shows special functions assigned to multi-reference setpoints M1-M7 when using Input Mode O4 (MRef 3W).

SETTING UP Adjustment is only necessary when a function requiring multi-references is selected.

Determine the speed or torque reference level needed for each state and enter this value.

SCREEN GROUP N: MOTOR NAMEPLATE DATA



Screen **N1 MTR CUR=0.0A**
 Description RATED (NAMEPLATE) MOTOR CURRENT
 Valid Range 20% TO 150% OF ELITE SERIES SIZE
 Units AMPS
 Default Value 75%(Dependant on Elite Series model)
 OFF to Modify NO

Screen **N2 MTR VOLT=0V**
 Description RATED (NAMEPLATE) MOTOR VOLTAGE
 Valid Range 0 TO 999V
 Units VOLTS
 Default Value 400
 OFF to Modify NO

Screen **N3 MTR FRQ=0Hz**
 Description RATED (NAMEPLATE) MOTOR FREQUENCY
 Valid Range 25 TO 400Hz
 Units HERTZ
 Default Value 50
 OFF to Modify NO

Screen **N4 MTR P=0.0kW**
 Description RATED (NAMEPLATE) MOTOR POWER
 Valid Range 0 TO 650kW,
 50% TO 150% OF ELITE RATED kW
 Units KILOWATTS
 Default Value Dependant on Elite Series model
 OFF to Modify NO

Screen **N5 MTR RPM=0**
 Description RATED (NAMEPLATE) MOTOR SPEED
 Valid Range 200 TO 24000 RPM
 Units REVOLUTIONS PER MINUTE
 Default Value Dependant on Elite Series model
 OFF to Modify NO

Screen **N6 MTR COOL=40%**
 Description MOTOR COOLING AT ZERO SPEED
 Range 20 to 100%, OFF
 Units PERCENTAGE OF COOLING AT RATED SPEED
 Default Value 40%
 OFF to Modify NO

FUNCTION Calibrates the Elite Series for the motor being driven. Provides information for the thermal model motor protection.

The Elite Series must be correctly sized to control the motor being driven. The motor should be between 50% and 150% of the Elite Series rated power (kW) and the motor must have between two and twelve poles.

If the motor nameplate power is listed in horsepower(hp) then convert to kilowatts(kw) by using the following formula:

N8

$$kw = \frac{hpx746}{1000}$$

The thermal model includes correction for the reduced efficiency of standard motor cooling at reduced speed by interpolating between the zero speed cooling term (Screen N6) and rated cooling at rated speed (refer Figure 4.2). The thermal model is reset when power is removed from the Elite Series.

SETTING UP These parameters must be set before operating the Elite Series. Invalid combinations of values will be detected as "Parameter Fault" error, tripping the Elite Series.

Enter motor rated (nameplate) parameters - current, voltage, frequency, power and speed (rpm). Where the nameplate includes multiple options or the configuration (star/delta) of the windings has been altered, be sure to enter the correct data for your configuration.

Estimate the efficiency of cooling of your motor at zero speed and enter this figure. (This is very application dependent - as a guide, 40% is typical. Where open frame, force cooled or water cooled motors are used, higher zero speed cooling efficiency will be achieved.) If extended operation at low speed leads to tripping due to the motor thermal model, check the motor. If it is clearly not very hot, the zero speed cooling figure may be safely increased. The motor thermal model may be disabled by setting the motor cooling parameter to OFF.

Independent external thermal protection should then be applied to the motor.

N8 ENCODER SENSOR CALIBRATION

Screen **N8 ENCODER=0**

Description PULSES PER REVOLUTION OF TACHO ENCODER

Range 0 TO 8191 PPR

Default Value 0

OFF to Modify NO

FUNCTION To operate the Elite Series in Closed Loop vector mode, feedback of motor shaft position is required. The Elite Series is designed to accept input from an incremental shaft encoder. This parameter calibrates the Elite Series to the number of pulses per motorshaft revolution generated by the encoder.

SETTING UP Enter the encoder's number of pulses per motor shaft revolution. Any gearing between the motor and encoder must be taken into account.

Notes: See also Section 4.2.

Full details on selection, mounting and checking of the shaft encoder are detailed in the Elite Series Getting Started Manual (PDL Part No. 4201-179).

N9 ENCODER INPUT TYPE SELECTION

Screen **N9 ENC I/P=DIFF**

Description SELECTION OF TYPE OF ENCODER

Range SING (single ended) or DIFF (differential)

Default Value DIFF


OFF to Modify YES

FUNCTION The input circuit on the Control Board can be configured to accept either style of shaft encoder. Differential type is recommended for its superior noise-rejection capabilities.

Full details on selection, mounting and checking of the shaft encoder are detailed in the Elite Series Getting Started Manual (PDL Part No. 4201-179).

SCREEN GROUP O: OUTPUTS

Group Attribute HIDDEN



SUBGROUP O1: ANALOGUE OUTPUTS

O1a, O1e ANALOGUE OUTPUTS SOURCE SELECTION

Screens	O1a AO1 O/P=06 O1e AO2 O/P=02
Description	ANALOGUE OUTPUT SOURCE SELECTION
Range	00 TO 19 - REFER TO FIGURE 9.17
Default Value	AO1 O/P= 06 (MOTOR SPEED) AO2 O/P= 02 (OUTPUT CURRENT)
OFF to Modify	YES
FUNCTION	Provides the ability to select the driving source for each of the two analogue outputs, from the following list:

NO.	SOURCE	UNITS
00	NULL	minimum signal output
01	FULL SCALE	maximum signal output
02	OUTPUT CURR	% of motor rated current
03	OUTPUT VOLTS	% of motor rated voltage
04	BUS VOLTAGE	% of motor rated voltage x 1.414
05	MOTOR POWER	% of motor rated power
06	MOTOR SPEED	% of motor rated speed
07	MOTOR TORQUE	% of motor rated torque
08	REF SPEED	% of motor rated speed
09	REF TORQUE	% of motor rated torque
10	MOTOR TEMP	% of motor rated temperature
11	INVERTER TEMP	% of inverter rated temperature
12	ANALOG IN 1	%
13	ANALOG IN 2	%
14	ANALOG IN 1+2	%
15	FIBRE IN	%
16	PROCESS REF	%
17	PROCESS FEEDBACK	%
18	PROCESS ERROR	%
19	VISTA CONTROL	%

Figure 9.17: Analogue & Fibre Outputs Source Selection

SETTING UP Select the desired analogue signal source for each of the two analogue outputs.

Select the format of each output using Screens O1b, O1f. Adjust the scaling using Screens O1c and O1d for Analogue Output 1, and O1g and O1h for Analogue Output 2.

O1b

O1b-O1d, O1f-O1h
ANALOGUE OUTPUT FORMATTING AND SCALING CONTROLS

O1c

Screen **O1b AO1=+/-10V**
 Description ANALOGUE OUTPUT 1 FORMAT
 Range REFER FIGURE 9.18
 Default Value +/-10V
 OFF to Modify YES

O1d

Screen **O1c AO1 LO=-100%**
 Description ANALOGUE OUTPUT 1 LOW SETPOINT
 Range -250% TO +250%

O1e

Units %
 Default Value -100%
 OFF to Modify NO

O1f

Screen **O1d AO1 HI=+100%**
 Description ANALOGUE OUTPUT 1 HIGH SETPOINT
 Range -250% TO +250%

O1g

Units %
 Default Value +100%
 OFF to Modify NO

O1h

Screen **O1f AO 2=+/-10V**
 Description ANALOGUE OUTPUT 2 FORMAT
 Range REFER FIGURE 9.18
 Default Value +/-10V
 OFF to Modify YES

Screen **O1g AO2 LO= -100%**
 Description ANALOGUE OUTPUT 2 LOW SETPOINT
 Range -250% TO +250%

Units %
 Default Value -100%
 OFF to Modify NO
 Screen **O1h AO2 HI=+100%**
 Description ANALOGUE OUTPUT 2 HIGH SETPOINT
 Range -250% TO +250%

CODE	ANALOGUE OUTPUT FORMAT
0-10V	0 to 10Vdc, input> 1 kohms
+/-10V	-10 to +10Vdc, input>1 kohms
4-20mA	4 to 20 mA, input<500 ohms
0-20mA	0 to 20 mA, input< 500 ohms

Figure 9.18: Analogue Output Format Selection

FUNCTION Provides the ability to change each of the two analogue outputs to one of the four formats listed in Figure 9.16.

SCALING AO1 LO / AO2 LO
 Maps the AO1 LO / AO2 LO level to the minimum output signal level for the selected output format.

AO1 HI / AO2 HI
 Maps the AO1 HI / AO2 HI level to the maximum output signal level for the selected output format. The Elite Series analogue outputs are interpolated linearly between the selected LO and HI settings.

LO settings may be greater than HI settings,

thus providing inverse control (i.e., increasing the analogue output source level decreases the analogue output signal level).


SETTING UP No action is required if no devices are connected to these terminals.

Determine the required format of these analogue outputs to suit the external devices being driven by their respective output terminals, and set up on Screens O1b, O1f.

Determine the range over which analogue control is desired.

Adjust the LO setting (Screens O1c, O1g) to the desired minimum analogue output signal (-10V/0V/4mA/0mA).

Adjust the HI setting (Screens O1d, O1h) to the desired maximum analogue output signal (+10V/20mA).



4808-055 Rev. A

Figure 9.19: Analogue Output Scaling

Each analogue output may be tested by selecting its source to be FULL SCALE (Screens O1a, O1e to Selection 01).

EXAMPLE 1 Analogue Output 1 (AO1) is formatted as a ±10V output and is used to drive an analogue meter to represent motor speed for a 1440 rpm motor across the range -3000 rpm to +3000 rpm;

Set the source via Screen O1a to:
 O1a AO1 O/P=06 (actual motor speed)

Set the format via Screen O1b to:
 O1b AO1=+/-10V (-10Vdc to +10Vdc)

Set the scaling via Screens O1c and O1d to:
 O1c AO1 LO= -200%
 O1d AO1 HI=+200%
 of rated synchronous speed of 1500 rpm.

With this setup, Analogue Output 1 (AO1) would output -4.8Vdc when the motor was rotating in the reverse direction at 1440 rpm.

$$\left(\frac{\text{actual motorspeed}}{\text{ratedsynchronousspeed}}\right) \cdot \frac{10V}{200\%/100\%} = -4.8V$$

where actual motor speed = -1440rpm and rated synchronous speed = 1500rpm

EXAMPLE 2 Analogue Output 2 (AO2) is formatted as a 4-20mA output and is used to drive into a 4-20mA PLC analogue input to represent motor current for a 20A motor across the range 0A to 50A;

Set the source via Screen O1e to:
 O1e AO2 O/P=02 (actual motor current)

Set the format via Screen O1f to:
 O1f AO2=4-20mA

Set the scaling via Screens O1g and O1h to:
 O1g AO2 LO=0.0%
 O1h AO2 HI=+250%

With this setup, Analogue Output 2 (AO2) would source 10.4mA when the motor was drawing 20A.

SUBGROUP O2: DIGITAL O/P RELAYS

O2a,O2c,O2e RELAY SELECTIONS

Screens **O2a RELAY1=02**
O2c RELAY2=05
O2e RELAY3=08

Description RELAY CONTROL SOURCE SELECTION
 Range 00 TO 23, REFER FIGURE 9.20
 Default Value RLY1 = 02 (No faults)
 RLY2 = 05 (Overload fault)
 RLY3 = 08 (Run)

OFF to Modify NO

FUNCTION Provides the ability to link each relay to one of the outputs shown in Figure 9.20.

All relays have a 250ms minimum pulse width.

SETTING UP No action required if relays are not to be used.

Select the desired source for each relay. If necessary, set up associated level setting screens (i.e., comparators C1 to C6).

O2b, O2d, O2f RELAY INVERSION

Screens **O2b RELAY1 INV=N**
O2d RELAY2 INV=N
O2f RELAY3 INV=N

Description INVERT THE LOGIC OF THE OUTPUT RELAY

Range Y/N
 Default Value N
 OFF to Modify NO

FUNCTION Provides the ability to invert the function of each output relay if desired.

SETTING UP No action required unless relays are used and an inverted output is necessary.

Determine desired logic inversion and select as necessary.

Note: RLY1 has both normally open contacts (T1/T2) and normally closed contacts (T2/T3).

RLY2 has normally open contacts (T4/T5).

RLY3 has normally open contacts (T6/T7).

NO.	DISPLAY	ENERGISED STATE	DESCRIPTION
00	ALWAYS OFF	N/A	Can be used to manually force this state.
01	ALWAYS ON	Drive Powered	Indicates supply present at drive
02	NO FAULTS	No Fault	No faults present: failsafe
03	DRIVE FAULT	No Fault	Drive related fault or low supply; failsafe
04	SUPPLY FAULT	No Fault	Supply phase fault or low supply; failsafe
05	O/L FAULT	No Fault	Motor or Drive Overload Trip; failsafe
06	O/L WARNING	No Warning	Motor or Drive predictive overload; failsafe warning
07	START	Started	Drive has responded to a START command
08	RUN	Running	Drive inverter is active (running)
09	ZERO SPEED	Standstill	Motor at standstill (+/-1% of its rated speed)
10	AT SET SPEED	At Set Speed	Motor at set speed (+/-1% of set speed)
11	TORQUE SIGN	Negative (-)	Sign of direction of motor torque
12	SPEED SIGN	Reverse (-)	Sign of direction of motor speed
13	TQ REF SIGN	Negative (-)	Sign of direction of reference torque
14	SP REF SIGN	Reverse (-)	Sign of direction of reference speed
15	SPEED LIMIT	At Limit	Drive is operating at either speed limit (Screens L2, L3)
16	TORQUE LIMIT	At Limit	Drive is operating at either torque limit (Screens L4, L5)
17	VOLTAGE LIMIT	Voltage Limiting	Drive is operating at voltage limit
18	CURRENT LIMIT	Current Limiting	Drive is operating at current limit
19	COMPARATOR 1	Above ON Level	De-energises below OFF level (Screens C2, C3)
20	COMPARATOR 2	Above ON Level	De-energises below OFF level (Screens C5, C6)
21	WINDOW COMP	Inside Window	Comparator 1 ON and Comparator 2 OFF
22	BRAKE RELEASE	Release	See Brake Release
23	VYSTA CONTROL		Controlled by Vysta program

Figure 9.20: Relay Table Selection

Brake Release:

This function can be used to release a mechanical brake on the motor. The output is activated after the current is first applied to the motor and deactivated one second before the end of the off delay period (Refer Screen S6).

O3a

SUBGROUP O3: FIBRE OUTPUT

O3a FIBRE OUTPUT SOURCE SELECT

Screen **FIBRE O/P=06**

Description FIBRE OUTPUT SOURCE SELECTION

Range 00 TO 19 - REFER TO FIGURE 9.17.

Default Value 06 (MOTOR SPEED)

OFF to Modify NO


FUNCTION Provides the ability to select the driving source for Fibre Optic output.

P1

SETTING UP Select the desired Fibre signal source.

SCREEN GROUP P: PROCESS CONTROL

Group Attribute Hidden



Introduction The Elite Series process controller is a fully featured PID regulator. The setpoint and feedback sources may be selected from a wide choice of options. If selected the PID output is routed at the reference source to provide a speed or torque reference source (Refer Screens I2,I4, I3, I5). Refer to Technical Application Note 4216-048 for more detail about using the process controller.

Tuning The process controller may be tuned using manual Ziegler-Nichols techniques or by starting with the default values:

Increase the Controller Gain (Screen P3) until oscillation first occurs; then set to approximately 40% this setting.

Decrease the Integration Time (Screen P4) until oscillation occurs; then set back to approximately 150% this setting.

Increase the Differential Time (Screen P5) until minimal overshoot has been achieved but oscillation has not occurred. Typically the Differential Time would not exceed 25% of the Integration Time.

P1 PROCESS CONTROL SETPOINT SOURCE

Screen **P1 PR SRC=NULL**

Description PROCESS CONTROL SETPOINT SOURCE

Range REFER FIGURE 9.21

Default Value NULL

OFF to Modify YES

FUNCTION Defines which input source is used as the setpoint source for process control:

CODE	PROCESS CONTROL SETPOINT SOURCE
NULL	NO SOURCE SELECTED
AIN1	ANALOGUE INPUT 1
AIN2	ANALOGUE INPUT 2
AIN 1+2	ADDITION OF SCALED ANALOGUE INPUTS 1 + 2
FIBRE	FIBRE OPTIC INPUT
LOCAL	LOCAL SETPOINT CONTROL (SCREEN A3)
MREF	MULTI-REFERENCE (SCREENS I7a, M1 TO M7)
MTRPOT	MOTORISED POTENTIOMETER (SCREEN I7a, M1 TO M7)

Figure 9.21: Process Control Setpoint Source

SETTING UP Select the desired process control setpoint source to suit your requirements. Refer Figure 3.10.

P2 PROCESS CONTROL FEEDBACK SOURCE

Screen **P2 FB SRC=NULL**
 Description PROCESS CONTROL FEEDBACK SOURCE
 Range REFER FIGURE 9.22
 Default Value NULL
 OFF to Modify YES
 FUNCTION Defines which input source is used as the feedback source for process control:

CODE	PROCESS CONTROL FEEDBACK SOURCE
NULL	NO SOURCE SELECTED
AIN1	ANALOGUE INPUT 1
AIN2	ANALOGUE INPUT 2
AIN 1+2	ADDITION OF SCALED ANALOGUE INPUTS 1 + 2
FIBRE	FIBRE OPTIC INPUT

Figure 9.22: Process Control Feedback Source

SETTING UP Select the desired process control feedback source to suit your requirements. Refer Figure 3.10.

P3, P4, P5 PROCESS CONTROL PID SETTINGS

Screen **P3 Kc=0.1**
 Description CONTROLLER GAIN (Kc)
 Range 0.1 TO 10.0
 Default Value 0.1
 OFF to Modify NO
 FUNCTION Defines the controller gain (Kc) of the process controller.

SETTING UP Select the desired controller gain to suit your requirements.

Screen **P4 Ti=INF**
 Description INTEGRATION TIME (Ti)
 Range 1s TO 1000s, INF
 Default Value INF
 OFF to Modify NO
 FUNCTION Defines the integration time of the process controller.

SETTING UP Select the desired integration time to suit your requirements.

Anti-windup protection limits the process controller integrator.

Setting the integration time too small leads to faster error correction but the possibility of overshoot or instability.

Note: The process controller has a sampling period (Ts) of 100ms.

Screen **P5 Td=0.0s**
 Description DIFFERENTIATION TIME (Td)
 Range 0.0s TO 250s
 Default Value 0.0s
 OFF to Modify NO
 FUNCTION Defines the differentiation time of the process controller.

SETTING UP Select the desired differentiation time to suit your requirements. Typically left at the default value of 0.0s for pump and HEVAC applications.

Screen **P6 ERROR=+0.0%**
 Description PROCESS ERROR
 Default Value 0.0%

FUNCTION Displays the difference between the process setpoint (Screen P1) and the process feedback (Screen P2).

Screen **P7 INVERT PID=N**
 Description INVERT PID
 Default Value N
 Range YES/NO

FUNCTION Setting this screen to Y inverts the output of the PID.

When set to N, the PID response to a drop in the feedback signal is to increase the output speed. This is typically the response required when using the PID for constant pressure control. A drop in pressure (feedback) due to a higher demand will require the pump speed to increase to maintain the pressure.


When set to Y, the PID response to a drop in the feedback signal is to decrease the output speed. This is typically the response required when using the PID for temperature control. A decrease in temperature (feedback) due to a lower demand will require the cooling fan speed to decrease to maintain the temperature.

SCREEN GROUP R: ACCEL/DECEL RATES

R1

Group Attribute HIDDEN

R2



R3

R4

R1, R2 ACCELERATION AND DECELERATION RATES

Screen **R1 ACC=10.0%/s**
Description ACCELERATION RATE

R5

Screen **R2 DEC=10.0%/s**
Description DECELERATION RATE
Range 0.02 to 1300%/SEC
Units % OF MOTOR RATED SYNCHRONOUS SPEED PER SECOND

Default Value 10%/s
OFF to Modify NO

FUNCTION Controls the rates of change of speed (acceleration or deceleration) of the Elite Series.

SETTING UP These rates should be set according to suitability to a process. In high performance applications it may be desirable to calculate the maximum rates with respect to torque capability of the drive system and motor/load inertia. In some cases it may be desirable to adjust the rate to a very high level and rely on the automatic torque limit function - this will give the fastest response.

Generally, use the slowest settings acceptable for your application. An acceleration rate which is too fast may cause the drive to overload (status ILT) and automatically override your setting with a slower one. A deceleration rate which is too fast can cause the motor to regenerate (status VLT) into the drive and automatically override your setting with a slower one.

Being realistic with these settings generally leads to a more successful commissioning. Where fast accelerations/decelerations are called for, it is often best to use slower settings initially, until all other operations are proven.

Freewheel to stop (instead of controlled deceleration) can be achieved by setting the Stop mode (Screens S2, S4) to spin or OFF.

Regeneration limit may be used to automatically provide maximum deceleration rate for the given losses of a system as an alternative to fixed deceleration. See Screen L8.

EXAMPLE For a 4 pole 50Hz motor with rated synchronous speed of 1500rpm; setting 5%/s acceleration rate would accelerate the motor from 0% speed (standstill) to 100% speed (1500rpm) in 20s.

Note: Remember when using extended (long) deceleration rates, adjust the Stop Timeout (Screen S11) appropriately.

R3, R4, R5 ALTERNATIVE ACCELERATION RATES

Screen **R3 AACC=10%/s**
Description ALTERNATIVE ACCELERATION RATE
Range 0.02 to 1300%/SEC
Units % OF MOTOR RATED SYNCHRONOUS SPEED PER SECOND

Default Value 10.0%/s Frames 1 to 3
5%/s Frame 4
2%/s Frames 5 to 7
OFF to Modify NO

Screen **R4 ADEC=10%/s**
Description ALTERNATIVE DECELERATION RATE
Range 0.02 to 1300%/SEC
Units % OF MOTOR RATED SYNCHRONOUS SPEED PER SECOND

Default Value 10.0%/s Frames 1 to 3
5%/s Frame 4
2%/s Frames 5 to 7
OFF to Modify NO

Screen **R5 BRK SP=OFF**
Description BREAK SPEED FOR ALTERNATIVE ACCEL/DECEL
Range OFF, 0.1 TO 250%
Units % OF MOTOR RATED SYNCHRONOUS SPEED

Default Value OFF
OFF to Modify NO

FUNCTION These alternative acceleration and deceleration settings are provided to offer the ability to achieve alternative rates. They may be accessed in two ways:

i) Access by break point -

Screen R5 is used to select a break speed **below** which the alternative rates are active.

ii) Access by utilising alternative acceleration rate multi-function control -

A multi-function input (Option 14, Screens I7c to I7h) via Screen I7a. The acceleration/ deceleration rates which are not currently in use (as controlled by Screen R5) are chosen when the input is active (closed).

SETTING UP Program the desired control (multi-function input selection or break point) as desired. Set the alternative rates to the desired levels.

The break speed for alternative accel/dec (Screen R5) defaults to zero, effectively disabling the alternative rates for normal use.




Figure 9.23: Dual Acceleration/Deceleration Rates

Note: Remember when using extended (long) deceleration rates, adjust the Stop Timeout (Screen S11) appropriately.

R6 STOP DECELERATION RATE

Screen **R6 STOPR=1300%/s**
 Description DECELERATION (STOPPING) RATE USED WHEN STOPPING
 Range 0.02 to 1300%/SEC
 Units % OF RATED MOTOR SYNCNCHRONOUS SPEED PER SECOND
 Default Value 1300
 OFF to Modify NO
 Attribute HIDDEN

FUNCTION When the Elite Series receives a "stop-rate" command (see Screens S2, S4) this deceleration rate is used.

This provides the ability to separately program running accel/decel rates (e.g., to suit a control system) and a different stop-rate (e.g., to provide a very fast stop for safety reasons).

This function overrides normal and alternative deceleration rates.

SETTING UP If this function is desired, set to the appropriate deceleration rate. Set desired stop mode screen (Screen S2, S4) to STOPR.

R7 SPEED FILTER TIME CONSTANT

Screen **R7 SP FILT=0.0s**
 Description SPEED S-CURVE FILTER TIME CONSTANT (used to "soften" acceleration and deceleration)
 Range 0 to 60s
 Units seconds for 100%/s change in acceleration and deceleration
 Default Value 0.0s/100%/s Frames 1 to 3
 1.0s/100%/s Frame 4
 2.0s/100%/s Frames 5 to 7
 OFF to Modify NO
 Attribute HIDDEN

FUNCTION Provide "S-CURVE" filtering to changes in speed reference, including STOP and START commands. The S Curve filter limits the changes of acceleration and deceleration. It is often used to "soften" acceleration and deceleration, especially in hoists and elevators.

Also useful for improving deceleration under high inertia.

Active only in speed control mode. Not active during Stop Rate stop.

SETTING UP Leave set at the default value if not required. Setting at a value other than 0 will affect the unit's ability to follow a speed profile. Increase this value to improve deceleration under voltage limits.

R8 TORQUE FILTER TIME CONSTANT

Screen **R8 TQ FLT=0.00s**
 Description TORQUE FILTER TIME CONSTANT
 Range 0 to 10.0 SEC
 Units SECONDS
 Default Value 0.0 SEC
 OFF to Modify NO
 Attribute HIDDEN

FUNCTION Provides low-pass filtering to changes in torque reference, including STOP and START commands. This controls the rate of change of output torque.

It is often used to "soften" changes in torque. It is especially useful when changing the sign of the torque. If there is any backlash in the mechanical system it can soften the taking up of the backlash.

Active only in torque control modes.

SETTING UP Adjust if the shock due to sudden changes in commanded torque exhibit undesirable effects in the mechanical system. If the time constant is set to one second, the response to a 100% torque reference step change will be a 63% change in the reference torque after one second.


R6

R7

R8

S1 SCREEN GROUP S: START AND STOP MODES

Group Attribute HIDDEN



S5 S1 START MODE

Screen **S1 START=NORMAL**
 Range NORMAL/SPIN
 Default NORMAL
 OFF to Modify NO

FUNCTION In V/Hz operation this screen provides the option of a special starting mode for motor loads which may be spinning when started (e.g., freewheeling fans).

Problems can occur if a spinning load is started conventionally (i.e., Elite Series turns on at zero hertz, before accelerating to the set speed) as the load must first be stalled to near zero speed, before being accelerated.

When spin start is selected, the Elite Series starts at the maximum frequency, instead of zero hertz. If the set speed does not match the spinning speed of the load, an over current situation arises, causing the Elite Series to operate in current limit and reduce its output frequency until the frequency matches the speed of the the load. Once the frequencies match, the current will be reduced and the load will be accelerated normally toward the set point.

Note: When spin starting from the maximum frequency, the direction is set to the same as the reference speed. When the reference speed is 0.0, the spin start will be in the positive direction.

SETTING UP If the Elite Series will not normally be require to start spinning loads or is operating in Closed Loop Vector Mode, set the starting mode to (normal) ramp acceleration.

If starting into spinning loads is a specific requirement of your application, set the starting mode to SPIN. During a spin start, while the Elite is trying to match the output frequency with the motor speed, the output current will be controlled independently of the motor current limit (Screen L9) and the Torque limit timeout (Screen L7). For most reliable starting, set the torque limit timeout to above 0.0s to prevent "Shearpin" tripping once the Elite matches the motor speed.

For reliable low speed spin starting, the Start Torque (Screen X4c) must be set correctly. Set the screen using Normal start.

S2 STOP MODE

Screen **S2 STOP=NORMAL**
 Description USUAL STOPPING MODE
 Range NORMAL/RAMP/SPIN/STOP-RATE/OFF/DC-BRAKE
 Default Value NORMAL
 OFF to Modify NO
 FUNCTION Select the stopping mode to use (see figure 9.24).

SETTING UP Be sure to understand the function which the process needs. Usually the default [Normal] setting will be appropriate. Select other modes to suit the application.

S4 ALTERNATIVE STOP MODE

Screen **S4 ASTOP=NORMAL**
 Description ALTERNATIVE STOPPING MODE
 Range NORMAL/RAMP/SPIN/STOP-RATE/OFF/DC-BRAKE
 Default Value NORMAL
 OFF to Modify NO

FUNCTION Select the stopping mode to use (see figure 9.22).
 The alternative stop mode is used if the MFI input function Alternative Stop-Reset is activated.

SETTING UP Be sure to understand the function which the process needs. Usually the default [Normal] setting will be appropriate. Select other modes to suit the application.

S5 START DELAY TIME

Screen **S5 STR DLY=0.00s**
 Description START DELAY TIME
 Range 0 to 5 SEC
 Units SECONDS
 Default Value 0.00s
 OFF to Modify NO

FUNCTION Sets a period of time following the receipt of a START command before accelerating the motor.

Operates in speed control only. It is intended to provide time for slow release functions to operate (particularly hoist brakes in cranes) before accelerating the motor.

SETTING UP Leave set to zero (default) unless the application specifically requires such a delay. If required, set the appropriate delay.

S6 OFF DELAY TIME

Screen **S6 OFF DLY T=1.0s**
 Description OFF DELAY TIME
 Range 0 to 3600 SEC
 Units SECONDS
 Default Value 1s
 OFF to Modify NO

FUNCTION Sets the period of time that the Elite Series maintains the magnetising flux in the motor after coming to zero speed when stopping. It is desirable to maintain the flux if the motor is expected to restart without a delay (the

reason for this is that when starting from the "OFF" state, flux must first be built up before attempting to accelerate the motor or provide torque. This may take several hundred milliseconds, and such a delay may be undesirable in some situations). The delay may also be used in applications to maintain control of the motor at zero speed, until the brake is applied, before turning the motor off.

SETTING UP Leave set to the default setting unless the application requires a special value. Set to the appropriate time according to your process.

MODE	V/Hz and Open Loop	Closed Loop Vector Speed Mode	Closed Loop Vector Torque Mode
NORMAL	Applies a zero speed reference and decelerate to zero speed		Applies a zero torque reference and coasts to zero speed
RAMP	Same as NORMAL		Transitions to speed control and performs a normal speed controlled stop - i.e., decelerates to zero speed
SPIN	Turns outputs off for the off delay time then changes to OFF state	Transitions to torque control and performs a normal torque controlled stop (i.e., coasts to zero speed)	Same as NORMAL
STOP-RATE	Same as NORMAL except the special stop deceleration rate (Screen R6) is used		Transitions to speed control and performs a speed controlled stop using the special stop deceleration rate (Screen R6)
OFF	Immediately disables the output - i.e., coasts to zero speed		Immediately disables the output - i.e., coasts to zero speed
DC BRAKE	Applies a DC current as set by screen S8 until the end of the OFF delay time		Applies a DC current as set by Screen S8 until the end of the OFF delay time

4202-171 REV E

Figure 9.24: Stopping Modes




Figure 9.25: Start and Off Delay Times

S6

S7

S7 MAINS POWER LOSS RESPONSE

Screen **LOW V TRIP=N**
 Description MAINS POWER LOSS RESPONSE
 Options [Y]ES / [N]O
 Default Value [N]O
 OFF to Modify NO
 FUNCTION The high voltage (mains supply) power loss function provides an optional response to a power loss situation.

Upon power loss or brown out conditions, the Elite Series continues to operate normally until the energy supplied to the motor load discharges the inverter high voltage DC bus to its minimum working voltage. At this stage the output power from the inverter is disabled to prevent further energy consumption by the load, but otherwise the Elite Series continues to operate from the remaining energy in the DC bus. The minimum voltage for the Elite Series is 250Vdc, for the frames 5 to 7 the minimum is 385Vdc. Depending on the size of the Elite Series (and hence the energy in its DC bus), the control board can stay active for several seconds during such an event. While in this state (before the DC bus discharges below the switch mode power supply minimum operating voltage) the Elite Series is able to restart and continue normal operation when the mains supply returns to normal.


If the high voltage (mains supply) power loss function is set to not trip (N), the Elite Series will stay active as long as there is sufficient DC supply (perhaps several seconds). If the mains returns to normal while the control board is still active, the Elite Series will restart

S8	automatically.
S9	If the high voltage (mains supply) power loss function is set to trip (Y), the Elite Series will trip and register a mains low fault after a two second power loss and require resetting. If the mains returns to normal within two seconds, the Elite Series will restart automatically.
S10	SETTING UP The decision of whether to trip or not is usually based upon questions of the safety of automatically restarting equipment after brief power outages, the ability of associated equipment to continue normal operation and the reliability required of a process. If required, the Elite Series control board may be powered with a 24Vdc supply. Connection information is given in the Elite Series Getting Started Manual (PDL Part No. 4201-179)
S11	
S8	DC BRAKE CURRENT LEVEL
Screen	BRAKE I=0%
Range	0 to 150%
Units	PERCENT OF MOTOR RATED CURRENT
Default	0.00%
OFF to Modify	NO
FUNCTION	Sets the level of current to be applied to the motor while DC Braking. This level of current is applied for the OFF DELAY TIME (Screen S6). In Closed Loop Vector Mode, this current is applied while stopping and during the off delay time.
SETTING UP	DC braking is used to stop the motor without regenerating power into the Elite Series. In some circumstances this allows for faster stopping than regenerative braking. It should be noted that during DC braking the energy of the load is dissipated within the motor and the Elite's motor thermal model does not take this into account. Adjust the current level until the desired braking is achieved.
S9	DC HOLDING VOLTAGE IN V/Hz
Screen	HOLD V=0.0%
Range	0 to 25%
Units	PERCENT OF MOTOR RATED VOLTAGE
Default	0.00%
OFF to Modify	NO
FUNCTION	Sets the amount of DC voltage applied to the motor during the off delay period in V/Hz mode. When applied, the DC current causes the motor to resist movement and is used to brake the motor.
SETTING UP	If motor braking after stopping is not required leave set to 0. First set the off delay time to a suitable value (say 2 seconds) and adjust the hold voltage to give the required amount of hold when the motor is stopped (but not off).
Notes	DC hold is only used in V/Hz mode and is not used if the DC-BRAKE stopping mode is selected.

S10	DC HEATING CURRENT
Screen	S10 HEAT I=OFF
Range	OFF/1 to 30%
Units	PERCENT OF MOTOR RATED CURRENT
Default	OFF
OFF to Modify	NO
FUNCTION	Sets the amount of DC current applied to the motor after the off delay period or before a start command is received. This provides standby (anti-condensation) heating to the motor.
SETTING UP	If motor heating is not required leave set to OFF. Anti-condensation heating is normally set to between 10% and 25%.
WARNING:	High voltage will be present on the motor terminals while DC heating is employed.
S11	STOP TIMEOUT
Screen	STP T/O=30s
Range	OFF, 1 TO 3600 SEC
Units	SECONDS
Default Value	30s Frames 1 to 3 60s Frame 4 120s Frames 5 to 7
OFF to Modify	NO
FUNCTION	To provide the safety function of automatically tripping the Elite Series if the motor has not stopped within the selected Stop Timeout period once a stop signal has been received.
SETTING UP	This function is typically used to protect against incorrectly set parameters maltuning the Elite Series and preventing a controlled stop. The controlled stop time is the time to stop under normal conditions and is determined from the maximum speed (Screen L3), deceleration rates (Screens R2, R4, and R6), speed filter time constant (Screen R7), and Off Delay (Screen S6). The Stop Timeout period should be set to a value greater than the controlled stopping time. Alternatively, the controlled stopping time may be measured experimentally and the Stop Timeout set appropriately.
Note:	With a high input supply voltage, the Elite Series has limited headroom in the DC bus to absorb regenerated power from a high inertia motor/load combination. This may prevent the Elite Series from being able to follow the requested speed reference profile. The Stop Timeout may be used to provide protection against loss of control from excessive regeneration. The Stop Timeout is also useful for protecting against incorrectly set speed PID settings in closed loop vector mode.

SCREEN GROUP X: TUNING

Group Attribute HIDDEN



X1 CONTROL TYPE SELECTION

Screen **X1 CTRL TYP=V/Hz**
 Description SELECTION OF OPERATING MODE
 Range O/L = OPEN LOOP MODE
 C/L = CLOSED LOOP VECTOR MODE
 V/Hz = V/Hz
 Default Value V/Hz
 OFF to Modify YES
 FUNCTION This selection determines the type of operating mode for the Elite Series.

V/Hz:

No external feedback is required to operate in the mode. Selection the of control type V/Hz forces the control mode to Speed Control.

Closed Loop Mode:

This control type requires an incremental encoder to be mounted on the motor to provide direct feedback on actual rotor speed. Commissioning and auto-tuning must be completed before selecting this control type. Closed Loop Vector Mode is used where there are high requirements for speed accuracy or torque control is required.

Open Loop Mode:

The Open Loop mode is a speed control mode suitable for frames 1 to 4. This mode of operation can provide improved starting torque and speed accuracy compared to V/Hz mode. No external feedback is required to operate in this mode, which can offer features of the Closed Loop Vector Mode. Commissioning and autotuning must be completed before selecting this control type.

SETTING UP V/Hz mode should be used for initial commissioning to check the operation of any shaft encoder fitted to the motor and to check motor rotation direction.

Once initial commissioning is complete,

select Closed Loop Vector Mode, Open Loop Mode or V/Hz as required.

V/Hz mode **must** also be employed when multiple motors are connected to the Elite Series output.

X2 AUTOTUNE MODE SELECTION

Note: Autotune only applies to Elite Series operated in open loop or closed loop vector mode.

Screen **AUTOTUNE=N**

Description AUTOTUNES MOTOR

Range NO/YES

Default Value None

OFF to Modify YES

FUNCTION The motor must be correctly characterised for good dynamic performance. This can be done automatically by the Elite Series.

Autotuning will automatically set optimum values for the following parameters (without turning the motor):

X3a Lm	Motor Main Inductance
X3b Rs	Stator Resistance
X3c Rr	Rotor Resistance

The motor must be stopped for Autotuning to function correctly.

WARNING: Autotuning applies voltage to the terminals of the motor. Check that all personnel are clear of the motor and attached machinery, and that it is safe to operate the motor.

Note: Manual tuning of the Motor/Drive is required for optimum performance in dynamic applications.

SETTING UP Ensure that LOCAL control is enabled (Screen I7a = 00 DISABLED) before autotuning the motor.

Screen X2 selects AUTOTUNE options, as follows:

X2 AUTOTUNE = NO
Autotuning not active

AUTOTUNE = YES
This tunes the motor without moving the motor.

Autotuning may take from several seconds to several minutes to complete.

Refer to Section 3 of the Elite Series Getting Started Manual, Part No. 4201-179 for details on preliminary commissioning.

X3a	SUBGROUP X3: MOTOR TUNING
X3a-X3d	MOTOR IMPEDANCES
X3b	Note: Only applies to Elite Series operated in open loop or closed loop vector mode.
X3c	<p>Screen X3a Lm=190%</p> <p>Description MAIN INDUCTANCE</p> <p>Range 40 to 800%</p> <p>Units PERCENTAGE OF RATED IMPEDANCE</p> <p>Default Value 190% (Dependant on Elite Series model)</p> <p>OFF to Modify NO</p> <p>X3d FUNCTION The main inductance of the motor defines the magnetising current. This is a key parameter directly affecting motor fluxing.</p> <p>X3e SETTING UP This parameter is self-adjusting and should set itself up under autotuning (Screen X2). Typical values range from 75% (for small motors) to 800% for large motors.</p> <p>The correctness of the setting may be gauged by first ensuring that the Elite Series is operating in full vector control (speed control) mode. Now operate the motor at no load at some defined speed (e.g., 50%) and check that the output voltage matches the percentage speed (i.e., approximately 50% of rated voltage in this case).</p> <p>If the voltage does not match, adjust the main inductance value up (will decrease voltage) or down (will increase voltage).</p> <p>Screen X3b Rs=3.0%</p> <p>Description STATOR RESISTANCE</p> <p>Range 0 to 15.0%</p> <p>Units PERCENTAGE OF RATED IMPEDANCE</p> <p>Default Value 3.0% (Dependant on Elite Series model)</p> <p>OFF to Modify NO</p> <p>FUNCTION The stator resistance represented as a percentage of rated impedance.</p> <p>SETTING UP This parameter is self-adjusting and should set itself up under the autotuning feature (Screen X2). Usually the stator resistance varies approximately between half to twice the rotor resistance (see Screen X3c Rr).</p> <p>In Open Loop mode, care should be taken to set this correctly. The value can be set using Autotune. Alternatively, the per cent rated slip value can be used (See X3c below).</p> <p>Screen X3c Rr=6.00%</p> <p>Description ROTOR RESISTANCE</p> <p>Range 0 to 15.0%</p> <p>Units PERCENTAGE OF RATED IMPEDANCE</p> <p>Default Value 6.0% (Dependant on Elite Series model)</p> <p>OFF to Modify NO</p> <p>FUNCTION Sets rotor resistance of the motor. This is a key parameter directly affecting output torque.</p> <p>SETTING UP This parameter is self-adjusting and should set itself up under autotuning (Screen X2). The parameter should set itself to approximately the rated slip of the motor - i.e.,</p>

$$\text{Slip} = 100 \times \frac{\text{Syncspeed} - \text{Ratedspeed}}{\text{Syncspeed}}\%$$

The setting should change dynamically with changing motor temperature. The accuracy of this setting may be checked by observing output voltage variation during a step load change. If the voltage dips upon a small increase in load, Rr is set too high. If the voltage overshoots, Rr is set too low. If set correctly, the voltage should not change significantly. This setting should be checked when the motor is at its normal operating temperature.

For Open Loop mode, set up as per Closed Loop Vector Mode.

This value will also influence the accuracy of slip compensation (X5d).

X3d	<p>Screen SIGMA=6.0%</p> <p>Description TOTAL LEAKAGE</p> <p>Range 0 to 20%</p> <p>Units PERCENTAGE OF RATED IMPEDANCE</p> <p>Default Value 6.0%</p> <p>OFF to Modify NO</p> <p>FUNCTION The total leakage inductance represented as a percentage of main inductance.</p> <p>SETTING UP This parameter is not usually adjusted by the user.</p> <p>In Open Loop mode, sigma should be set to 6% for motors below 7.5kW and for motors above this the following calculation can be used (however 6% should suffice for most cases).</p> <p>$\text{Sigma} = ((\text{No load current} / \text{Rated current})^2) * 0.8$</p>
------------	--

X3e FIELD WEAKENING POINT

X3e	<p>Screen FLD WEAK=100%</p> <p>Description FIELD WEAKENING POINT</p> <p>Range 50 to 100%</p> <p>Units PERCENT OF AVAILABLE VOLTAGE</p> <p>Default Value 100%</p> <p>OFF to Modify NO</p> <p>FUNCTION May be used to force the Elite Series to enter the field weakening region at less than the maximum potential voltage. The advantages of this is that it then leaves some voltage available to maintain full vector control - i.e., response in the field weakening region is improved.</p> <p>The disadvantage is that since full voltage is not available, rated power cannot be achieved. If left at 100%, full voltage is applied to the motor and in the field weakening region vector control transitions to slip control. Torque response is slower in, and during exit of, this region.</p> <p>SETTING UP If highly dynamic performance is not required (near maximum output voltage of the Elite Series), leave set to 100%. Otherwise set to approximately 90%. Note that the achievable motor power will be reduced in proportion.</p> <p>For Open Loop mode, this value is also the point at which the system transitions between Open Loop normal mode and Open Loop overspeed mode.</p>
------------	--

SUBGROUP X4: LOAD TUNING

Screen **X4a MIN. FLX=100%**
 Description DYNAFLUX MINIMUM FLUX LEVEL
 Range 40% to 100%
 Default 100%
 Note Dynaflux only operates in V/Hz control mode.

FUNCTION Sets the minimum flux level that the motor will be operated at under reduced load conditions.

The Elite incorporates the Dynaflux (dynamic flux) automatic motor flux optimising system. This system is particularly useful for reducing noise and power loss by automatically reducing motor flux levels (and so losses and noise), in reduced load situations.

SETTING UP If the flux reducing feature is not required, leave set at 100% (factory set value).

Dynaflux is best suited for slowly varying loads (e.g., pump and fan). This is due to the possibility of motor stall, upon a rapid load increase at a time when there is insufficient fluxing.

For fan and pump (or similar) loads, set to the lowest value, consistent with reliable operation. Usually 40% will be suitable.

Using a value which is too low can lead to instability or surging. If this occurs, increase the minimum flux level.

Selecting intermediate levels of minimum fluxing caters for more dynamic loads with reduced amounts of Dynaflux action.

Set the minimum flux level to 100% for highly dynamic loads (e.g., servos and cranes).

Screen **X4b STR TYP=AUTO**
 Description STARTING BOOST TYPE
 Range FIX/AUTO/CUR
 Default Value AUTO
 OFF to Modify YES
 Note Starting Boost selection is only available in V/Hz control mode.

FUNCTION Provides compensation to start difficult loads. Under V/Hz control a compensating boost may be applied to the motor in order to obtain full torque at low frequency. This screen permits configuration for Automatic Voltage Boost [AUTO], Fixed Voltage Boost [FIX], or Current Controlled Boost [CUR]. Open Loop mode can use any setting of this variable.

SETTING UP The Start Boost Type provides three different starting torque profiles – the most suitable of which depends on the application.

Automatic Voltage Boost
 For normal single motor operation, the automatic voltage boost [AUTO] provides the best performance. In this mode the boost level is automatically adjusted according to the load conditions. Automatic voltage boost does not operate at zero frequency, therefore applications which are required to produce torque at zero frequency (e.g., hoists) must have the Start Boost Type set to [FIX] or [CUR].

Fixed Voltage Boost

This starting boost type may be used with simple non-varying loads. However, for multiple motor operation, fixed voltage boost [FIX] must be selected to provide reliable starting.

X4a

Current Controlled Boost
 Current controlled boost [CUR] should be used for high stiction loads that are unable to be started using the voltage boost modes [AUTO], [FIX]. This mode allows the starting profile to be tuned using Screens X4c and X4d, where the boost level and the region it operates over are defined.

X4b

X4c

NOTES Screen X4c defines the level of boost that will be applied and must be set to a level appropriate to the motor being used.

Screen **X4c STR TQ=0%**
 Description STARTING TORQUE (BOOST) ADJUSTMENT
 Range 0 to 250%
 Default Value 0%
 OFF to Modify NO

FUNCTION Provides improved low speed torque performance when an encoder is not used, i.e., in Open Loop Mode or V/Hz modes (refer to Screen X1).

SETTING UP This screen has different setting up procedures depending on the control mode (Screen X1) and the starting boost type (Screen X4b) selected.

When using V/Hz with Automatic or Fixed Voltage Boost, adjustment should be made until sufficient starting torque is developed to start the load. If the load is such that the adjustment levels required to start the load causes the Elite Series to enter a current limiting protection state, then Current controlled Boost (rather than Automatic or with fixed voltage Boost) is recommended.

When using V/Hz Current Controlled Boost, adjust the Starting Torque level so that the load starts and smoothly accelerates. High levels of adjustment may require the Torque Limit screens (Screens L4 and L5) and Current Limit screen (Screen L9) to be adjusted. The Starting Torque adjustment should be used in conjunction with the Starting Band adjustment (Screen X4d) to provide the desired starting torque profile. Levels far in excess of that required by the load should be avoided, as this will cause increased heating of the motor.

When using Open Loop Mode, adjust the starting Torque to the desired starting Torque level.

When using Closed Loop Vector Mode the starting torque adjustment has no affect.

Screen **X4d STR BAND=10%**
 Description STARTING (BOOST) BAND ADJUSTMENT
 Range 0 TO 99% OF RATED (NAMEPLATE) MOTOR FREQUENCY
 Default Value 10%
 OFF to Modify NO

Note Start Band only operates in V/Hz mode if current controlled boost is selected.

X4d	<p>FUNCTION Provides speed related profiling of the starting torque for the current controlled boost (Screen X4b STR TYPE=CUR).</p> <p>For Open Loop, this parameter determines the transition from Open Loop start mode to Open Loop normal mode. When stopping, the drive will re-enter the Open Loop start mode from Open Loop normal mode. This will occur when the speed drops to 4.5% below the STR BAND value. In Open loop mode this cannot be increase above 50% as the overspeed band can be reduced to 50% speed.</p>
X4f	
X4g	
X4h	<p>SETTING UP Adjust the Starting Band to define the region (from zero speed) where the current controlled starting torque is required. When the output speed exceeds this band the boost level will be automatically adjusted to a reduced level to minimise the heating effects of possible high levels set by Screen X4c.</p>
X4i	
X4j	<p>Loads that are characterised by high stiction but relatively low inertia will usually only require a small starting band. High inertia loads may require prolonged Current Controlled Boost to ensure smooth acceleration of the load.</p> <p>It is recommended that the minimum band adjustment necessary to start and accelerate the load be used to avoid undue heating of the motor</p>
NOTES	<p>If this band is set to the default 0% then the starting torque level set by Screen X4c will not have its full effect.</p>

X4f, X4g, X4h ROTOR SPEED PID LOOP GAINS

Note	Only operates in Open Loop or Closed Loop Vector mode.
Screen	X4f Kp w=20%
Description	ROTOR SPEED PID LOOP PROPORTIONAL GAIN
Range	0 to 300%
Default Value	20%
OFF to Modify	NO
FUNCTION	<p>The proportional gain of the rotor speed PID controller.</p> <p>Affects the response, stiffness and damping of the speed loop.</p> <p>In Open Loop mode, set up as per Closed Loop Vector mode.</p>
SETTING UP	<p>The default value is a low, conservative setting. While this may not give the fastest speed response, it will generally be stable. Only adjust this value if setting up for a high performance application.</p> <p>When the system inertia is low, typical maximum values range from 30% (small motors) to 35% (large motors).</p> <p>Where significantly higher inertia are present, the gain may be increased.</p> <p>Gain settings which are too high may cause rapid oscillation of the motor shaft.</p>

Screen	X4g Ki w=30%
Description	ROTOR SPEED PID LOOP INTEGRAL GAIN
Range	0 TO 999%
Default Value	30%
OFF to Modify	NO
FUNCTION	<p>The integral gain of the rotor speed holding PID controller. Affects the long term speed hold accuracy of the speed control loop.</p> <p>In Open Loop mode, set up as per Closed Loop Vector mode.</p>
SETTING UP	<p>The default value is a fairly conservative (over damped) gain, generally assuring stability, but at the penalty of slowed response.</p> <p>A typical maximum value is 50% when the motor has a low attached inertia. With higher inertia, the integral gain may need to be reduced, although increasing the proportional term may retain stability.</p> <p>Gain Settings which are too high may cause rapid oscillation of the motor shaft.</p>
Screen	X4h Kd w=0%
Description	ROTOR SPEED PID LOOP DERIVATIVE GAIN
Range	0 TO 999%
Default Value	0%
OFF to Modify	NO
FUNCTION	<p>The derivative gain of the rotor PID controller. May improve damping of the PID loop in some cases.</p>
SETTING UP	Rarely used. Usually left set to default (zero).
Screen	X4i LS FL BO=0%
Description	FLUX BOOST A
Range	X4j setting to 99%
Default Value	0%
OFF to Modify	NO
FUNCTION	<p>Boost flux to cope with large or unstable loads when operating in Open Loop mode. Increased flux means less torque current is needed to generate a given torque.</p>
SETTING UP	Leave at default unless a large or unstable load is present, a conservative setting of up to 15% is recommended for these loads.
Screen	X4j HS FL BO=0%
Description	FLUX BOOST B
Range	0% TO x4i setting
Default Value	0%
OFF to Modify	NO
FUNCTION	<p>Used in conjunction with FLUX BOOST A in order to phase out the adjustment linearly at higher speeds in order to prevent early onset of Open Loop Mode overspeed mode.</p>
SETTING UP	Leave set to zero if phasing out of FLUX BOOST A is required. For a constant flux boost set to the X4i setting.

X4k	INERTIA COMPENSATION
Screen	X4k INERTIA k=1
Description	INERTIA COMPENSATION
Range	1 to 10
Units	none
Default	1
FUNCTION	The compensation factor for inertia is required for large inertia loads if slip compensation or open loop mode is used. Used for enhancing stability and not for tuning of the speed controller.

SUBGROUP X5: CONTROLLER TUNING

Note	V/Hz and Open Loop mode only
Screen	X5a ILT SLIP=2.0%
Description	CURRENT LIMIT SLIP VALUE
Range	0.0% TO 10%, OFF
Default Value	2.0%(dependant on Elite Series model)
FUNCTION	To actively reduce the Elite frequency or acceleration to maintain load current within controllable bounds (status=ILT).
SETTING UP	Do not adjust this unless current limit action is unstable. Nominally this value should be set to the rated percent slip of the motor. To improve stability of current limit use a lower figure (the penalty against this is that predictive current limit action will occur at an earlier stage, more severely limiting acceleration rates and possibly intruding more into the normal area of operation). For optimal operation in Open Loop mode set value to motor slip in per cent.
Screen	X5b VLT SLIP=2.0%
Note	V/Hz only
Description	VOLTAGE LIMIT SLIP
Range	0.0% TO 20%
Default Value	2.0%(dependant on Elite Series model)
FUNCTION	If a motor is overdriven (e.g., by decelerating its attached load too fast) it will regenerate into the Elite. Too much regeneration will cause the Elite to take evasive action ("voltage limiting") by reducing the deceleration rate as regeneration occurs. The voltage limit slip setting is an adjustment which is used to enhance the stability of voltage limiting control.
SETTING UP	Do not adjust this setting unless voltage limiting is unstable. Nominally this value should be set to the rated percent slip of the motor. To improve stability of voltage limit use a lower value. The penalty against this is that voltage limiting will occur at an earlier stage, thus affecting deceleration more. The speed filter setting (Screen R7) may also be used to improve stability during voltage limiting. For optimal operation in Open Loop mode, set value to motor slip in per cent.

Screen	X5c DAMPING=2.0%	X4k
Description	NO LOAD DAMPING	
Range	0% TO 20%	
Default Value	2.0%(dependant on Elite Series model)	
FUNCTION	Some motors may become unstable and appear to surge when operated at light load and at certain speeds. The damping term may be introduced to eliminate this tendency.	X5a
SETTING UP	Do not adjust this value unless light load stability problems exist. Increase setting to improve stability. Increasing the setting too far may induce instability.	X5b
	No load damping introduces very small output frequency variations (typically <0.1 Hz). If absolute fixed output frequency is a specific requirement of your application, set to 0.0%	X5c
Screen	X5d SLIP COMP=N	X5d
Note	V/Hz only	
Description	ENABLE SLIP COMPENSATION	
Default Value	NO COMPENSATION	
FUNCTION	Changes the output frequency based on the load current to compensate for the slip of the motor.	X5e
SETTING UP	If Speed regulation under varying load is required in V/Hz or open Loop control modes - turn on. May be enabled when using Open loop mode, this will assist with speed regulation when in operating in the Open Loop mode overspeed region.	X5f

X5e, X5f MODULATION

Screen	X5e FREQ = AUTO
Description	MODULATION FREQUENCY
Options	AUTO/4000-16000 or 4000-1000 > 22.5
Units	HERTZ
Default Value	AUTO
OFF to Modify	NO
FUNCTION	Alters the output frequency to the motor. May be used to avoid mechanical noise within the motor. AUTO allows the Elite's thermal management system to optimise the switching frequency to maintain reliable operation.
Note:	Maximum frequency on the Elite Series greater than 22.5 Amps is limited to 10000Hz.
Screen	X5f SWITCH FR=WW
Description	MODULATION TYPE
Options	[WW] WHISPER WAVE [NB] NARROW BAND
Units	HERTZ
Default Value	WW
OFF to Modify	NO
FUNCTION	Alters the type of noise produced by the motor. Narrow band produces a conventional fixed frequency noise spectrum. Whisper

X5g

Wave is a special mode which distributes the noise over a wider frequency range. The noise produced in Whisper Wave mode is usually found to be less annoying and easier to mask.

X5h

SETTING UP To allow for direct comparison of the motor acoustic noise level, this mode may be switched while the Elite Series is running. Choose the option that you find most suitable.

X5i

Whisper Wave or Narrow Band should be selected to minimise the audible noise.

Y1

X5g, X5h CURRENT CONTROL LOOP GAIN

Screen X5g Kp I=25%
Description CURRENT PI LOOP PROPORTIONAL GAIN
Range 0 TO 100%
Default Value 25%
OFF to Modify NO
Note Not V/Hz
FUNCTION Proportional gain of the current control loop internal to the flux vector controller.

SETTING UP This parameter is not usually adjusted by the user.

Screen X5h Ki I=13%
Description CURRENT PI LOOP INTEGRAL GAIN
Range 0 TO 100%
Default Value 13%
OFF to Modify NO
Note Not V/Hz

FUNCTION Integral gain of the current control loop internal to the flux vector controller.

SETTING UP This parameter is not usually adjusted by the user.

Screen X5i Kf w=50%
Description ROTOR SPEED FILTER CONSTANT
Range 3 to 100%
Default Value 50%
OFF to Modify NO
Note Closed Loop Vector mode only


FUNCTION A filter gain in the rotor speed feedback. Can improve stability if the encoder coupling to the motor is not completely direct, or not perfect (e.g., due to any degree of backlash or elasticity in the coupling).

Note: The filter time constant in msec is 100/Kfw

SETTING UP Usually left set to 50%. Decrease Kf w to increase effect of filter.

SCREEN GROUP Y: MENU OPTIONS

Group Attribute HIDDEN



Screen Y1 LANGUAGE=1
Description SELECTS LANGUAGE OF SCREEN LIST
Range 1 = ENGLISH
 2 = DEUTSCH
 3 = SPANISH

Default ENGLISH
OFF to Modify NO
Attribute READ-WRITE

FUNCTION Determines the language displayed by the Elite Series

SETTING UP Choose the required language. Further languages will be available on an "as required" basis.

Screen Y2 INITIALISE
Description SELECTS LEVEL OF INITIALISATION OF PARAMETERS AND MODES
Range REFER FIGURE 9.26
Attribute HIDDEN

DISPLAY	DESCRIPTION
NO	Not initialising
INIT USER SETTINGS	Initialises all user settings including menu setup mode with the exception of the motor parameters (Screens N1 to N6, X3 to X5)
INIT MOTOR PARAMS	Initialises all motor parameters (Screens N1 to N6, X3 to X5)
INIT ALL	Initialises all parameters. Available after F18 fault

Figure 9.26: Initialisation Levels

FUNCTION This screen allows for the initialisation of parameters (setting to default values) to the desired level.

If you want to retain settings for re-entry after initialisation, record these settings first, (e.g., on the appropriate Commissioning Configuration Record at the end of this manual).


SETTING UP Select the required level and release the keys. The display will show INITIALISING... while doing so, and returns to NO when completed.

Screen **Y3 PROG 1 of 1**
 Description SELECTS PROGRAM TO USE
 Default 1
 OFF to Modify YES
 Attribute READ ONLY
 FUNCTION Determines the Control program that is running. See Section 8.

SCREEN GROUP Z: COMMISSIONING SCREENS

Y3

Group Attribute READ ONLY



Z

Z Commissioning Mode

SCREEN **Z COMMISSION=NO**
 Description COMMISSIONING MODE
 Range YES or NO
 Default Value NO
 OFF to Modify NO
 Attribute Read only (if password is set)
 Read-Write (if password is not set).
 FUNCTION Commissioning mode is a special mode that allows the commissioning engineer to modify commissioning data.
 SETTING UP Set to YES to enter commissioning mode.

The commissioning mode is normally protected with a password set from Screen Z1. This prevents unauthorised modification to commissioning data.

Once the commissioning data has been entered (and a password set if required), this screen should be set to NO.

Setting to COMMISSIONING mode before a Password has been set:

Scroll to Main Screen Z.
 Z COMMISSION=N

Press "*" and "+" or "-". The control line should change to:
 Z COMMISSION=Y

All screens will now be visible, and all parameters are adjustable.

Selecting COMMISSIONING mode after a Password has been set:

Scroll to Main Screen Z. The display's control (bottom) line will read:
 Z COMMISSION=N

Press "*" and "+" or "-". The screen will automatically display:
 PASSWORD=ZZZZ

Where the number shown as "ZZZZ" is a special hashing number and is required for lost passwords. Refer to the description of Screen Z1.

Now press "*" and "+" or "-" until the correct password is reached. Then release the keys.

Z1	The display's control (bottom) line will now read: Z COMMISSION=Y
Z2	All screens will now be visible, and all parameters adjustable.
Z3	Selecting OPERATION Mode: To change from COMMISSIONING Mode to OPERATION Mode, scroll to Screen Group Z.
Z4	The display's control line will read: Z COMMISSION=Y
Z5	Use "*" and "+" or "-" to toggle to : Z COMMISSION=N
Z1	Commissioning Mode Password
Z5	<p>Screen Z1 PASSWORD=OFF</p> <p>Description COMMISSIONING MODE PASSWORD</p> <p>Range OFF, 1 to 65535</p> <p>OFF to Modify NO</p> <p>FUNCTION Allows the commissioning engineer to set a password to protect against unauthorised modification of commissioning parameters.</p> <p>SETTING UP Once set to COMMISSIONING mode as described above, a password may be set up. Unfold Screen Group Z and scroll to Screen Z1. The display will read: Z1 PASSWORD= OFF.</p> <p>Press "*" and "+" or "-" to set the required password.</p> <p>What happens if a password is unknown or forgotten?</p> <p>Once a password has been entered, a special hashing number is displayed on Screen Z when trying to enter COMMISSIONING mode.</p> <p>The display will read: Z PASSWORD= ZZZZZ</p> <p>Take a note of this number and contact a PDL Electronics Applications Engineer, who with suitable authority will be able to pass this code through an algorithm to reconstruct the original password.</p>
Z2	SOFTWARE AND HARDWARE REVISIONS
Z2	<p>Screen Z2 S/W1.1 H/W1.1</p> <p>Description SOFTWARE AND HARDWARE REVISION NUMBERS</p> <p>FUNCTION Shows the revision number (X.X) of the software and hardware currently fitted to the Elite Series.</p>

Z3	ANALOGUE INPUT 1 STATUS
Z3	<p>Screen Z3 AI1=99=+9.9V or Z3 AI1=99=+20mA</p> <p>Description STATUS OF ANALOGUE INPUT 1</p> <p>Range 00 to 99; -10V to +10V or 0 to 20mA</p> <p>Screen Z3 AI1=99=+9.9V or Z3 AI1=99=+20mA</p> <p>Reference 0 1 2</p> <p>Reference 0: Screen number Z3</p> <p>Reference 1: Status of Analogue Input 1 (Terminal T26) 00 to 99% of the input range</p> <p>For ±10V input, -10V = 00, +10V = 99 For 0-10V input, 0V = 00, +10V = 99 For 4-20mA input, 4mA = 00, 20mA = 99 For 0-20mA input, 0mA = 00; 20mA = 99</p> <p>Reference 2: Status of Analogue Input 1 (Terminal T26) For Voltage inputs, -10V to +10V For Current inputs, 0mA to 20mA</p>
Z4	ANALOGUE INPUT 2 STATUS
Z4	<p>Screen Z4 AI2=99=+9.9V Z4 AI2=99=+20mA</p> <p>Description STATUS OF ANALOGUE INPUT 2</p> <p>Range 00 TO 99; -10V to +10V or 0 to 20mA</p> <p>Screen Z4 AI2=99=+9.9V Z4 AI2=99=+20mA</p> <p>Reference 0 1 2</p> <p>Reference 0: Screen number Z4</p> <p>Reference 1: Status of Analogue Input 2 (Terminal T27) 00 to 99% of the input range</p> <p>For ±10V input, -10V = 00, +10V = 99 For 0-10V input, 0V = 00, +10V = 99 For 4-20mA input, 4mA = 00, 20mA = 99 For 0-20mA input, 0mA = 00; 20mA = 99</p> <p>Reference 2: Status of Analogue Input 2 (Terminal T27) For ±10V input, -10V to +10V For 0-10V input, 0V to +10V For 4-20mA input, 4mA to 20mA For 0-20mA input, 0mA to 20mA</p>
Z5	ANALOGUE OUTPUT 1 STATUS
Z5	<p>Screen Z5 AO1=99=+9.9V Z5 AO1=99=+20mA</p> <p>Description STATUS OF ANALOGUE OUTPUT 1</p> <p>Range 00 TO 99; -10V to +10V or 0 to 20mA</p> <p>Screen Z5 AO1=99=+9.9V Z5 AO1=99=+20mA</p> <p>Reference 0 1 2</p> <p>Reference 0: Screen number Z5</p> <p>Reference 1: Status of Analogue Output 1 (Terminal T23) 00 to 99% of the input range</p> <p>For ±10V output, -10V = 00, +10V = 99 For 0-10V output, 0V = 00, +10V = 99 For 4-20mA output, 4mA = 00, 20mA = 99 For 0-20mA output, 0mA = 00; 20mA = 99</p>

Reference 2: Status of Analogue Output 1 (Terminal T23)
 For $\pm 10\text{V}$ output, -10V to +10V
 For 0-10V output, 0V to +10V
 For 4-20mA output, 4mA to 20mA
 For 0-20mA output, 0mA to 20mA

Z6 ANALOGUE OUTPUT 2 STATUS

Screen **Z6 AO2=99=+9.9V or
Z6 AO2=99=+20mA**

Description STATUS OF ANALOGUE OUTPUT 2
 Range 00 to 99;
 -10V to +10V or 0 to 20mA
 Attribute Read Only

Screen **Z6 AO2=99=+9.9V or
Z6 AO2=99=+20mA**

Reference **0 1 2**
 Reference 0: Screen number Z6
 Reference 1: Status of Analogue Output 2 (Terminal T24)
 00 to 99% of the input range
 For $\pm 10\text{V}$ output, -10V = 00, +10V = 99
 For 0-10V output, 0V = 00, +10V = 99
 For 4-20mA output, 4mA = 00, 20mA = 99
 For 0-20mA output, 0mA = 00; 20mA = 99

Reference 2: Status of Analogue Output 2 (Terminal T24)
 For $\pm 10\text{V}$ output, -10V to +10V
 For 0-10V output, 0V to +10V
 For 4-20mA output, 4mA to 20mA
 For 0-20mA output, 0mA to 20mA

Z7 MULTIFUNCTION INPUT STATUS

Screen **Z7 MFI:000000 X**

Description STATUS OF MULTI-FUNCTION INPUTS
 Range O (OPEN) or X (CLOSED)
 Attribute Read Only

Screen **Z7 MFI:000000 X**

Reference **0 1 2 3 4 5 6 7**
 Reference 0: Screen number Z7
 Reference 1: Status of Digital Input 1 (Terminal T13)
 O - Open
 X - Closed

Reference 2: Status of Digital Input 2 (Terminal T14)
 O - Open
 X - Closed

Reference 3: Status of Digital Input 3 (Terminal T15)
 O - Open
 X - Closed

Reference 4: Status of Digital Input 4 (Terminal T16)
 O - Open
 X - Closed

Reference 5: Status of Digital Input 5 (Terminal T17)
 O - Open
 X - Closed

Reference 6: Status of Digital Input 6 (Terminal T18)
 O - Open
 X - Closed

Reference 7: Status of External Trip Input (Terminal T19)
 O - Open
 X - Closed

Note 1: Multi-function inputs - O or X represent only an Open (circuit not connected to the common) or a Closed (circuit connected to the common) respectively.

Z8 FIBRE OPTIC INPUT STATUS; SERIAL INPUT STATUS

Screen **Z8 FI:O SERIAL:O**

Description STATUS OF FIBRE OPTIC INPUT;
STATUS OF SERIAL INPUT
 Range O (INACTIVE) or X (ACTIVE);
O (INACTIVE) or X (ACTIVE);
 Attribute Read Only

Screen **Z8 FI:O SERIAL:O**

Reference **0 1 2**
 Reference 0: Screen number Z8
 Reference 1: Status of Fibre Optic Input
 O (Inactive)
 X (Active)

Reference 2: Status of Serial Input
 O (Inactive)
 X (Active)

Note 1: An Active (X) status indicates that a valid fibre optic data packet has been received since the last screen update. An Inactive (O) status indicates that no valid data packet has been received since the last screen update.

Note 2: An Active (X) status indicates that a valid serial communication data packet has been received since the last screen update. An Inactive (O) status indicates that no valid data packet has been received since the last screen update.

Z9 ENCODER COUNT

Screen **Z9 ENCODER=0000**

Description ENCODER COUNT
 Range 0 to 16383

FUNCTION Encoder counter; displays the number of edges counted by the incremental encoder input terminals (Terminals T31 to T34). Increasing count should correspond with forward rotation (see Section 4.2 and Screen N8 for more information).

EXAMPLE For a 2000 ppr encoder, this status screen should increase by 2000 counts for a 360° rotation of the motor shaft, in the forward direction.

Z9a ENCODER SPEED

Screen **Z9a TACHO=0.0%**

Description ENCODER SPEED

FUNCTION Displays the speed of the encoder as a % of motor synchronous speed.

This screen is useful for checking for faults in the encoder and encoder wiring.

Z10	Z10	OUTPUT RELAY STATUS; DYNAMIC BRAKE OUTPUT STATUS
	Screen	Z10 RLY:XXX DB:X
Z11	Description	STATUS OF OUTPUT RELAYS; STATUS OF DYNAMIC BRAKE OUTPUT
	Range	O (OPEN) or X (CLOSED); O (OPEN) or X (CLOSED);
	Attribute	Read Only
Z12	Screen	Z10 RLY:XXX DB:X
	Reference	0 1 2 3 4
	Reference 0:	Screen number Z10
	Reference 1:	Status of Output Relay 1 (Terminals T1/T2) O (Open) X (Closed)
	Reference 2:	Status of Output Relay 2 (Terminals T4/T5) O (Open) X (Closed)
	Reference 3:	Status of Output Relay 3 (Terminals T6/T7) O (Open) X (Closed)
	Reference 4:	Status of Dynamic Brake (DB) Output O (Open) X (Closed)
	Note 1	RLY1 is normally open on Terminals (T1/T2) RLY1 is normally closed on Terminals (T2/ T3) RLY2 is normally open on Terminals (T4/T5) RLY3 is normally open on Terminals (T6/T7) The status of the change-over relay (RLY1) on the normally closed terminals (Terminals T2/T3) is the inverse of reference 1.
	Note 2	A Closed (X) status indicates that the Dynamic Brake (DB) output has been closed in the interval since the last screen update. An Open (O) status indicates that the Dynamic Brake (DB) output has not been closed in the interval since the last screen update.
	Z11, Z12	FIBRE OPTIC INPUT AND OUTPUT STATUS
	Screen	Z11 F I/P=+0.0%
	Description	FIBRE OPTIC INPUT STATUS
	Range	-250% to +250%
	Attribute	Read Only
	FUNCTION	Indicates the level of the data on the fibre optic input port. The status indicates the magnitude and sign of the data packet being received by the Elite Series fibre optic input port.
	Screen	Z12 F O/P=+0.0%
	Description	FIBRE OPTIC OUTPUT STATUS
	Range	-250% to +250%
	Attribute	Read Only
	FUNCTION	Indicates the level of the data on the fibre optic output port. The status indicates the magnitude and sign of the data packet being sent by the Elite Series fibre optic output port. Refer to Screen Z8 for an indication of fibre optic input errors.

10 APPLICATION EXAMPLE - SIMPLE FAN SPEED CONTROL

A typical application example is for simple fan speed control using a potentiometer to set 0-10V speed reference, and pushbuttons for start and remote stop-reset control. External speed monitoring is achieved using a simple 0-10V meter representing 0-100% speed. This section shows the configuration, wiring and adjustment of a typical example.

The example given is of a system of the following specification:

Control signal 0-10V (potentiometer)

Motor 5.5kW, 11.4A, 400V 1450rpm

Elite Model ME-12

Stop/start control 3 wire

Direction control None required

The configuration table (not including irrelevant and/or settings that have not been altered from factory set values) and wiring configurations follow:

SIMPLE FAN SPEED CONTROL EXAMPLE CONFIGURATION TABLE

DRIVE NO:	MODEL:	ME-12			
LOCATION:	FAN SPEED CONTROL				
MOTOR:	KW:	5.5	A:	11.4	V: 400
POLES:	4	RPM:	1450		

SETUP:

Using the procedure as set up in Section 2.1:

Set up the motor information of Screen Group N:

N1 MTR CUR=11.4A

N2 MTR VOLT=400V

N3 MTR FR=50Hz

N3 MTR RPM=1450

N6 MTR COOL=40%

Set the limits of operation using Screen Group L:

L2 MIN S=0.0%

L3 MAX S=+100%

L9 I LIMIT=17.1A (this represents 150%)

Set up the control sources via Screen Group I:

I1 LOCAL S/STP=0 (Local control disabled)

I2 REF S=AIN1

I6a AI1=0-10V

I6b AI1 LO=0%

I6c AI1 HI=+100%

I7a I/P MODE=1 (Remote 3 wire control)

External monitoring of speed is achieved via Screen Group O:

O1a AO1 O/P=06 (%of motor speed)

O1b AO1=0-10V

O1c AO1 LO=0%

O1d AO1 HI=+100%

The ramp rates are then set via Screen Group R:

R1 ACC=5.0%/s

R2 DEC=5.0%/s

R6 STOPR=10.0%/s

START is activated by momentarily closing the normally open pushbutton connected at Terminal T14. This starts the Elite Series accelerating the motor to the reference speed defined by the potentiometer connected at Terminal T26.

STOP is activated by momentarily opening the normally closed pushbutton connected at Terminal T15. This stops the Elite Series decelerating the motor to zero speed.

The acceleration and deceleration rates are defined by Screens R1 and R2.

By momentarily opening the normally closed EXT TRIP pushbutton connected at Terminal T19 the Elite series will trip, displaying the fault condition "22 EXT/PTC".

By opening the normally closed switch connected at Terminal T13, the Elite Series will stop, decelerating the motor using the stop rate defined by Screen R6 (This overrides the deceleration rate defined by Screen R2). If any internal or external fault should occur, then the Elite Series may be reset (once the fault condition has been removed) upon the opening edge of the ASTOP-RESET switch.

COMMISSIONING CONFIGURATION RECORD — SCREENS

DRIVE NO: _____ MODEL: _____

LOCATION: _____

MOTOR KW: _____ A: _____ V: _____

POLES: _____ RPM: _____

RECORD 1 RECORD 2

DATE: / / / /

BY: _____

SCREEN UNIT

KEYBOARD CONTROLS

A1 LOCAL MODE=SP _____

A2 LOCAL TQ=+0.0% % _____

A3 LOCAL SP=+100.0% % _____

COMPARATOR CONTROLS

C1 COMP1 SEL=02 _____

C2 COMP1 ON =+100% % _____

C3 COMP1 OFF=+90% % _____

C4 COMP2 SEL=02 _____

C5 COMP2 ON =+100% % _____

C6 COMP2 OFF=+90% % _____

DYNAMIC BRAKE CONTROLS

D1 DB TIME=10s SEC _____

D2 DB DUTY=OFF % _____

SERIAL COMMUNICATIONS CONTROLS

H1 PROTOCOL=M _____

H2 COMS T/O=OFF SEC _____

H3a COMMS ADR=10 _____

H3b BAUDRATE=9600 _____

H3c PARITY=EVEN _____

H4a MAC ID=63 _____

H4b BAUDRATE=125kps _____

H4c ASM IN=70 _____

H4d ASM OUT=20 _____

H4e CTRL SRC=00 _____

H4f REF SRC=00 _____

INPUT CONTROLS

I1 LOCAL S/STP=STR/STP RESET _____

I2 REF S=LOCAL _____

I3 REF T=NULL _____

I4 AREF S=AIN1 _____

I5 AREF T=NULL _____

SCREEN UNIT

I6a AI1=0-10V _____

I6b AI1 LO=0% % _____

I6c AI1 HI=+100% % _____

I6d AI2=0-10V _____

I6e AI2 LO= 0% % _____

I6f AI2 HI=+100% % _____

I6g ZERO BAND=N _____

I7a I/P MODE=0 _____

I7b POLARITY=Hi _____

I7c MFI1 SEL=00 _____

I7d MFI2 SEL=00 _____

I7e MFI3 SEL=00 _____

I7f MFI4 SEL=00 _____

I7g MFI5 SEL=00 _____

I7h MFI6 SEL=00 _____

I8a F LO =-100% % _____

I8b F HI = +100% % _____

I8c FIBRE MODE=0 _____

I8d FIB T/O=OFF SEC _____

L LIMITS

L2 MIN S=-110% % _____

L3 MAX S=+110% % _____

L4 MIN T=-150% % _____

L5 MAX T=+150% % _____

L6 SP T/O=INF _____

L7 TQ T/O=INF _____

L8 REGEN=150% % _____

L9 I LIMIT=* AMP _____

L10 SKIP1=+0.0% % _____

L11 SKIP2=+0.0% % _____

L12 SK BW=0.0% % _____

L13 GND ILT=12A AMP _____

L14 MIN SP RUN=Y _____

MULTI-REFERENCE

M1 MREF1=+0.00% % _____

M2 MREF2=+0.00% % _____

M3 MREF3=+0.00% % _____

M4 MREF4=+0.00% % _____

M5 MREF5=+0.00% % _____

M6 MREF6=+0.00% % _____

M7 MREF7=+0.00% % _____

MOTOR NAMEPLATE PARAMETERS

N1 MTR CUR* AMP _____

N2 MTR VOLT=400V VOLT _____

N3 MTR FRQ=50Hz Hz _____

N4 MTR PWR* kW _____

N5 MTR RPM* RPM _____

N6 MTR COOL=40% % _____

N8 ENCODER=0 _____

N9 ENC I/P=DIFF _____

OUTPUT SIGNALS

O1a AO1 O/P=06 _____

O1b AO1=+/-10V _____

O1c AO1 LO= -100% % _____

O1d AO1 HI=+100% % _____

O1e AO2 O/P=02 _____

O1f AO2=+/-10V _____

O1g AO2 LO= -100% _____

O1h AO2 HI=+100% % _____

O2a RELAY1=02 _____

O2b RELAY1 INV=N _____

O2c RELAY2=05 _____

O2d RELAY2 INV=N _____

O2e RELAY3=08 _____

O2f RELAY3 INV=N _____

O3a FIBRE O/P=06 _____

PROCESS

P1 PR SRC=NULL _____

P2 FB SRC=NULL _____

P3 Kc = 0.1 _____

P4 Ti = INF SEC _____

P5 Td = 0.0s SEC _____

P6 ERROR=+0.0% % _____

P7 INVERT PID=N _____

ACCELERATION RATES

R1 ACC=10.0%/s %/SEC _____

R2 DEC=10.0%/s %/SEC _____

R3 AACC=* %/SEC _____

R4 ADEC=* %/SEC _____

R5 BRK SP=OFF % _____

R6 STOPR=1300%/s %/SEC _____

R7 SP FILT=* SEC _____

R8 TQ FILT=0.00s SEC _____

START/STOP MODES

S1 START=NORMAL _____

S2 STOP=NORMAL _____

S4 ASTOP=NORMAL _____

S5 STR DLY=0.00s SEC _____

S6 OFF DLY=1s SEC _____

S7 LOW V TRIP=N _____

S8 BRAKE I=0% % _____

S9 HOLD V=0% % _____

S10 HEAT=OFF % _____

S11 STP T/O=* SEC _____

IMPEDANCES AND GAINS

X1 CTRL TYPE=V/Hz _____

X3a Lm=* % _____

X3b Rs=* % _____

X3c Rr=* % _____

X3d SIGMA=6.0% % _____

X3e FL WEAK=100% % _____

X4a MIN FLX=100% % _____

X4b STR TYPE=AUTO _____

X4c STR TQ=0% % _____

X4d STR BAND=10% % _____

X4f Kp w=20% % _____

X4g Ki w=30% % _____

X4h Kd w=0% % _____

X4i LS FL BO=0% % _____

X4j HS FL BO=0% % _____

X4k INERTIA k=1 _____

X5a ILT SLP* % _____

X5b VLT SLP* % _____

X5c DAMPING* % _____

X5d SLIP COMP=N _____

X5e FREQ=AUTO _____

X5f SWITCH FR=WW Hz _____

X5g Kp I=25% % _____

X5h Ki I=13% % _____

X5i Kf w=50% % _____

MENU OPTIONS

Y1 LANGUAGE=1 _____

Y3 PROGRAM=1 _____

COMMISSION = Y/N

Z1 PASSWRD=OFF _____

Z2 S/W REVISION _____

Z2 H/W REVISION _____

*Model dependant default

COMMISSIONING CONFIGURATION CONTROL — TERMINALS

				Wire Designation		Wire Colour				
Relay 1	N.O.	T1	O2a	O2b	T1					
	N.C.	T2	Relay Selection =	Inverted=Y/N	T2					
		T3			T3					
Relay 2	N.O.	T4	O2c	O2d	T4					
		T5	Relay Selection =	Inverted=Y/N	T5					
Relay 3	N.O.	T6	O2e	O2f	T6					
		T7	Relay Selection =	Inverted=Y/N	T7					
External D.B. Switch		T8	D1	D2	T8					
		T9	D.B. Time =	D.B. Duty =	T9					
+24V Display DATA 0V		T10	I1		T10					
		T11	Local Start/Stop-Reset=		T11					
		T12		T12						
Multi-function Inputs	MFI 1	T13	I7a	I7c MFI 1=	T13					
	MFI 2	T14	Multi-function Input Mode =	I7d MFI 2=	T14					
	MFI 3	T15		I7e MFI 3=	T15					
	MFI 4	T16		I7f MFI 4=	T16					
	MFI 5	T17		I7g MFI 5=	T17					
	MFI 6	T18		I7h MFI 6=	T18					
Ext Trip/PTC	T19	External Trip /PTC Input			T19					
0V	T20	I7b	Digital Input Polarity = High/Low		T20					
+24V	T21						T21			
0V	T22		O1b	0-10V ±10V	O1c Lo = %	T22				
Analogue Output 1	T23	O1a	Output =	4-20mA 0-20mA	O1d Hi = %	T23				
Analogue Output 2	T24	O1e	Output =	0-10V ±10V	O1g Lo = %	T24				
0V	T25			4-20mA 0-20mA	O1h Hi = %	T25				
Analogue Input 1	T26	I6a	0-10V/ +/- 10V 4-20mA/0-20mA	I6b Lo = %	I6c Hi = %	T26				
Analogue Input 2	T27	I6d	0-10V/ +/- 10V 4-20mA/0-20mA	I6e Lo = %	I6f Hi = %	T27				
Potentiometer Supply 10V	T28						T28			
0V	T29						T29			
Encoder Supply +5V @ 100mA	T30						T30			
Encoder Input	A	T31	N8	N9	T31					
	\bar{A}	T32	Encoder PPR =	Encoder Type =	T32					
	B	T33			T33					
	\bar{B}	T34			T34					
0V	T35						T35			
User Supply +24V @500mA	T36						T36			
0V	T37						T37			
Isolated RS485	A	T38	H3a	H3b	H2	T38				
	B	T39	Communications Address=	Baudrate = 1200 2400 4800 9600 OFF	Comms Timeout = 1s/5s 25s/OFF	T39				
Isolated 0V	T40	T40								
Isolated RS232	Rx	T41							T41	
	Tx	T42							T42	
Fibre Optic In	FI	I8a	Lo = %	I8b	Hi = %	I8c	Mode			
Fibre Optic Out	FO	O3a	Output =			FO				

4808-053 Rev G

ELITE SERIES SPARES LIST

COMMON SPARES

Description	PDL Part No.	Quantity
Elite Control Board	E000-610S	1
Control board fuse link set		1
1A Ceramic, 20x5mm	2401-037	10
Control Wiring plug set		1

MICRODRIVE ELITE SPARES (FRAME SIZE 1)

Common to 400Vac and 500Vac models:		
Heatsink cooling fan	2941-012	
Terminal Shield	3903-124	1
Elite Display 3m cable	E000-621S	1
Microdrive Elite Series display unit	E000-620S	1
ME2.5A to 12A:		
ME-2.5 Gate drive PCB	E002-612S	1
ME-2.5 Terminal PCB	E002-616S	1
ME-2.5/6.5 Power Board	E006-611S	1
ME-6.5 Gate Drive Board	E006-612S	1
ME-6.5 Terminal Board	E006-616S	1
ME-10.5 Gatedrive Bard	E010-612S	1
ME-10.5/12 Power Board	E012-611S	1
ME-12 Gatedrive Board	E012-612S	1
ME-10.5/12 Terminal Board	E012-616S	1
ME2D to 11D:		
ME-2A 500V Terminal PCB	E003-616S	1
ME-6A 500V Terminal Board	E007-616S	1
ME-2/12A 500V Gatedrive Board	E013-612S	1
ME9/11A 500V Terminal Board	E013-616S	1
ME-2/11A 500V Power Board	E013-611S	1

MICRODRIVE ELITE SPARES (FRAMES SIZE 2)

Common to 400Vac and 500Vac models:		
Heatsink cooling fan	2941-012	
Terminal Shield	3903-124	1
Elite Display 3m cable	E000-621S	1
Microdrive Elite Series display unit	E000-620S	1
ME18 to 22A:		
ME-16 Power Board	E016-611S	1
ME-16 Gatedrive Board	E016-612S	1
ME-16 Terminal Board	E016-616S	1
ME-18 Gatedrive Board	E018-612S	1
ME-18/22.5 Power Board	E022-611S	1
ME-22.5 Gatedrive Board	E022-612S	1
ME-18/22.5 Terminal Board	E022-616S	1
ME16D to 21D:		
ME-15/22A 500V Power Board	E023-611S	1
ME-15/22A 500V Gatedrive Board	E023-612S	1
ME-15/22A 500V Terminal Board	E023-616S	1

MICRODRIVE ELITE SPARES (FRAMES SIZE 3)

Common to 400Vac and 500Vac models:		
Microdrive Elite Series display unit	E000-620S	1
Heatsink cooling fans	2941-012	2
ME-31A to 46A:		
ME-31 Power Board	E031-611S	1
ME-31 Gatedrive Board	E031-612S	1
ME-31 Capacitor Board	E031-617S	1
ME-38/46 Power Board	E038-611S	1
ME-38 Gatedrive Board	E038-612S	1
ME-38 Capacitor Board	E038-617S	1
ME-38/46 Power Board	E046-611S	1
ME-46 Gatedrive Board	E046-612S	1
ME-31/46 Rectifier Board	E046-615S	1
ME-46 Capacitor Board	E046-617S	1
ME-31/46 DCCT Interface Board	E046-618S	1
ME-30D to 41D:		
ME-30A 500V Power Board	E032-611S	1
ME-30A 500V Capacitor Board	E032-617S	1
ME-35A 500V Capacitor Board	E039-617S	1
ME-35/46A 500V Power Board	E047-611S	1
ME-30/46A 500V Gatedrive Board	E047-612S	1
ME-30/41A 500V Rectifier Board	E047-615S	1
ME-41A 500V Capacitor Board	E047-617S	1

ULTRADRIVE ELITE SPARES (FRAME SIZE 4)

Common to 400Vac and 500Vac models:		
Ultradrive Elite Series display unit	E000-622S	1
Heatsink cooling fan, Dia. 172mm	2941-015	1
Heatsink cooling fan, 120x120mm	2941-012	1
Internal cooling fan	2941-013	1
UE-60A to 140A (400V):		
UE-60 Power Tray	E060-611S	1
UE-75 Power Tray	E075-611S	1
UE-90 Power Tray	E090-611S	1
UE-115 Power Tray	E115-611S	1
UE-140 Power Tray	E140-611S	1
UE-60/140 RFI PCB Assy	E140-614S	1
UE-55/660 Thermal Sense	E000-619S	1
UE-60/140 PCB Bus Assembly	E140-621S	1
UE-60D to 140D (500V):		
UE-55/60A 500V Power Tray	E061-611S	1
UE-80/140A 500V Power Tray	E141-611S	1
UE-68/75A 500V Terminal Board	E076-611S	1
UE-80/140A 500V PCB Bus	E141-621S	1
UE-55/660A Thermal Sense	E000-619S	1
UE-60/140 PCB Bus Assembly	E141-621S	1

ULTRADRIVE ELITE SPARES 400VAC (FRAMES 5-7)

Description	PDL Part No.	Quantity		
		F5	F6	F7
Elite control PCB	E000-610S	1	1	1
Elite Series display unit - 1.2m cable	E480-620S		1	
Elite Series display unit - 1.7m cable	E660-620S			1
Elite Series display unit - 850mm cable	E250-620S	1		
Fuse link, UE DC fuse board, 2A ceramic 32x6.3mm	2401-004	10	10	10
Fuse link, UE SCR board, 10A ceramic 32x6.3mm	2401-025	10	10	10
Fuse: A1-66C350TS	3302-615	3	6	9
Fuse: A1-66C500TS (E210, E190, E250, E420, E480)	3302-616	3	6	9
Heatsink cooling fan , Dia. 170mm	2941-011	1	1	1
Internal cooling fan	2941-006	1	1	1
SCR Rectifier: PD160F-120	1421-027	1	2	3
Thermstrate, IGBT	1781-104	4	9	12
Thermstrate, rectifier	1781-103	1	2	3
Transistor: SKM 300 GA 123 D, IGBT (E170, E240, E305, E340)	1757-136	4	8	
Transistor: SKM 400 GA 124 D, IGBT (E250, E420, E480)	1757-135	4	8	12
UE-250 Gatedrive board	E250-612S	1		
UE-305/480 Gatedrive board	E480-612S		1	
UE-575/660 Gatedrive board	E660-612S			1
UE-170/660 SCR board	E660-615S	1	2	3
UE-170/660 DC fuse assembly	E660-621S			1
UE-170 Drive select board	E170-623S	1		
UE-190 Drive select board	E190-623S	1		
UE-210 Drive select board	E210-623S	1		
UE-250 Drive select board	E250-623S	1		
UE-305 Drive select board	E305-623S		1	
UE-340 Drive select board	E340-623S		1	
UE-480 Drive select Board	E480-623S		1	
UE-380 Drive select board	E380-623S		1	
UE-420 Drive select board	E420-623S		1	
UE-575 Drive select board	E575-623S			1
UE-660 Drive select board	E660-623S			1
UE-60/660 Thermal sense	E000-619S	1	1	1
UE-660 power tray (incl. power PCB, requires drive select)	E660-611S	1	1	1

ULTRADRIVE ELITE SPARES 500V (FRAMES 5-7)

Description	PDL Part No.	Quantity		
		F5	F6	F7
SCR Rectifier: PD160F-160	1421-040	3	6	9
Transistor: SKM 300 GA 123 D, IGBT (E170, E305, E370)	1757-136	4	8	
Transistor: SKM 400 GA 124 D, IGBT (All other models)	1757-135	4	8	12
Thermstrate, rectifier	1781-103	1	2	3
Thermstrate, IGBT	1781-104	4	8	12
Fuse link, UE DC fuse board, 6.3A ceramic 32x6.3mm	2404-063	2	2	2
Fuse link, UE SCR board, 10A ceramic 32x6.3mm	2404-100	3	6	9
Fan:6424HR 24VDC:Axial 172x150	2941-022	2	5	8
Fan:DV6224R 24VDC:AXL 172X172 (E250)	2941-025	2		
Fan:6424R 24VDC:AXL 172X150 FL (E170, E305)	2941-024	2		
Fuse: A1-66C350TS	3302-615	3	6	9
Fuse: A1-66C500TS (E205, E250, E440, E540, E620, E700)	3302-500	3	6	9
UE:Frame 5 Gatedrive Board	E251-612S	3		
UE:Frame 6 Gatedrive Board	E481-612S		3	
UE:Frame 7 Gatedrive Board	E661-612S			3
UE-170/700A 500V Power Tray (incl. Power PCB, requires drive select)	E661-611S	3	6	9
UE-170/700A SCR PCB	E661-615S	3	6	9
UE-170 Drive Select PCB	E170-623S	1		
UE-205 Drive Select PCB	E211-623S	1		
UE-250 Drive Select PCB	E251-623S	1		
UE-305 Drive Select PCB	E306-623S		1	
UE-370 Drive Select PCB	E371-623S		1	
UE-440 Drive Select PCB	E441-623S		1	
UE-540 Drive Select PCB	E541-623S		1	
UE-620 Drive Select PCB	E621-623S			1
UE-700 Drive Select PCB	E701-623S			1
Elite Series display unit - 850mm cable	E250-620S	1		
Elite Series display unit - 1.2m cable	E480-620S		1	
Elite Series display unit - 1.7m cable	E660-620S			1

ELITE SERIES OPTIONS LIST

OPTION	Part No
Elite Series display unit (3m cable)	E000-621S
DeviceNet interface	EDNI
Profibus DP Interface	PBUS
Interbus interface	IBUS
Serial bus interface	ESBI
Fibre optic cable, 10m	2727-010
Fibre optic cable, 50m	2727-050
IP54 Remote control (graduated potentiometer and on/off switch)	0302
Dynamic Brake 15A (includes resistor)	B015
Dynamic Brake 140A (external resistor required)	B140
UE 170/660 extension Plinth	0397 to 0400
Shaft Encoder Mounting Bracket	0300-BR
Shaft Encoder Coupling	0300-CP
Shaft Encoder 1000ppr & plug	0322-EN

INDEX

		Multi-function Input Inversion	58
		Multi-function Input Modes	21
		Multi-reference	56
A		N	
Acceleration Rate	70	Noise	79
Alternative Acceleration Rate	70	O	
Alternative Deceleration Rate	70, 72	Options List	92
Alternative References	52, 54	Outputs	20
Alternative Stopping Mode	72	Overload	50
Analogue Input Scaling	54	Overspeed	25, 26
Anti-condensation Heater	74	P	
B		Password	40, 82
Bus Voltage	73	Phase Rotation	26
C		PID Control	78
Commissioning	57	Potentiometer Supply	19, 20
Comparators	21, 49, 50	Power	60, 73
Contactors	26	Process control	68, 69
Cooling	34, 35, 49	PTC	25
Coupling	80	R	
Current Control	61, 76	Regeneration	60, 70
Current Limit	50	Relay	20
D		Relays	19, 67
DC Brake	74	Reset	52, 56, 73
DC Heating	74	Revolutions Per Minute (RPM)	63
DC Holding	74	Rotor Resistance	76
Deceleration Rate	70	Rotor Speed Filter Constant	80
DeviceNet	52	S	
Digital Inputs	21	Screening	20
Digital Outputs	67	Serial Communications	52
Direction	59, 79	Setpoint	68
Dynamic Brake (DB)	27, 61	Shear-pin	61
E		Skip Speed	61
Encoder	20, 33, 64	Slip Control	76
F		Software Revision	82
Fans	38	Specifications	10
Fault Screen	34, 51	Speed	21, 33, 49
Fibre Optic	59	Speed Filter	71
Field Weakening	76	Speed Limit	35, 50, 59, 79
Fuse Failure	38	Speed Reference	21, 52
Fuses	38	Starting	59, 72, 79
I		Stator Resistance	76
Inertia	78	Status Line	47
Input Scaling	59	Stopping	73
Isolator	26	T	
L		Temperature	35, 49, 50
Leakage Inductance	76	Thermal Model	34, 49
LED Indicators	18	Timeouts	60
M		Torque	26, 50, 71, 76
Magnetising Current	76	Torque Filter	71
Main Inductance	76	Torque Limit	50, 59, 60, 79
Mains Power	73	Torque Mode	26
Maintenance	33	Torque Reference	54
Modulation	79	V	
Motor –		Voltage Limit	34, 50, 60, 70
Frequency	26, 63	W	
PTC	25	Window Comparator	49
Ratings	25, 63	Wiring	33
Sizing	25	Z	
Speed	25, 63	Zero Band	55
Temperature	50		
Voltage	49, 63		
Motorised Potentiometer	56		
Multi-function Input	19, 57, 58, 83		

Manufactured by:



PDL ELECTRONICS LTD

HEAD OFFICE: 81 Austin Street, Napier, New Zealand ♦ Phone: +64 6 843 5855 ♦ Fax: +64 6 843 5185
Internet: www.pdl.co.nz ♦ Email: electronics@pdl.co.nz
Germany: Nuremberg ♦ Phone: +49 9128 91990 ♦ Fax: +49 9128 9199 80
Distributors in most countries worldwide.



Specifications are subject to change without notice.

4880-012 Rev I

Distributed by: