


Figure 3-1 Terminal arrangement of IS620P



The preceding figure shows arrangement of the terminals in the servo drive.